




STACKED GAS DRYER/WASHER LAUNDRY SYSTEM

MODELS:

WGT4027HW2 (White)


DRYER/WASHER CONTROL PANEL PARTS



DRYER/WASHER CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10414411	Switch, Rotary Encoder (5 Position)	11	W10694669	Harness, Jumper
	W11563107	Owners Manual	6	W10414381	Switch, Rotary Encoder (2 Position)	12	W11579776	Control Unit Assembly, Machine and Motor
	W11082888	Tech Sheet	7	W10420741	Switch, Push To Start	13	90767	Screw
	W11097400	Wiring Diagram	8		Knob, Assembly	14	W10642934	Timer Assembly
	W11360572	Energy Guide		W10576636	White/Metallic	15	3389453	Bracket, Hinge
	W11559778	Installation Instructions	9		Knob, Assembly	16	9740848	Screw
2	W11040441	Shield, Console		W10576634	White/Metallic	17	W10636208	Screw
3	W11049351	Button, Push To Start	10	688805	Clip, Spring			
4	W11313670	Console						


DRYER FRONT PANEL AND DOOR PARTS



DRYER FRONT PANEL AND DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	342055	Screw	8	3388229	Retainer	13	3393008	Screw
2	3388958	Panel, Toe	9	3387242	Seal, Front Panel	14	W10610880	Assembly, Door Catch
3	3357011	Screw	10		Hinge, Spring Assembly	15		Handle, Door
4	W10878138	Panel, Front		W10279703	Silver		W10095180	White
5	W10823582	Seal, Door				16	W10529197	Bezel, Door Catch
6	W10878120	Door, Rear	11	W10601014	Strike, Door	17	W11156601	Switch, Door
7	W10322546	Door, Front	12	697773	Screw			


DRYER CABINET AND MOTOR PARTS



DRYER CABINET AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10121316	Clamp, Motor Mount	13	W10239314	Cord, Power	26	W11028800	Cover, Transition Panel (White)
2	W10396030	Motor, Main Drive (60 Hz)	14	W11028744	Magnet, Lid Catch	27	3389272	Panel, Transition
3	3391087	Pulley, Motor (60 Hz.)	15	3389231	Clip, Front Panel	28	W11096834	Top, Dryer (Assembly)
4	3390631	Screw	16	W11341565	Panel, Back Assembly	29	W11028409	Bracket
5	W11107903	Bracket, Motor	17	W11100260	Bracket, Bulkhead	30	3389682	Spacer, Toe Panel
6	W10892491	Rear Panel	18	W11372862	Base, Dryer	31	8281191	Screw
7	343641	Screw	19	W10760374	Bracket, Roller Assembly	32	692400	Screw Grommet
8	W11424535	Bracket, Terminal Block	20	W11575710	Belt, Drive	33	693304	Screw
9	W10773242	Screw	21	694415	Clip, Strain Relief			
10		Panel, Side	22	W10547294	Idler and Pulley Assembly			
	W11043388	White (Left Hand)	23	W10468057	Assembly, Pulley			
	W11043381	White (Right Hand)	24	W10512946	Washer, Tri Ring			
11	3389420	Screw	25	W10446781	Spring, Idler			
12	W11418906	Harness, Main Dryer						

DRYER BULKHEAD PARTS




DRYER BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359272	Shaft, Drum Roller - Left Hand Thread	16	W10001120	Nut, Hex (Left Hand Thread)	30	W10692558	Grill, Outlet
2	90767	Screw	17	W11162462	Bulkhead, Rear	31	W10685669	Assembly, Outlet Housing
3	343641	Screw	18	3387459	Washer	32	3389644	Screen, Lint
4	W10892720	Air Duct Assembly	19	W10359271	Shaft, Drum Roller - Right Hand Thread	33	8566209	Seal, Transition Duct
5	3387910	Collar, Air Duct	20	W10512946	Washer, Tri Ring	34	3387134	Thermostat
6	8544362	Housing, Blower	21	W10314171	Roller, Support	35	3390935	Clip, Duct Locator
7	693995	Screw	22	3357011	Screw	36	697770	Seal, Plate Cover
8	3934666	Nut, Hex	23	W11368933	Burner Assembly (Complete)(60 Hz.)	37	697772	Wheel, Blower
9	3387230	Screw	24	695240	Screw	38	3389445	Duct, Transition
10	697557	Bulkhead, Front	25	W10518375	Assembly, Drum	39	697366	Cover Plate, Blower
11	8563748	Pipe, Exhaust	26	W10219342	Screw	40	3392519	Fuse, Thermal (91C)
12	3390647	Screw	27	W10495828	Seal, Drum Front	41	W10850806	Bracket, Blower
13	697814	Seal, Drum Front	28	8066086	Plug, Drum Hole	42	W11026420	Lint Duct Assembly
14	3392226	Clip, Thermostat	29	3389449	Baffle, Drum			
15	3388697	Fixed, Thermostat (205~F)						

BURNER ASSEMBLY PARTS


USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED, TYPE 3 - MANUFACTURED
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11368933	Burner Assembly (Complete)(60 Hz.)	5	239822	Plug, Pipe	11	686590	Ignitor
2	3391699	Base, Burner	6	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)	12	3393909	Screw
3	8281909	Valve, Gas (60 Hz.)	7	694540	Coil, 60 Hz. (2 Terminal) (Main)	13	338906	Sensor, Radiant
4		Orifice, Burner						Following Parts Not Illustrated
	3394360	Natural Gas	8	694421	Screw, Coil		3392235	Conversion Kit (Type 1 and 2 to Type 4) L.P.G.
	15422	Type 4 (Propane)	9	3387057	Screw			
	3392234	Type 4 (Butane)	10	8578392	Burner			


DRYER SUPPORT AND WASHER HARNESS PARTS



DRYER SUPPORT AND WASHER HARNESS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11028053	Harness, Washer	5	W11026515	Assembly, Channel (Right)	8	3393008	Screw
2	W11136272	Hose, Pressure Switch				9	W11108179	Shield, Thermostat
3	W10585084	Coupling, Pressure Hose	6	W11026516	Assembly, Channel (Left)	10	W11108667	Shield, Front
4	W10210799	Clip, Harness	7	343641	Screw			


WASHER TOP AND CABINET PARTS



WASHER TOP AND CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11177399	Inlet Assembly, Water	11		Top	20	W10660565	Screw
2	W10213953	Screw		W11028798	White	21	356138	Clamp, Hose
3		Assembly, Lid and Bumper	12	21258	Bearing, Lid Hinge	22	W10732708	Foot Assembly, Leveling
	W10027624	White	13	90016	Clip, Harness	23	W10339879	Tie, Cable
4	9724509	Bumper	14	W11028055	Latch, Lid Lock Assembly	24	W11042299	Harness Cover, Rear Inlet
5	9740848	Screw	15	W10567155	Screw	25	W10676061	Cover, Harness
6	91770	Hinge, Lid	16	W11417173	Panel, Rear	26	W11234073	Hose, Outer Drain Assembly
7	W10119872	Screw	17		Cabinet	27	W10280024	U-Bend, Drain Hose
8		Strike, Lid Lock		W10478060	White			
	W10714899	White	18	W10215098	Brace, Cabinet Top - Front			
9	W10273971	Screw						
10	W10192089	Dispenser, Bleach	19	W10512626	Channel, Top Rear			


WASHER BASKET AND TUB PARTS



WASHER BASKET AND TUB PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8575076	Dispenser, Fabric Softener	10	3363003	Mover, Clothes	20	W10821951	Damper Assembly, Tub Suspension (Set Of 4-Includes Suspension Bushings and Suspension Balls)
2	3354733	Cap, Barrier	11	3951608	Spacer-Thrust			
3	W10072840	Seal, Inner Cap	12	3951632	Agitator			
4	W10003790	Screw and Washer	13	W10531289	Ring, Tub	21	W11249320	Harness, Lower
5	3949550	Washer	14	21366	Nut, Spanner	22	W11166073	Hose, Pressure Switch
6	3951744	Agitator (Complete)	15	W10554251	Basket Assembly	23	W11284522	Clip, Harness
7	3951682	Cam, Driven	16	389140	Block, Basket Drive	24	W10580763	Seal, Tub
8	3366877	Dog, Agitator Clutch	17	W10238320	Tub			
9	3952374	Bearing, Cam	18	W10215093	Filter, Drain Pump			
			19	8533928	Screw			

WASHER GEARCASE, MOTOR AND PUMP PARTS



WASHER GEARCASE, MOTOR AND PUMP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10775446	Pump Assembly, Drain	6	W10249633	Screw	12	W10843770	Capacitor, Motor Run
2	W10004910	Screw	7	W10623547	Motor, Drive	13	W10427633	Shield, Pulley Cover
3	W10763078	Hose, Inner Drain Assembly	8	W10094780	Screw	14	357640	Screw
4	8317496	Clamp, Hose	9	W10808317	Belt, Drive	15	W10721967	Splutch Kit (60Hz)
5	W10870910	Gearcase Assembly	10	W11398781	Actuator, Shift			
			11	9741052	Screw			

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350938	Gray Primer
350930	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

3391335	Kit, Side Exhaust
W11106442	Kit- Stability
279948	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing

WATER SYSTEM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

285835	Connector Assembly
285863	4' Drain Hose w/Clamp
285834	Siphon Break Kit
3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
DRNEXT4	Drain Hose Extension Kit Hose, Water Inlet
W10194210	Cold Water
W10194211	Hot Water
W10810281	Washer, Filter
W10242307	Washer, Hose
3976300	Washer, Inlet Hose
3357450	Washer, Hose Adapter
W10269488	Connector, Hose -"Y"