




REFRIGERATOR

MODELS:

WRF535SWHV10 (Black Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	12992602	Screw	21	W10211855	Cover, Unit
	W11580822	Owners Manual	10	W11046934	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)	22		Grille, Toe
	W11647525	Energy Guide					W10534153	Black
	W11623343	Tech Sheet				23	688983	Screw
2		Cabinet (Not a Servicable Part)	11	W10673840	Screw (Stainless)	24	M0108107	Clamp, Tube
3		Cover, Top Hinge Left Hand (Includes Foil)	12	12698403	Plate, Pivot	25	12990702	Screw
	W10337647	Black	13	12726003	Cover, Water Line	26		Shim, Top Hinge
4		Cover, Top Hinge Right Hand	14	12992403	Screw		12999501	Left Hand
	12962302B	Black	15		Hinge, Center		12999502	Right Hand
5	W10208593	Guard, Dual Water Valve		W11610757	Left Hand	27	12990504	Screw
6	W10141622	Brake, Roller	16		Hinge, Center	28	W11446816	Valve, Water Inlet
7		Hinge, Top		W11610758	Right Hand	29	W11534848	Gasket
	W11456626	Left Hand	17		Cover, Corner	30	12961602	Cover, Control Box
	W11456625	Right Hand		12587703B	Black	31	W10317076	Board, HV Control
8	W10528513	Sweep, Dual Tube	18	W11651067	Block, Fill Tube	32	W10296541	Lid, HV Control Box
			19		Assembly, Roller			
				W10515763	Left Hand			
				W10515762	Right Hand			
			20	W10709365	Screw			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13	12806701	Cover, Damper	26	W11551461	Facade, Dispenser
2	W10464764	Module, Light	14	W11657832	Insulation, Damper	27	W11437528	Plate, Switch
3	W10746278	Overlay	15	W10594329	Control, Damper	28	W11031909	Guide, Waterline
4	W10464767	Module, Control	16	W11536439	Filter, Water	29	12251001	Clip, Water Tube
5	W11593757	Board, Control	17	10685510	Gasket, Seal	30	W11657834	Insulation, Water Tank
6	W10847853	Switch, Rocker	18	61006182	Union, Water	31	B8390302	Clip, Facade
7	W11132917	Cover, Light	19	W11097710	Tank, Water	32	W11437003	Facade, Dispenser (Top)
8	W10443023	Housing, Light	20	12990512	Screw			FOLLOWING PARTS NOT ILLUSTRATED
9	W11468934	Light Module, LED	21	12791416	Thermistor			
10	W11437004	Foam, Plate Switch	22	W11510657	Plate, Filter			
11	12806801	Insert, Damper Cover	23	W11519957	Manifold, Water System	W11609495		Harness, Fresh Food Control (Includes Thermistor)
12	12990604	Screw	24	W11510654	Cover, Filter			
			25	W11495787	Switch, Limit			


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10277025	Module, Light	24	2169142	Blade, Fan
2	A3189392	Gasket, Foam	15	13058002	Clip, Evaporator Motor	25		Bracket, Door
3	W11341630	Guide, Fill Tube	16	W10847849	Switch, Light		W10330991	Left Hand
4	W10157765	Diverter, Air	17		Rail, Side		W10330993	Right Hand
5	13062901	Motor, Evaporator		W11309374	Left Hand	26	12990521	Screw
6	12791419SP	Thermistor		W11309377	Right Hand	27	W10171529N	Pan, Ice
7	12002497	Gear	18	W10662407	Assembly, Drain Funnel	28	W11644400	Slide, Door
8	12815301	Cover, Thermistor	19	M0500703	Seal	29		Adapter, Slide
9	W11468934	Light Module, LED	20	A3189396	Gasket		W10284684	Left Hand
10	W10802332	Shaft, Rack	21	B8381501	Gasket, Drain		W10284685	Right Hand
11	W10308416	Cover, Evaporator	22	13024803	Grille, Freezer Air	30	12990501	Screw
12	12990511	Screw	23	13057901	Shroud, Evaporator Fan	31	W11525253	Assembly, Complete Icemaker
13	W10150583	Grommet, Fan Motor						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	6		Mullion, Door	13	12996601	Clip, Bushing
		Left Hand	12722803BN		Black	14		Latch, Door Closer
	W11622644	Black Stainless	7	12990204	Screw			Left Hand
2		Door, Refrigerator	8		Gasket, Door		W10725268	Black
		Right Hand	W10830162		Grey	15		Latch, Door Closer
	W10879190	Black Stainless	9		Handle, Door			Right Hand
3		Closure, Door	W11101972		Black Stainless		W10725267	Black
	12028505B	Black	10	12990504	Screw	16	W10289497	Bucket, Gallon
4	W11328753	Screw	11		Stop, Door	17	12990518	Screw
5	W10371194	Bucket, Medium		12968202B	Black			
			12	W10884773	Badge			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	2		Handle, Door	3		Gasket, Door
	W10879185	Black Stainless		W11101977	Black Stainless		W10443320	Grey
						4	W11328753	Screw


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	21	W10303521	Sleeve	28	W11332031	Compressor
2	12825803	Blade, Fan	22	W11515437	Assembly, Evaporator and Heater			(Also Order the Following Lokring Parts)
3	W11604794	Basepan			(Also Order the Following Lokring Parts)	W11504416	8.5/6 NR MS 00	(Suction Tube to Compressor)
4	12990511	Screw		W11504423	8/2 NR AL 00	W11504431	7/5 NR MS 00	(Discharge Tube to Compressor)
5	W10350564	Capacitor			(Capillary Tube to Evaporator)	W11506621	6 NK MS 00	(Charging Tube to Compressor)
6	W11566589	Tube, Discharge		W11504415	8.5/8 NR MS 00	W11506635	Tube, Charging (1/4 in w/ Schrader Valve)	
7	W11305540	Harness, Evaporator Heater			(Suction Line to Evaporator)	29	10623002	Clip, Evaporator
8	W10655368	Pan, Drain	23	2169104	Insulation, Sound Deadening	30	12477202	Axle, Roller
9	W10622701	Screw	24	W11505534	Motor, Condenser Fan	31	W11463236	Shroud, Condenser Fan
10	W11287565	Heater, Defrost	25	W11380964	Clip, Heater	32	W10622099	Extension, Drain Tube
11	W11379613	Strap, Bale	26	W11654036	Harness, Unit (Includes Power Cord)	33	2319835	Grommet, Condenser
12	W11359985	Device, Start	27	W10805035	Drier (Service Drier Without Dye)	34	W11244122	Gasket, Foam
13	W10137529	Grommet, Condenser			(Also Order the Following Lokring Parts)	35	W10815863	Clip, Condenser
14	W10236396	Strap, Compressor		W11504445	5/4 NR MS 00	36	W11566588	Tube, Suction
15	12477102	Roller			(Heat Loop to Drier)			REFRIGERANT CHARGE
16	12992101	Screw		W11504447	5/1.8 NR MS 00			54 grams (R600a)
17	10835903	Grommet			(Capillary Tube to Drier)			
18	W11353137	Condenser						
		(Also Order the Following Lokring Parts)						
	W11506623	5 NK MS 00						
		(Discharge Tube to Condenser)						
	W11504432	6/5 NR MS 00						
		(Heat Loop to Condenser)						
19	W10281329	Clip, Drier						
20	W11337767	Tray, Drip						

SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10893772	Glass, Shelf	12	12655402	Slide, Temperature Control	26	12990504	Screw
2		Mount, Gear	13	W10326469N	Rail, Center Crisper	27	12530805SP	Slide, Humidity Control
	W10348259	Left Hand	14	W10235370	Glide, Pantry	28	12655304	Bar, Control
	W10348260	Right Hand	15	W10802333	Shaft, Rack	29	12731302	Drawer, Pantry
3	W10149389N	Lift, Bail Arm	16		Endcap, Pantry	30	12655204	Knob, Temperature Control
4	W10528933	Support, Glass (Includes Pantry Brace)		W10845509	Left Hand	31	12656813	Lid, Pantry
				W10845508	Right Hand	32	W10293682	Bin, Lower
5	12802602SP	Front, Crisper Pan	17	12804601SP	Pan, Crisper	33	13062602	Support, Crisper Frame
6	12531901	Track, Deli Drawer	18	12642303WD	Brace, Crisper Cover	34	W11115256	Basket, Freezer (Upper)
7	W10171558	Divider, Basket (Upper)	19	W10231345N	Trim, Crisper			
8	W10241046	Divider, Basket (Upper)	20	W10329866	Frame, Crisper	35		Gear, Spur
9	12656901	Gasket, Pantry	21	12204824N	Glass, Shelf		W10474716	Left Hand
10	12656202	Housing, Control	22	W10273463	Ladder, Center		W10474715	Right Hand
11	W11350753	Assembly, Shelf	23	W10569182	Ladder, Side			
			24	12990513	Screw			
			25	W10215666	Screw			

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TOUCH-UP PAINT
	72032	Black PAINT, PRESSURIZED SPRAY (12 oz.)
	350939	Enamel, Black
	285006	Black Important: The spray paint is not to be used where the paint may make contact with the door gaskets.
		MISCELLANEOUS
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet TORX SCREW WRENCH
	1117510	Torx Key