




30" FREESTANDING GAS RANGE

MODELS:

WFG770H0FZ2 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Cooktop (Includes Hinges)	14	W10879790	Grate Hinge Spacer
	W11426597	Owner's Manual		W11418087	Black	15	W10850043	Bezel
	W11427475	Quick Start Guide	6		Panel, Manifold	16		Hinge, Grate (Not Serviced)
	W11336169	Tech Sheet		W10864528	Stainless	17	W11367086	Spreader, Flame (Center)
2		Burner Cap Kit	7		Knob	18	3196184	Screw
	W11352138	Black (Set of 4)		W10862482	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
3	W10067840	Screw	8		Grate Kit		W11451587	Harness, Main
4	W11352018	Spreader, Flame (Left Front & Right Front)		W11241659	Black(Set of 2)		W10753750	Harness, Bake/Broil
	W11352020	Spreader, Flame (Left Rear)	9	W10673618	Screw		3196896	Clip, Wire
	W11352021	Spreader, Flame (Right Rear)	10	W11379946	Manifold Panel Bracket		W10334923	Clip, Gas Wiring
			11	W11379358	Rear Gas Cooktop Bracket		3196520	Clip, Wire
			12	W11379945	Bracket, Anti-Tip		313438	Clip, Harness
			13	7101P485-60	Screw, Anti-Tip Kit			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6	W10192841	Shield, Heat	13	W10551614	Spreader, Clip-Spring
	W11130372	Black (Left)	7	W10901001	MRC Control	14	W10797001	Bracket, Ignitor
	W11130379	Black (Right)	8	W10762981	Bracket, Mounting	15	3196169	Screw
2	W10516123	Bracket, Console Mounting	9	W10184251	Cover, Back	16	3196165	Screw
3		Console	10	3196178	Screw			
	W10318550	Stainless	11		Assembly, Active Overlay			
4	W10920631	Module, Spark DSI		W10840426	Stainless			
5	W10198745	Cover, Upper	12	W10475149	Module, Spark (5+0)			

CHASSIS PARTS



CHASSIS PARTS

Illus.
No.

Part No.

Description

1	W10314347	Assembly, Flue
2	9758701	Spacer, Door
3	W10273002	Bracket, Oven Support
4		Panel, Side
	W10162245	Black
5	W10158780	Cover, Rear Fan
6	W10627802	Switch, Door
7	W10137382	Clip, Panel
8	3196560	Screw
9	W10289077	Receiver, Hinge
10	W10058460	Foot, Leveling
11	W10211368	Bottom, Oven
12	W10586204	Sensor
13	3601P356-45	Baffle, Bake Burner
14	3196178	Screw
15	W10435470	Brace, Main Back
16	W11040249	Assembly, Flue (Upper)

Illus.
No.

Part No.

Description

17	W10362924	Screw
18	W10323077	Diffuser, Flame
19	W10289145	Rack, Oven (Gull-Wing)
20	W10186592	Rack, Oven (Insert)
21	W11491752	Gasket, Door
22	W10031780	Screw
23	W10273195	Shield, Heat
24	W11370463	Rod, Door Switch
25	W10624590	Cord, Power
26	W10035900	Support, Oven Bottom
27	W11379356	Pan, Bake
28	W11430367	Light Assembly
29	W10571723	Bulb, Halogen 40 Watts
30	W10341186	Front Foot Assembly


Illus.
No.

Part No.

Description

31	W10390008	Base Rail Assembly (Left)
	W10390007	Base Rail Assembly (Right)
32	W10531060	Rack, Oven
33	W10874067	Motor, Fan (Convection)
34	W10346154	Cover, Convection
35	W10362924	Screw
36	W10205526	Rack, Oven (Partial)
		INSULATION
	W10526208	Insulation, Wrap
	W10526209	Insulation, Main Back
	4820F015-59	Insulation, Strap
	7111P017-60	Clamp, Wire


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front & Right Front)	19	3196385	Screw
2	W11459262	Orifice Holder Assembly (17K) (Left Front)		W11352013	Valve, Gas (Left Rear, Center)	20	3400016	Screw
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)		W11352015	Valve, Gas (Right Rear)	21	W10827923	Spring, Electrode
	W11459261	Orifice Holder Assembly (8K) (Center)	9	W10224921	Bracket, Aegis	22	W11428831	Electrode (Left Front, Left Rear, Center)
	W11459260	Orifice Holder Assembly (15K) (Right Front)	10	W10439242	Burner, Broiler		W11428858	Electrode (Right Front, Right Rear)
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	11	W10680035	Burner, Bake			FOLLOWING PARTS NOT ILLUSTRATED
3	W10295996	Bracket, Saddle Valve	12	W10720102	Valve, Gas	W11489399		LP 5 Orifice Conversion Kit
4	W10510125	Tubing, Main Supply	13	W10324262	Igniter, Bake	W10566535		LP Conversion Kit (Bake/Broil)
5	W10783317	Switch, 5 Burner Manifold Harness	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
6	3601P336-45	Baffle, Broil Burner	15	W10776437	Fitting, Broil			
7	W11418925	Manifold Assembly	16	W10333842	Electrode, Broil			
			17	W11485987	Orifice (17K) (Left Front)			
				W11485873	Orifice (9.5K) (Left Rear)			
				W11485874	Orifice (8K) (Center)			
				W11428753	Orifice (15K) (Right Front)			
				W11485871	Orifice (5K) (Right Rear)			
			18	3196178	Screw			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Vent
	W10842333	Stainless
2	W10317886	Screw
3	W10772958	Insulation, Door
4	W10297318	Liner, Door
5	W10300487	Glass, Inner
6		Handle, Door
	W10254687	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10327235	Screw
8	W10884775	Badge
9	W10294853	Bracket, Glass Liner
10	W10440013	Hinge, Door (Active)
11		Standoff, Handle
	W10410341	Black
12	W10294851	Rail, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Assembly, Outer Door
	W10871597	Stainless
14	W10426267	Screw
15	W10031790	Screw
16	W10031780	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	4	W10441804	Slide, Drawer (Left)	6		Handle, Drawer
	W11449702	Stainless		W10441805	Slide, Drawer (Right)		W10618239	Stainless
2	3400882	Screw	5	W10318026	Bracket, Mounting	7	3196169	Screw
3	W10688022	Drawer, Storage						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	WA906B	Scraper, Cooktop
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting
	W10432545	Kit, Grill
	W10432019	Alt Cleaning Kit Assembly, Trim (Includes Blind Threaded Insert)
		(5/8")
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		(1 1/8")
	W10731886	Black
	W10731885	White
	W10731887	Stainless
		Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless