




ELECTRIC RANGE

MODELS:

WFC150M0JS4 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	3196178	Screw	11	814399	Receptacle, Element
	W11509595	Owners Manual	6	3195812	Rod, Support			FOLLOWING PARTS NOT ILLUSTRATED
	W11401729	Tech Sheet	7	7101P485-60	Screw, Anti-Tip Kit			
	W11435582	Quick Start Guide	8	3196154	Screw		W11452635	Harness, Main
2	W10196406	Bowl, Drip (6 in)	9	W11364018	Element, Coil Heating (1500W)		W11134595	Harness, Cooktop
		(Right Front and Left Rear)			(Right Front and Left Rear)		W10281322	Kit, Bare Wire Adapter Block
	W10196405	Bowl, Drip (8 in)		W11364019	Element, Coil Heating (2400W)			
		(Left Front and Right Rear)			(Left Front and Right Rear)			
3		Cooktop						
	3186233	Black	10	W11379945	Bracket, Anti-Tip			
4	3195060	Hinge, Cooktop						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	3196169	Screw	13	3196178	Screw
	W11130372	Black (Left)	6	3400882	Screw	14	3196200	Clip, Spring
	W11130379	Black (Right)	7		Knob, Infinite			
2	W10695491	Bracket, Control		W11022718	Black			
3		Panel, Control	8	W10134247	Shield, Heat			
	W11027439	Stainless	9	3196165	Screw			
4	3148952	Switch, Infinite (Yellow)	10	8272473	Cover, Upper Rear			
		(Right Front and Left Rear)	11	W10525121	Bracket, Console Mounting			
	3148954	Switch, Infinite (Orange)	12		Control, Electronic (LCX)			
		(Left Front and Right Rear)		W11536412	Black			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11222267	Tube, Vent	15	W10390008	Base Rail Assembly (Left)	27	W10181986	Sensor, Oven
2	W11380208	Box, Burner				28	3196165	Screw
3		Panel, Side		W10390007	Base Rail Assembly (Right)	29	3186034	Bracket, Service
	W10162245	Black				30	3196178	Screw
4	W11173792	Rack, Oven	16	W10058460	Foot, Leveling	31	3400016	Screw
5	W10129032	Seal, Door	17	W10289077	Receiver, Hinge	32	W10326122	Cover, Terminal Block
6	W10308476	Element, Broil	18	3196172	Screw	33	W10910404	Counterweight
7	W11022836	Element, Bake	19	W10404688	Clip, Oven Support	34	3196560	Screw
8	3400029	Nut	20	W10674705	Glide, Drawer Front	35	W11510560	Barrier Rail, Rubber (Left and Right)
9	3196548	Fuse, Thermal	21	W10245259	Block, Terminal	36	W11464547	Bracket, Front Frame
10	3196169	Screw	22	W11034869	Screw			FOLLOWING PARTS NOT ILLUSTRATED
11	W10341186	Front Foot Assembly	23	3196174	Screw			
12	W10067840	Screw	24	W11634772	Light Assembly			
13	8054068	Retainer, Insulation	25	W10571723	Bulb, Halogen 40 Watts		8273263	Insulation, Wrap
14	W10137382	Clip, Panel					8272611	Insulation, Back
			26	3196567	Screw			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly (Includes Standoff)	8		Glass Assembly, Outer Door	14	3196165	Screw
	W11026570	Stainless		W10409946	Black	15	W10031790	Screw
2	9761344	Liner, Door	9	W11380221	Retainer, Insulation	16	W10200660	Screw
3	W10480830	Screw	10	W10299225	Hinge, Active	17	W10031780	Screw
4	W10137382	Clip, Panel	11	W11379944	Strap, Door	18		Trim, Lower Door
5	W10884775	Badge	12		Trim, Side		W11444043	Black
6	W11367326	Glass, Inner		W10746436	Black (Left)			
7	W10299227	Hinge, Door (Passive)		W10746435	Black (Right)			
			13	W10327235	Screw			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196165	Screw	3	W10462910	Bracket, Mounting Drawer	5		Panel, Front
2	W10688022	Drawer, Storage	4	W10674708	Glide, Drawer Rear		W10330070	Stainless

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	3184478	Cleaner, Glass
	4396923	Broiler Pan and Grid