




REFRIGERATOR

MODELS:

KRFC300EWH12 (White)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	12		Hinge, Top	21		Shim, Hinge
	W11580822	Owners Manual		W11456626	Left Hand		12999501	Left Hand
	W11647515	Energy Guide		W11456625	Right Hand		12999502	Right Hand
	W11665552	Tech Sheet	13		Cover, Hinge	22		Assembly, Grille (Includes Clips)
2	W11046934	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)			Left Hand (Includes Foil)		W10534154	White
				W10337634	White	23	W10317076	Board, HV Control
3	12698403	Plate, Pivot	14	12992403	Screw	24	W10296541	Lid, HV Control Box
4	W11534848	Gasket	15		Hinge, Center	25	12990702	Screw
5		Assembly, Roller		W11610757	Left Hand	26	12726003	Cover, Water Line
	W10515763	Left Hand	16		Hinge, Center	27	W10208593	Guard, Dual Water Valve
	W10515762	Right Hand		W11610758	Right Hand			
6	W10528513	Sweep, Dual Tube	17		Cover, Corner	28	688983	Screw
7	M0108107	Clamp, Tube		12587703W	White	29	12990504	Screw
8	12961602	Cover, Control Box	18	W10141622	Brake, Roller	30	W10211855	Cover, Unit
9	12992602	Screw	19		Cabinet (Not A Serviceable Part)	31	W11446816	Valve, Water Inlet
10		Cover, Hinge	20	W10709365	Screw	32	W11651067	Block, Fill Tube
		Right Hand						
	12962302W	White						
11	W10673840	Screw (Stainless)						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W11657832	Insulation, Damper	26	12791416	Thermistor
2	W10464764	Module, Light	15	W10594329	Control, Damper	27	B8390302	Clip, Facade
3	W10746278	Overlay	16	W11437003	Facade, Dispenser (Top)	28	W11437528	Plate, Switch
4	W10464767	Module, Control	17	61006182	Union, Water	29	W11658768	Insulation, Tank
5	W11593757	Board, Control	18	W11031909	Guide, Waterline	30	W11495787	Switch, Limit
6	W10847853	Switch, Rocker	19	W11097710	Tank, Water	31	W11437004	Foam, Plate Switch
7	W11132917	Cover, Light	20	W11551461	Facade, Dispenser			FOLLOWING PARTS NOT ILLUSTRATED
8	W10443023	Housing, Light	21	12990302	Screw			
9	W11468934	Light Module, LED	22	W11510657	Plate, Filter	W11609495		Harness, Fresh Food Control (Includes Thermistor)
10	12251001	Clip, Water Tube	23	W11519957	Manifold, Water System			
11	12806801	Insert, Damper Cover						
12	12990604	Screw	24	W11510654	Cover, Filter			
13	12806701	Cover, Damper	25	W11536439	Filter, Water			


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13		Bracket, Door	23	13057901	Shroud, Evaporator Fan
2	A3189392	Gasket, Foam		W10330994	Left Hand	24	2169142	Blade, Fan
3	12002497	Gear		W10330995	Right Hand	25	W10150583	Grommet, Fan Motor
4		Rack, Side	14	W10277025	Module, Light	26	13062901	Motor, Evaporator
	W11310677	Left Hand	15	13058002	Clip, Evaporator Motor	27	W10662407	Assembly, Drain Funnel
	W11310678	Right Hand	16	W10847849	Switch, Light	28	M0500703	Seal
5	W10802332	Shaft, Rack	17	12791419SP	Thermistor	29	B8381501	Gasket, Drain
6	12990501	Screw	18		Cradle, Basket	30	12815301	Cover, Thermistor
7	W10157765	Diverter, Air		W10281115	Left Hand	31	W10171529N	Pan, Ice
8	12990521	Screw		W10281116	Right Hand	32	W11525253	Assembly, Complete Ice maker
9	W11468934	Light Module, LED	19	W11643658	Slide, Door			
10	W11341630	Guide, Fill Tube	20	A3189396	Gasket			
11	W10308416	Cover, Evaporator	21		Adapter, Side			
12	12990511	Screw		W10284692	Left Hand			
				W10284693	Right Hand			
			22	13024803	Grille, Freezer Air			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left	10	W10449760	Gripper, Gallon	18		Latch, Door Closer
	W11622646	White	11	W10289497	Bucket, Gallon			Right Hand
2		Door, Right	12		Mullion, Door		W10833738	White
	13107887W	White		12722803W	White	19	12990518	Screw
3	12744905	Assembly, Dairy	13		Closure, Door	20	12996601	Clip, Bushing
4	12369502SP	Tray, Dairy		12028505W	White			
5	W10371194	Bucket, Medium	14		Stop, Door			
6	12990204	Screw		12968202W	White			
7	W11328753	Screw	15	12990504	Screw			
8		Gasket, Door	16	12804701SP	Door, Dairy			
	W10830189	White	17		Latch, Door Closer			
9		Handle, Door			Left Hand			
	W11339136	Stainless		W10833740	White			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	3		Gasket, Door	5		Nameplate
	12977879W	White		W10443319	White		W10765861	Grey
2		Handle, Door	4	W11328753	Screw			
	W11222206	Stainless						


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	20	W11337767	Tray, Drip	28	W11629397	Compressor (Also Order the Following Lokring Parts)
2	12825803	Blade, Fan	21	W10303521	Sleeve			
3	W11604794	Basepan	22	W11515437	Assembly, Evaporator and Heater			
4	12990511	Screw			(Also Order the Following Lokring Parts)		W11504416	8.5/6 NR MS 00 (Suction Tube to Compressor)
5	W10350564	Capacitor		W11504423	8/2 NR AL 00 (Capillary Tube to Evaporator)		W11504431	7/5 NR MS 00 (Discharge Tube to Compressor)
6	W11623085	Tube, Suction		W11504415	8.5/8 NR MS 00 (Suction Line to Evaporator)		W11506621	6 NK MS 00 (Charging Tube to Compressor)
7	W11305540	Harness, Evaporator Heater	23	W11244122	Gasket, Foam		W11506635	Tube, Charging (1/4 in w/ Schrader Valve)
8	W10655368	Pan, Drain	24	W11505534	Motor, Condenser Fan	29	10623002	Clip, Evaporator
9	W10622701	Screw	25	W11380964	Clip, Heater	30	12477202	Axle, Roller
10	W11287565	Heater, Defrost	26	W11654036	Harness, Unit (Includes Power Cord)	31	W11463236	Shroud, Condenser Fan
11	W11629200	Strap, Bale	27	W10805035	Drier (Service Drier Without Dye)	32	W10236396	Strap, Compressor
12	W11359985	Device, Start			(Also Order the Following Lokring Parts)	33	W10622099	Extension, Drain Tube
13	W10137529	Grommet, Condenser		W11504445	5/4 NR MS 00 (Heat Loop to Drier)	34	2169104	Insulation, Sound Deadening
14	2319835	Grommet, Condenser		W11504447	5/1.8 NR MS 00 (Capillary Tube to Drier)	35	W10815863	Clip, Condenser REFRIGERANT CHARGE 51 grams (R600a)
15	12477102	Roller						
16	12992101	Screw						
17	W11631702	Grommet						
18	W11597885	Condenser (Also Order the Following Lokring Parts)						
	W11506623	5 NK MS 00 (Discharge Tube to Condenser)						
	W11504432	6/5 NR MS 00 (Heat Loop to Condenser)						
19	W10281329	Clip, Drier						

SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10893771	Glass, Pantry	16		Track, Pantry	31	12656813	Lid, Pantry
2	12802602SP	Front, Crisper Pan		12656105	Left Hand	32	W11115782	Basket, Lower
3	W10742811	Rack, Wine		12656018	Right Hand	33	W10150061	Divider, Basket (Lower)
4	W10528935	Support, Glass	17	12531105SP	Pan, Crisper	34	W11115548	Basket, Freezer (Upper)
5	12227305WH	Brace, Pantry	18	W10832723	Brace, Crisper Cover	35	12709301	Divider, Pantry
6	12531901	Track, Deli Drawer	19	W10231485N	Trim, Crisper	36		Gear
7	12727304	Tray, Lower Basket	20	12531202SP	Frame, Crisper		W10474716	Left Hand
8	W10241046	Divider, Basket (Upper)	21	12204821	Glass, Crisper		W10474715	Right Hand
9	12656901	Gasket, Pantry	22	W10273463	Ladder, Center	37		Mount, Gear
10	12656202	Housing, Control	23	W10569182	Ladder, Side		W10348259	Left Hand
11	W10878953	Assembly, Fixed Top Shelf	24	12990513	Screw		W10348260	Right Hand
12	12655402	Slide, Temperature Control	25	W10215666	Screw	38	W10905889	Assembly, Shelf
13	W10878945	Assembly, Shelf	26	12990512	Screw	39	W10149389N	Lift, Bail Arm
14	W10235370	Glide, Pantry	27	12530805SP	Slide, Humidity Control	40	W10802333	Shaft, Rack
15	12990504	Screw	28	12655303	Bar, Temperature Control			
			29	W11427806	Drawer, Pantry			
			30	12655204	Knob, Temperature Control			

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TOUCH-UP PAINT
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350942	White Primer
		Important: The spray paint is not to be used where the paint may make contact with the door gaskets.
		PAINT, BULK (1 QT.)
	799344	White (Uncut)
		MISCELLANEOUS
	212643	Sealer, Gum (4 Feet)
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet