




27" BUILT-IN COMBINATION MICROWAVE WALL OVEN

MODELS:

KOCE507EBL11 (Black)
KOCE507EWH11 (White)
KOCE507ESS11 (Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W11037652	Chassis, Cover Top Back 27" WIFI	16	W10681157	Cover, Combo Blower
	W10725683	Instructions, Installation	8	7101P426-60	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W10643472	Guide, Use & Care (Oven)	9	7101P434-60	Screw	W11157180		Harness, Main
	W10643473	Guide, Use & Care (Microwave Oven)	10	W10655463	Bracket, Blower (Left)	W11157223		Harness, Signal
	W11041081	Sheet, Tech (English)		W10655462	Bracket, Blower (Right)	W11132989		Harness, Door Latch
	W11041082	Sheet, Tech (French)	11	4451758	Block, Foam	W11229448		Harness, Communication
2		Assembly, Control Panel (Includes Overlay)	12		Skin, Control Panel	W11356968		Harness, Inverter
	W10890571	Black		W10588745	Black	4450800		Screw, Grounding
	W10890567	White		W10588747	White	W11226264		Strap, Ground
	W10890570	Stainless		W10588741	Stainless	4448664		Clamp, Conduit
3	W11040195	Control (With Power Supply)	13	W11037653	Cover, Combo Chassis Back Duct (With Hole)	W10017410		Fuse, Time Delay
4	W11249635	Screw	14	W10618126	Chassis, Back Divider	4454949		Holder, Fuse
5	W11200130	Blower, Dual Speed	15	W10318159	Chassis, Cover Top Front 27"	W10431303		Bag, Hardware
6	W10655467	Chassis, Combo Side						


CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11289998	Manager, Appliance	17	W10490593	Holder, Lamp	36	461967570351	Spring, Torsion
2	423107845441	Sensor, Convection	18	W10795595	Lamp, Halogen	37	461967750494	Support
3	461967848711	Heater, Convection Element	19	W10358241	Assembly, Interlock Switch	38	461967750483	Arm, Sliding
4	461967001792	Fan, Convection	20	461967848881	Switch	39	423107570871	Spring, Release Rod
5	W10120233	Nut, Speed	21	W10876593	Holder, Switch	40	W10769147	Sealing, Lamp
6	W10692851	Filter, Noise	22	423107022541	Reflector	41	461967825781	Screw (Shoulder)
7	461967754821	Duct, Magnetron	23	423107720491	Lens, Lamp			MISCELLANEOUS PARTS
8	461967017511	Trim, Side (Left)	24	461967010591	Clip, Spring	W11356969		Harness, Interlock
	W11044584	Trim, Side (Right)	25	461968973251	Vent, Top	W11356954		Harness, Fan and Turntable
9	461967825321	Screw	26	W10460457	Sensor, Humidity	W11356977		Harness, Cable Tree Assembly
10	461967848621	Transformer, Light (20V)	27	461967008461	Support, Bottom	W11356987		Jumper Harness, Communication
11	461967842541	Thermoactuator	28	461968979601	Hinge, Door			
12	241908600053	Fuse	29	461967848251	Motor, Convection Fan			
13	4375231	Block, Fuse	30	W11131760	Assembly, Cooling Fan			
14	461967846741	Thermostat, Magnetron	31	W11237240	Inverter			
15	W11226473	Magnetron	32	461967825381	Screw			
16	W10465869	Spring, Lamp	33	W10120235	Rod, Release			
			34	241960100002	Sensor, Temperature			
			35	461967510191	Bushing			


MICROWAVE DOOR PARTS



MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door	4		Assembly, Handle	8	W10551026	Medallion, Handle
	W10615380	Black		W10640874	Stainless	9	W10656499	Screw
	W10615381	White	5	8304588BL	Cap, Screw			
	W10615379	Stainless	6	7101P338-60	Screw			
2	W10359769	Foam, Door Handle	7	W10319024	Washer, Door			
3	W10737653	Assembly, Inner Door						


INTERNAL MICROWAVE PARTS



INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461968977491	Plate, Crisp	7	W10367316	Ring, Turntable	13	461967753742	Adapter, Turntable Motor
2	W10796139	Steamer	8	W10545578	Drive, Turntable	14	252262898008	Support, Spring Lock Grill
3	W10748279	Rack, Low Convection	9	461968929542	Handle, Pan			
4	W10750839	Plate, Baking	10	W10387651	Element, Grill			
5	461967848971	Motor, Turntable	11	461967451001	Plate, Cover			
6	W11340343	Turntable	12	461967753871	Support, Element			


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10519707	Cover, Back Duct	19	W10282901	Base, Chassis	35		Trim, Side
2	W11085298	Tube, Vent	20		Assembly, Bottom Vent		W10344483	Black (Left)
3	W11044775	Receiver, Hinge					W10344482	Black (Right)
4	W10618102	Spacer, Base		W10327375	Black	36	W10283023	Support, Crossbar
5	W10618131	Latch, Motorized		W10506345	White	37	W10283025	Side, Bracket
6	W10904159	Chassis, Top		W10351280	Stainless	38	W10360517	Rail, Side (Left)
7	W11198684	Assembly, Oven Light	21	W10283008	Chassis, Bottom Duct	39	W10360519	Rail, Side (Right)
8	W10283020	Support, Base (Left)	22	W10283021	Support, Base (Right)	40	W10696226	Jack, Meat Probe
9	W10904163	Deflector, Blower	23	W10213759	Support, Air Channel	41	W11033111	Nut, Locking
10	W10495155	Vent, Center 27"	24	W10351308	Spacer, Chassis Bottom Duct	42	W11249635	Screw
11	W10282961	Gasket				43	7101P633-60	Screw (Black)
12	W10616810	Cover, Vent Exhaust	25	W10351278	Bumper & Screw			FOLLOWING PARTS NOT ILLUSTRATED
13	W10318190	Side, Chassis	26	W10472386	Lens, Light			
14	W10904162	Back, Chassis	27	7101P426-60	Screw		W10520716	Insulation, Wrap
15		Liner, Oven (Not Serviceable)	28	W10681156	Deflector, Chassis		W10282945	Insulation, Back
			29	W10254050	Screw			
16	W10622170	Probe, Sensor	30	W10347649	Spacers, Front			
17	W10655466	Chassis, Combo Side (Left)	31	9755542	Probe, Temperature			
			32	8285593	Cover, Connector			
	W10283029	Chassis, Combo Side (Right)	33	W10616809	Base, Vent Exhaust			
18	4449751	Thermostat (TOD)	34	W10472384	Bulb, Light			


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11383650	Assembly, Window Pack	9	W11368483	Glass, Inner	19	W10656499	Screw
2	W10284285	Spring, Door Glass Fixation	10	W10284297	Bracket, Glass	20	W11355410	Rail, Door Side (Left)
3	3196183	Screw	11	W10480830	Screw	21	W11355411	Rail, Door Side (Right)
4	W10518672	Badge	12	7101P426-60	Screw			
5	W10320793	Assembly, Liner	13	7101P635-60	Screw (Black)			
6	W10639067	Hinge, Door	14	W10653954	Clip, Spring Metal			
7		Assembly, Door	15	W10687815	Extension, Side Rail (Left)			
	W11318284	Black		W10687814	Extension, Side Rail (Right)			
	W11318285	White	16	W10669415	Shield, Door Liner			
	W11318283	Stainless	17	W10319024	Washer, Door			
8		Assembly, Handle	18	W10551026	Medallion, Handle			
	W10640874	Stainless						

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10764078	Element, Broil	8	W10911205	Shield, Broil Element	16	W10720084	Screw
2	W10554529	Rack, Oven	9	W10722667	Fan, Convection	17	W10906658	Screw
3	W10318198	Tray, Hidden Bake	10	W10631504	Nut, Acorn (LH)			
4	7101P434-60	Screw	11	W10631503	Blade, Fan			
5	7101P426-60	Screw	12	W10546519	Element, Convection			
6	W10282957	Crossbar, Hidden Bake Tray	13	W10819989	Baffle, Bow Tie			
7	W11292248	Element, Bake	14	W10554532	Rack, Sliding			
			15	W10588738	Shield, Broil Front			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black

PAINT, SPRAY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	261900	Citrine White
	830864	Black

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting

ADHESIVE

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic