




GAS DRYER

MODELS:

WGD4850HW2 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10416486	Panel, Rear Console	13	8312709	Clip, Console
	W11361424	Owners Manual	7	90767	Screw	14	W10298336	Nut, "U"
	W11355746	Quick Start Guide	8	688983	Screw	15	3389682	Spacer, Toe Panel
	W10876312	Wiring Diagram	9		Top	16	W11523109	Harness, Main
	W11366444	Cycle Guide		8559800	White	17	3348629	Screw
2	693995	Screw	10		Knob, Push To Start	18	694419	Buzzer, Mini
3		Assembly, Timer Knob		W11160348	White	19	W10420747	Switch, Rotary
	W11158829	White	11	W10436302	Timer Assembly (60 Hz.)	20	W10446920	Switch, Push to Start
4	8536939	Clip, Spring	12		Assembly, Console			
5		Lint Screen						
	W11451394	White		W11178662	White			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8066217	Hinge, Top	17	W10773242	Screw	34	691366	Idler Assembly
2	343641	Screw	18		Cabinet	35	695737	Door, Rear
3	693995	Screw		8530603	White	36		Door, Front
4	W10841728	Seal, Spill Guard	19	98234	Clip, Ground		W10714515	White
5	8558833	Cover, Terminal Block	20	8066092	Lock, Front Top	37		Handle, Door
6	3404162	Clamp, Motor (With Shield)	21		Panel, Front		W10714516	White
				W10664692	White	38	W10803476	Assembly, Seal and Bearing
7	W11598681	Panel, Rear	22	685203	Clip, Felt Pad			
8	W10575896	Clip, Spring	23	337189	Clip, Hinge	39	8066056	Hinge, Door (Right)
9		Plug, Sight Hole	24	3389441	Assembly, Door Catch		8066057	Hinge, Door (Left)
	8564457	White	25	W10823580	Seal, Door	40	342043	Screw
10	W10569603	Switch, Door	26	W10869141	Cord, Power	41	3357011	Screw
11	697773	Screw	27	342055	Screw	42	W11564940	Burner Assembly (60 Hz) (Type 1)
12	W10041960	Spring, Door	28	W10396029	Assembly, Motor			
13	W10121316	Clamp, Motor Mount	29	8066184	Pulley, Motor			
14	341029	Clamp, Pipe	30	3400500	Bolt			
15	W10775448	Clip, Front Panel	31	348780	Base, Motor			
16	W10561321	Foot, Dryer	32	W10131364	Belt, Drive			
			33	696144	Strike, Door			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	16	8066049	Funnel, Burner	28	W10856781	Seal, Rear Drum
2	W10298789	Nut, Hex	17	338906	Sensor, Radiant	29	W10219342	Screw
3	3388703	Washer	18	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	30	692526	Bearing, Ring
4	347139	Seal, Lint Chute	19	W10754607	Thermostat, High Limit SPST (180F)	31	W10714468	Rear Bulkhead
5	90767	Screw	20	489463	Screw	32	3397590	Roller, Support
6	W10389567	Shield, Exhaust	21	3390647	Screw	33	W10359269	Shaft, Drum Roller - Right Hand Thread
7	3392519	Fuse, Thermal (91C)	22	339956	Seal	34	W10359270	Shaft, Drum Roller - Left Hand Thread
8	3387134	Thermostat	23	W11032820	Bracket, Support	35	W10512946	Washer, Tri Ring
9	348197	Washer	24	90296	Nut, Push On	36	8578825	Bracket, Drum Light
10	694089	Wheel, Blower	25	W10757750	Assembly, Drum (Complete)	37	3406124	Bulb, Light
11	8577230	Housing, Blower	26	692490	Baffle, Drum (Long)	38	W10214261	Socket, Light
12	3398161	Clip, Heater Box	27	3403636	Baffle, Drum (Short)			
13	343641	Screw						
14	3402841	Lens, Drum Light						
15	8530285	Box, Heater (96C)						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564940	Burner Assembly (60 Hz) (Type 1)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9		Orifice, Burner			
4	686590	Ignitor		234826	Type 1 (Natural)	W11581316		Kit, LP Conversion
5	W10366705	Screw	10	W11564943	Valve, Gas (60 Hz)			
6	343641	Screw	11	W10295523	Pipe Plug			
			12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	72017	White
--	-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	799344	White (Uncut)
--	--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	350930	White
	350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	279948	Kit, Dryer Repair
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing