




BOTTOM MOUNT FRENCH DOOR REFRIGERATOR

MODELS:

KRFC704FBS00 (Black Stainless)

KRFC704FSS00 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	W10731474	Screw	28	W10754144	Cover, Control Box
		Tech Sheet	15		Hinge, Center	29	W10141645	Screw
	W10832390	English			Left Hand	30	W10669259	Cover, Unit
	W10832391	French		W10691674	Black	31	M0108107	Clamp, Tube
	W10815169	Use and Care Guide		W10816322	Grey	32	W10853597	Tube, Ice maker Water (Includes Seal)
	W11112950	Energy Guide			Right Hand			
2	12990204	Screw		W10691700	Black		W10853599	Tube, Dispenser Water (Includes Seal)
3	W10840312	Block, Pivot		W10816323	Grey			
4	W10838044	Pad, Sound	16	12990702	Screw	33	W10768379	Lid, HV
5	W10789113	Control, Electronic	17		Cover, Corner	34	W10705239	Retainer, Door
6	W10415341	Gasket, HV Box		12587703B	Black	35		Cabinet (Not a Servicable Part)
7		Assembly, Roller		W10868482	Grey	36	549193	Clamp, Power Cord
	W11084045	Left Hand	18	W11095287	Valve, Water	37		Assembly, Inner Air Tunnel (Includes Gasket)
	W11084046	Right Hand	19	W11105994	Switch, Reed		W10835557	Black
8	W10846099	Brake, Roller	20	W10709365	Screw		W10838745	Grey
9	12990521	Screw	21		Divider, Air	38	W10831587	Bushing
10		Hinge, Top		W10878918	Rear	39	W10208592	Cover, Valve
	W11032620	Right Hand		W10878920	Bottom	40	W10485964	Switch, Reed
	W11032616	Left Hand	22		Grille, Toe			
11	W10673840	Screw (Stainless)		W10821308	Black			
12		Cover, Top Hinge		W10821309	Grey			
		Left Hand	23	12992601	Screw			
		(Includes Foil)	24		Assembly, Outer Air Tunnel (Includes Gasket)			
	W10868791	Black		W10835554	Black			
	W10831820	Grey		W10838744	Grey			
13		Cover, Top Hinge	25	W10141645	Screw			
		Right Hand	26	12990511	Screw			
	W10819301	Black	27	W10831131	Assembly, Jumper Wire			
	W10819300	Grey						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10119266	Screw	25	W10815960	Base, Tower Cover
2	W10708473	Housing, Water Tank	15	12990518	Screw	26	W10848895	Harness, Air Tower Jumper
3	W10786645	Strip, LED	16	W11348541	Insulation, Under Filter	27	12990501	Screw
4	W11024082	Reservoir, Water	17	W10817432	Assembly, Air Filter	28	W10877761	Heater, Filter
5	W11490564	Valve, Dual Water	18	W10856502	Cover, Air Filter	29	W10901792	Gasket, Sealing
6	W11024083	Housing, Water Filter	19	W10673133	Bracket, Evaporator Drain	30	W10818463	Gasket, Evaporator Air Dam
7	W10900011	Cover, Water Valve	20	W10813883	Cap, Filter	31	W11307147	Cover, Filter
8	W11517696	Tube, Water Filter	21	W10815735	Assembly, Evaporator Cover (Includes Fan Motor, Wire Assembly and Thermistor)			FOLLOWING PARTS NOT ILLUSTRATED
9	W10815965	Cover, Cooling Duct					W10871610	Assembly, Valve Wire
10	W11259417	Cover, Tower	22	W10635994	Assembly, Evaporator			
11	W10680605	Filter, Water	23	W10906201	Strip, LED			
12	W10315189	Filter, Air	24	W10831305	Insulator, Foam			
13	W10708474	Bracket, Filter						


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	10623002	Clip, Evaporator	14	W10503218	Assembly, Drain Funnel
2	W10882136	Assembly, Evaporator	9	W10683507	Clip, Defrost Heater	15	M0500703	Seal
3	W11228040	Assembly, LED Light Module	10	W10668191	Shield, Heat	16	B8381501	Gasket, Drain
4	W11209447	Assembly, Evaporator Cover (Includes Fan Motor and Wire Assembly)	11	W10683540	Gasket, Drip Tray Rear	17	W10280385	Thermistor
5	12990511	Screw	12		Dam, Air	18	W10770923	Seal, Crisp Front
6	W10882092	Heater, Defrost		W10668201	Left Hand	19	W11206828	Assembly, Icebox Fan
7	W10847855	Switch, Light		W10668198	Right Hand			
			13	W10655745	Assembly, Evaporator Heater Wire (Includes Thermistor)			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator (Also, order item # 18)	10		Bumper, Door	22		Gasket, Door
		Left Hand		W10407187	Black		W10917312	Black
	W10798171	Black Stainless		W10798308	Grey		W10917313	Grey
	W10798170	Stainless	11	W10518672	Badge	23	W10823512	Trim, Gallon
2	W10793652	Assembly, Fill Tube (Icemaker)	12	W11328753	Screw	24	W10795526	Assembly, Utility Bin
			13	W10795606	Trivet, Ice Compartment Door	25	W10795523	Base, Utility Bin
3	W10238319	Screw	14		Bin, Door	26	W10803630	Door, Utility Bin (Includes Gasket)
4	W11554923	Assembly, Ice Door		W10806697	Medium	27	W10795525	Gasket, Utility Bin
5	W10763415	Bracket, Door Stop	15	W10834282	Retainer, Door Duct	28	W10795524	Lid, Utility Bin
6		Mullion, Door	16	W10853441	Gasket, Ice Door	29		Door, Refrigerator
	W11034029	Black	17	W11315303	Clip, Tube			Right Hand
	W11034034	Grey	18	W11045560	Control, Electronic		W10798252	Black Stainless
7	12990204	Screw	19	W10828418	Gasket, Cooling Duct		W10831951	Stainless
8		Handle, Door	20		Bin, Door	30		Closer, Door
	W10704121	Stainless		W10776705	Gallon		W10714907	Left Hand
9	W11035875	Switch, Rocker Arm	21	W10883965	Tube, Water		W10714908	Right Hand


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Door Gasket)	7	12990518	Screw	15		Gasket, Door
	W10798129	Black Stainless	8	W11102087	Assembly, Top Pan		W11563147	Black
	W10832272	Stainless	9	W10277361	Collar, Gear		W11563145	Grey
2		Handle, Door	10	12991401	Screw	16	W10697812	Bar, Support
	W10798381	Stainless	11	W10469177	Support, Pan	17	W10874022	Roller
3	W11328753	Screw	12	489443	Screw (Stainless)	18	W10839803	Axle, Roller
4	W10851956	Shaft, Rack	13	W10795835	Assembly, Upper Half Pan	19	W10830659	Rail, Guard
5		Assembly, Bracket	14		Stop, Pan	20	W10837296	Roller
	W10795843	Left Hand		W10795820	Left Hand			
	W10795847	Right Hand		W10795822	Right Hand			
6	W10795851	Assembly, Bottom Pan						

UNIT PARTS




UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw
2	W10820084	Screw
3	W10658357	Baseplate
4	12990511	Screw
5	W10860180	Assembly, Drain Extension
6	W10674646	Assembly, 3 Way Valve
7	W10838081	Pad, Sound
8	W10877573	Tray, Evaporator
9	W10683708	Gasket, Condenser Fan
10	W10697007	Bolt
11	W10697017	Clip, Retaining
12	W10918848	Assembly, Orion Box (Includes Wiring Harness for Compressor and Power Cord)
13	W10774846	Roller
14	12992101	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10836504	Grommet, Compressor
16	W10658301	Condenser
17	W10391376	Bracket, Valve
18	W10767831	Cover, Housing
19	W10141645	Screw
20	W10792503	Filter, EMI
21	W10701009	Cover, Terminal
22	2169104	Insulation, Sound Deadening
23	W10666068	Assembly, Suction Tube
24	W10655759	Harness, Unit (Condenser Fan)
25	W10805035	Drier (Service Drier Without Dye)
26	W11025999	Compressor Assembly
27	W10883082	Assembly, Condenser Fan
28	12477202	Axle, Roller

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
29	W10709318	Coil, 3 Way Valve
30	W10884826	Grommet, Condenser
31	W10735062	Tube, Process
		FOLLOWING PARTS NOT ILLUSTRATED
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
		REFRIGERANT CHARGE
		4.65 oz. (R134A)


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10794563	Base, Pantry	14	W10804533	Glass, Crisper Cover	30	W10794250	Bar, Support
2	W10696184	Ring, Handle	15		Glide, Crisper	31	W10834719	Cover, Wiring Harness
3	W11347069	Assembly, Filter Door		W10816001	Left Hand	32	W10779301	Assembly, Pantry Wire (Includes Thermistor)
4	W10792132	Insulation, Filter Housing		W10814857	Right Hand	33	W10794550	Assembly, Center Support
5	2223877	Latch, Push	16	W10903881	Handle	34	W10794547	Frame, Crisper Cover
6	W10793467	Assembly, 15" Full Shelf	17	W10918349	Assembly, Crisper Pan	35	W10794336	Gasket, Crisper Cover (Rear)
7	W11116719	Assembly, 12" Full Shelf	18	W10901221	Assembly, Light	36	W10794242	Gasket, Crisper Cover (Front)
8	W11367768	Assembly, Tuck Shelf	19	W10903879	Screw	37	W10835866	Jumper, Crisper LED
9		Assembly, Block	20	W10826105	Assembly, Produce Preserver	38	W10854845	Cover, Wiring Harness
	W10817922	Front Left/Back Right	21	W11444736	Pan, Under Shelf	39		Support, Side
	W10817921	Front Right/Back Left	22	W10794571	Glass, Platter		W10794553	Left Hand
10	W10898655	Pan, Pantry	23	W10840918	Flange, Side Support		W10794555	Right Hand
11	W11367790	Assembly, Platter Shelf	24	W10840920	Knob, Side Support	40	W10834285	Screw (Grey)
12		Glide, Platter	25	W10795580	Assembly, Herb Storage (Includes Lid and Gasket)			
	W10843722	Left Hand	26	W10847999	Screw			
	W10814862	Right Hand	27	W10804977	Screw			
13	W10663641	Spacer, Handle	28	W10794565	Support, Pantry			
			29	W10794557	Cover, Pantry			





DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	7		Tray, Drip	15	W10696713	Gasket, User Interface Adapter
2	W10919039	Assembly, User Interface	8	W10792138	Black	16	W10696704	Assembly, Ice Door Motor Bracket
3		Wall, Dispenser False		W10792136	Chrome	17	W10663699	Pad, Sound
	W10792135	Black	9		Paddle, Ice Dispenser	18	W10752689	Heater, Dispenser
4		Paddle, Water Dispenser	10	W10403752	Switch, Limit	19	W10757499	Bracket, User Interface Adapter
	W10889223	Chrome	11	W10672578	Spring, Torsion	20	W10809296	Guide, Light
5		Seperator	12	W10663682	Spring, Torsion			
	W10889235	Black	13	W10704135	Assembly, Paddle Jumper Wire			
6	W10837350	Grate, Drip	14	W10888235	Gasket			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10793257	Plate, Ice Chute
3	W10291905	Gasket
4	W10903434	Assembly, Ice Container

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W11363574	Shaft-Motor
6	W11185741	Motor, Dispenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	W10888882	Assembly, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key