




REFRIGERATOR

MODELS:

KBSD708MSS00 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	20	2221242	Spring, Door Closure (Green)	39	W10847848	Switch, Rocker (Refrigerator)
	W11504344	Owner's Manual	21	3400230	Screw		W10847852	Switch, Rocker (Freezer)
	W11549877	Energy Guide	22	2005008	Ring, Bushing Retaining	40	8281163	Screw (Stainless)
	W11494194	Tech Sheet	23	2215612	Cover, Air Duct	41	W10005050	Screw
2		Cabinet (Not Serviced)	24		Bracket, Switch	42	W10271541	Connector, Union
3	2318189	Tray, Filter Drip		W11610480	Left Hand	43	W10663352	Clip
4	W10138054	Assembly, Roller		W11610479	Right Hand	44		Bracket, Support
5		Assembly, Support Base	25		Hinge, Bottom		2006616	Left Hand
	W10279275	Left Hand		2006779	Left Hand		2006556	Right Hand
	W10138423	Right Hand		2006780	Right Hand	45	W10141604	Screw
6		Cap, Water Filter	26	2302876	Bushing, Adjustable	46	2005032	Leveler, Adjustable
	W10797527	Black	27	W11370632	Screw	47	2005433	Spacer
7	2307640	Bracket, Grill Mounting	28	W10188551	Skirt, Bottom Grille	48	2006841	Ring, Retainer
8	W11421923	Harness, Water Valve	29		Assembly, Light Switch Cam	49	304392	Screw
9	W10121140	Housing, Water Filter		W10121046	Left Hand	50	W11439643	Shield, Water Valve
10	2307584	Grommet, Crossover Tube		2307857	Right Hand	51	W11449524	Tube, Water
11	3400525	Screw	30		Grille, Bottom	52	W10357286	Fitting, Water
12	W10121146	Filter, Water		W10182718	Black	53	W11450887	Tube, Water Filter
13	8281164	Screw (Stainless)	31	2221070	Clamp, Tube	54	W10578757	Valve, Isolation (No Flow Washer)
14		Arm, Door Closer Extension	32	487415	Screw	55	W10237915	Bracket, Water Valve
	W11229516	Left Hand	33	486194	Screw	56	W10279866	Assembly, Dual Valve
	W10728112	Right Hand	34	2006617	Bracket, Base Support (Rear)	57	W11447812	Waterline
15	2257644	Hinge, Top	35	W11533762	Cover, Switch	58	W10782424	Locking Ring (5/16)
16	W10674648	Bracket, Filter	36	2320559	Support, Valve		W10782423	Locking Ring (1/4")
17	W10001250	Screw	37	W10780213	Assembly, Switch Wire			
18	2004994	Lock, Bushing	38		Button, Water Filter			
19	W10484913	Bushing, Top Hinge		2260503B	Black			


CABINET TRIM PARTS



CABINET TRIM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side	2	W10121451	Insert, Blind Threaded
		Left Hand	3	486194	Screw
	W10568007	Aluminum	4		Trim, Top Cabinet
		Right Hand		2314018	Aluminum
	W10568005	Aluminum			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not Serviced)	8	W11480888	Cover, Air Diffuser	16	W11550866	Assembly, Thermistor
2	W10315189	Filter, Air	9	2302937	Thermistor	17	2220377	Baffle, Air
3	W11447198	Assembly, Air Diffuser Cover	10	W10141518	Screw	18	W11449562	Assembly, Air Diffuser
4	487539	Screw (Stainless)	11	W10609678	Cover, Thermistor	19	W11229041	Assembly, LED Module
5	W11481390	Ladder, Shelf	12	W11463083	Reservoir, Water	20	W11480891	Gasket, Air Baffle
6	520965	Support, Ladder	13	2188820	Thermistor			
7	W10808291	Screw	14	W11443086	Guard, Air Return			
			15	W10782835	Diverter, Crisper Cover			


FREEZER LINER AND AIR FLOW PARTS



FREEZER LINER AND AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11437867	Assembly, Evaporator Fan	9	487539	Screw (Stainless)	21		Liner (Not Serviced)
2	2198665	Tube, Circuit Board	10	W11229041	Assembly, LED Module	22	W10808291	Screw
3	W11544700	Fan, Evaporator	11	W11553041	Board, Receiver Circuit	23	W11481390	Ladder, Shelf
4	3400916	Washer	12	W10609678	Cover, Thermistor	24	W11597100	Flipper, Shut Off
5	W11467833	Gasket, Evaporator Cover	13	489214	Screw	25	W11444470	Cover, Evaporator
6		Rail, Evaporator Cover	14	W11603662	Cover, Receiver	26	520965	Support, Ladder
	W11467831	Left Hand	15	2188820	Thermistor	27	2198634	Pin, Door
	W11467830	Right Hand	16	W10308487	Screw (Black)	28	2198635	Spring, Door
7	486194	Screw	17	W11410845	Duct, Air	29	W11603482	Slide, Icemaker Shut Off
8		Wedge, Air Duct	18	2198643	Lens, Receiver	30	W10191952	Screw
	W11447235	Left Hand	19	W11550866	Assembly, Thermistor	31	W11445126	Assembly, Shelf Stud
	W11447234	Right Hand	20	W11603485	Cover, Emitter	32	W11553040	Board, Emitter Circuit


ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2222970	Bin, Ice	8	W11443152	Clip, Shaft	14	W10254073	Washer
2	W11567291	Bin, Lower Crusher	9	2198628	Seal	15	W11574172	Assembly, Ice Container
3	W10749207	Button, Bin	10	2318030	Shaft, Drive	16	2315559	Sleeve, Bearing
4	W10134785	Latch, Bin	11	W11608470	Enclosure, Dispenser Motor	17	W11592419	Switch, Auger Motor
5	2198608	Spring, Latch	12	W11185741	Motor, Dispenser	18	487539	Screw (Stainless)
6	2198671	Screw (Stainless)	13	W11608469	Cover, Dispenser Motor	19	W11458114	Assembly, Complete Ice maker
7	8281163	Screw (Stainless)						


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11410511	Assembly, Shelf	9	W11611417	Assembly, Platter Shelf	15		Slide, Meat Pan
2	W11448661	Assembly, Crisper Pan					2302954	Left Hand
3	W11441725	Assembly, Meat Pan Cover	10	W11522384	Pan, Cake		2302955	Right Hand
			11	W11522386	Sheet, Baking	16	8533928	Screw
4	W11441727	Assembly, Crisper Cover	12		Spacer, Crisper			(Left Hand)
				W11410122	Left Hand		8533929	Screw
5	W11448428	Assembly, Meat Pan		W11410123	Right Hand			(Right Hand)
6	W11482031	Pan, Cool Control Crisper	13		Spacer, Meat Pan			
				W11410124	Left Hand			
7	W11408073	Assembly, Bakeware Shelf		W11410125	Right Hand			
			14		Slide, Crisper			
8	2307810	Duct, Deli Pan		2302956	Left Hand			
				2302957	Right Hand			


FREEZER SHELF PARTS



FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11602367	Shelf, Wire	5		Slide, Basket	7	W11567119	Cover, Icemaker
2	W11603230	Shelf, Fixed		2259318	Left Hand	8	W10749631	Bracket, Icemaker Cover
3	W11602366	Basket, Freezer		2259317	Right Hand			
4	W11410135	Front, Freezer Basket	6	8533928	Screw			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11576687	Door, Refrigerator	9		Gasket, Door	15	W10761897	Spacer, Door Skin (Top)
2	2006346	Washer, Extension Arm		W10760886	Grey			
			10		Skin, Door	16	W10756209	Spacer, Hinge Side Door
3	W11414335	Assembly, Hinge (Top)		W10859717	Stainless			
4	2316804	Spacer, Door Hinge Bottom			Filler (Not Serviced-Included With Skin)	17	W10761937	Spacer, Door Skin (Bottom)
5	W10162602	Screw	11		Handle, Door	18	W10482554	Cover, Bottom Gap
6	2302878	Assembly, Hinge (Bottom)		W10541592	Stainless	19	W10127710	Plate, Handle Door
7	W11610618	Assembly, Top Door Bin	12	W10758113	Spacer, Handle Side Door	20	W11408930	Bin, Gallon Door
8	308544	Screw	13	488568	Screw (Stainless)	21	W11408938	Bin, Shallow Door
			14	8281250	Screw (Stainless)			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11502201	Door, Freezer	9	W10758113	Spacer, Handle Side Door	15	W10756209	Spacer, Hinge Side Door
2	W10127710	Plate, Handle Door						
3	2302879	Assembly, Hinge (Bottom)	10		Skin, Door	16	308544	Screw
4	W10162602	Screw		W11441140	Stainless	17	W10482554	Cover, Bottom Gap
5	W11414335	Assembly, Hinge (Top)			Filler (Not Serviced-Included With Skin)	18	W11408940	Bin, Shallow Door
6	2316804	Spacer, Door Hinge Bottom	11	8281250	Screw (Stainless)	19	2006346	Washer, Extension Arm
7		Gasket, Door	12	W10758121	Spacer, Door Skin (Top)			
	W10760884	Grey	13	488568	Screw (Stainless)			
8		Handle, Door	14	W10758123	Spacer, Door Skin Bottom			
	W10541592	Stainless						


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	9	2305235	Assembly, Spigot	15	W11426690	Assembly, User Interface
2	8281163	Screw (Stainless)	10	W11425798	Assembly, Separator	16	W11428836	Wire, User Interface Jumper
3	W10542660	Bracket, Motor	11		Housing, Middle (Not Available Order Item 12)	17	W11408077	Assembly, Drip Tray
4	W10546285	Assembly, Motor and Bracket	12	W11429556	Assembly, Pad Housing			
5	W10205979	Motor, Ice Door	13	W11408129	Assembly, Water Paddle			
6	W10504458	Door, Ice	14	W11408128	Assembly, Ice Paddle			
7	W10542663	Support, Ice Door						
8	4449745	Screw						

TOP GRILLE AND UNIT COVER PARTS




TOP GRILLE AND UNIT COVER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille
	W10645406	Stainless
2	W10545068	Cover, Unit
3	W10784922	Screw (Black)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	2256466	Panel, Unit Back
5	W11435372	Cover, Unit Front
6		Nameplate
	W10518672	Badge

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10645086	Divider, Unit Air
8	2215910	Grommet, Flexible
9	W11244166	Insulation, Unit Back Panel


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11411269	Assembly, Inverter Box	13	2256328	Bracket, Inverter Mounting	22	W11435371	Bracket, Control Assembly
2	489473	Screw	14	W11435369	Housing, Control Board	23	W11464545	Assembly, Condenser Fan
3	W11332037	Compressor (Also Order the Following Lokring Parts)	15	1157158	Screw	24	W11443119	Bracket, Condenser Bottom
	W11504415	8.5/8 NR MS 00 (Suction Tube to Compressor)	16	W11408149	Condenser (Also Order the Following Lokring Parts)	25	W11242280	Clamp, Power Cord
	W11504431	7/5 NR MS 00 (High Pressure Side to Compressor)		W11504445	5/4 NR MS 00 (High Side to Condenser)	26	487294	Screw
	W11504416	8.5/6 NR MS 00 (Process Tube to Compressor)		W11504445	5/4 NR MS 00 (Suction Line to Condenser)	27	W11460409	Tube, Heat Loop Transition
4	W10550831	Housing, Control Board Mounting	17	W11421662	Harness, Unit Wire	28	W11311927	Switch, Power Disconnect
5	W10587113	Grommet	18	W11482040	Sensor, Relative Humidity	29	2310195	Assembly, Jumper Wire (Power Switch to Power Cord)
6	2183042	Grommet	19	W10068580	Screw	30	W11411473	Tube, Drier Transition
7		Support, Condenser	20	2155774	Tie, Wire	31	W11482820	Tube, Process
	W11443116	Left Hand	21	W10805035	Drier (Service Drier Without Dye) (Also Order the Following Lokring Parts)	32	486194	Screw
	W11443117	Right Hand				33	W11443120	Cover, Condenser Support
8	W11235263	Assembly, Compressor Cover		W11504445	5/4 NR MS 00 (Heat Loop to Drier)	34	2310196	Cord, Power REFRIGERANT CHARGE 79 grams (R600a)
9	9741232	Screw		W11504432	6/5 NR MS 00 (Capillary Tube to Drier)			
10	2319835	Grommet, Condenser						
11	W11619405	Control, Electronic						
12	487415	Screw						

LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11463140	Bracket, Evaporator Right Top	11	W11439436	Assembly, Evaporator and Heater	14	W10413009	Grommet, Air Return
2	W11530767	Tube, Transition (Drier/Restrictor)			(Also Order the Following Lokring Parts)	15	W10303521	Sleeve
3	486194	Screw				16	W11475798	Gasket, Evaporator Bypass
4	2221070	Clamp, Tube		W11504450	4/1.8 NR MS 00	17	2155774	Tie, Wire
5	W11444578	Tube, Oil Trap Suction			(Capillary Tube to Evaporator)	18	W10169509	Clip, Heat Exchanger
6	W11491712	Assembly, Drain Pan		W11506620	8 NK AL 00	19	2320554	Support, Drain Pan
7	W10309012	Cover, Wiring			(Suction Line to Evaporator)	20	2215648	Dampener
8	W10321048	Cover, Wire Box				21	304392	Screw
9	W11444570	Tube, Discharge	12	W11267072	Heater, Defrost	22	2169104	Insulation, Sound Deadening
10	W10321050	Shelf, Wiring Cover	13	W11549269	Thermistor, Evaporator			