


KitchenAid®

Dishwasher

MODELS:

KDITF204PPS3 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>RM#</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>RM#</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>RM#</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	300068	Screw (Black)	12		Handle
	WH1668938	Owners Manual	8	WH1625188	Panel, 2" Adjustable (Black)		WH1617401	Stainless
	WH1643481	Energy Guide	9	WH1664663	Insulation, Inner Door	13	WH1643662	Support, Door (Left)
	WH1663620	Test Sheet					WH1643666	Support, Door (Right)
2		Arm, Hinge	10	WH1643031	Screw	20	WH1616673	Nutplate
	WH1607618	Left Hand	11	WH1641635	Screw	21	WH1616672	Screw
	WH1607636	Right Hand	12	WH1625188	Panel, 4" Adjustable (Black)	22	WH1611263	Screw
3	WH1126166	Cross Brace, Door	13	WH1643063	Screw	23	WH1643663	Stud, Mounting
4	WH1654088	Nut, Bolt	14	WH1606170	Insulation, Door	24	WH1667113	Self Screw
5	WH1625187	Panel, Mesh Access (Black)	15	WH1609338	Insulation, Long Tube			
6		Front Panel (includes 4 10, 18, 20, 21, 22 & 23)	16	WH1643663	Gasket, Door			
	WH1643470	Stainless	17	WH1641124	Insulation, Room Panel			


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1		Console Assembly (Includes Inter)	2	W112541880	Screw	5	W110291894	Latch Assembly (Includes Switch)
	W11343937	Black	4	W113381283	Screw	5	W111715719	Inner Door Assembly (Includes Soap Dispenser)
2	W11353240	Wiring Harness, Inner Door						


TUB AND FRAME PARTS



TUB AND FRAME PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1		Tub-Rail Service	19	WH1333000	Side Panel (Left)	38	WH1371000	Power Cord Assembly
2	WH1317000	Rear Tub Support		WH1333000	Side Panel (Right)	39	WH1413700	Filter, RP
3	WH1333000	Gasket, Tub	20	WH1333400	Screw	40	WH1343000	Jumpers Harness, Service Port
4	WH1333000	Nut, Air Break	21	WH1333000	Assembly, Base	41	WH1333400	Control, Electronic
5	WH1314775	Slide, Latch	22	WH1334000	Shield, Tub Sound	42	WH1333000	Wiring Harness, Main
6	WH1313200	Assembly, Leveling Leg (Rear)	23	WH1343000	Assembly, Junction Box	43	WH1334700	Channel, Overflow (Left)
7	WH1334000	Relaxer, Tub Gasket	24	WH1333000	Miscellaneous Parts Bag		WH1334700	Channel, Overflow (Right)
8	WH1325471	End, Foot Adjustment (Rear)	25	WH1325000	System, Side Panel	44	WH1333000	Feet, Crossbar
9	WH1333000	Holder, Dimple	26	WH1333000	Screw	45	WH1333775	Kit, Side Cover Installation
10	WH1317000	Cover, Door Opening	27	WH1341000	Screw	46	WH1333000	Insulation, Back
11	WH1333700	Assembly, Door Opening	28	WH1343000	Tub Mount, Upper Rack	47	WH1333000	Crossbar, Upper Back
12	WH1313300	Cover, Tub Corner (Left)	29	WH1333000	Button, Top	48	WH1313400	Tub Mount, Third Level Rack (Left)
	WH1313300	Cover, Tub Corner (Right)	30	WH1327000	Nut, Bottom		WH1313400	Tub Mount, Third Level Rack (Right)
13	WH1333000	Foot, Switch	31	WH1327000	Cap, Set	49	WH1333000	Nut, Tub
14	WH1321000	Plug, Tub	32	WH1343000	Buffered, Water	50	WH1333000	Strip, Anti-Condensation
15	WH1333000	Air Break	33	WH1324000	Base, Bottom	51	WH1333000	Insulation, Floor
16	WH1325100	Leg, Leveling (Front)	34	WH1333000	Panel, Set			
17	WH1317000	Cover, Tub	35	WH1333000	Panel, In/Out Hoses			
18	WH1333000	Crossbar, Front Frame	36	WH1343000	Jumpers, RP to Control			
			37	WH1343000	Spring, Bouncing			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1	WY1530727	Header Pump	9	WY0096331	Clamp, Hose	17	WY022517	Clap. Hose
2	WY1530728	Motor Pump	10	WY1531551	Motor, Dish	18	WY1315223	Clamp, Hose
3	WY1530852	Burns (Includes Seal)	11	WY1530593	Hose, Dish	19	WY1442113	Grease
4	WY1530923	Clap. Vent Assembly	12	WY1173636	Disc, Chiller	20	WY1543524	Clap. Valve Motor
5	WY1530937	Diffuser, Int'l	13	WY0343327	Housing, Connector	21	WY1555845	Filter
6	WY1530938	Check Valve, Clap.	14	WY1122351	Clamp, Hose			
7	WY1530955	Wash Arm Assembly	15	WY1551555	Hose, Int'l			
8	WY1530952	Hose, Pump-out	16	WY1125174	Indicator, Optical Wash			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	WH-E00352	Feed Tube Assembly	2	WH-E22201	Sprayer, Third Level	2	WH-E22465	Cover, Greaser
2	WH-E22115	Retainer, Docking (2nd Level)	4	WH-E00150	Upper Sprayer assembly	2	WH-E22104	Retainer, Docking (2nd Level)


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11534558	Canister, Volute	7	W11532802	Cup, Cup Shelf	13	W11534812	Tire Rod, Back (Left)
2	W11312114	Track Stop, Front	8	W11532888	Cup Shelf		W11534817	Tire Rod, Back (Right)
2	W11312116	Track Stop, Rear	9	W11532842	Tire Rod, Fold Down	14	W11532247	Handle, Front
4	W13084548	Track, Discrete	10	W11313801	Cup, Tire Rod	15	W11532235	Handle, Rear
5	W11551903	Adjustment Assembly (Left)	11	W11317336	Screw			
	W11551902	Adjustment Assembly (Right)	12	W11533482	Tire Rod, Front (Left)			
5	W11358048	Support, Tire Rod		W11533481	Tire Rod, Front (Right)			

LOWER RACK PARTS




LOWER RACK PARTS

<u>Qty</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W1152547	Control, Lower
2	W1154555	Wheel & Transport Assembly
3	W1152577	Engineer's Seat Assembly
4	W1154537	Upright Backrest (Rear)
5	W1154538	Upright Backrest (Front)

<u>Qty</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W11550235	Handle, Rear
7	W11550247	Handle, Front
8	W117237335	Seat
9	W11545710	Siding Tire, Side
10	W11523445	Cup, Siding Tire

<u>Qty</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W11355035	Tire, Fodder (Rear)
	W11355035	Tire, Fodder (Front)
12	W11545635	Cup, Foddering
13	W11545635	Cup, Ratchet

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Qty</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11543109	Rack, Third Level	4	W11527309	Screw	2	W11519716	Track Stop, Rear
2	W11543302	Shelving Tray	2	W11590233	Handle, Rear	10	W11594049	Track, Cabinet
2	W11525717	Mount, Cabinet Left	2	W11590249	Handle, Front			
	W11525718	Mount, Cabinet Right	7	W11522690	Washer Assembly			
			2	W11525714	Track Stop, Front			