




GAS RANGE
Fingerprint Resistant

MODELS:

MGR6600FZ6 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	13		Bezel
	W11427471	Quick Start Guide		W11418086	Black		W11042485	Stainless
	W11450808	Owners Manual	5		Panel, Manifold	14	W11367086	Spreader, Flame
	W11508882	Wiring Diagram		W10861559	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
2		Burner Cap Kit	6		Knob, Control		W11457167	Harness, Main
	W11498499	Black (Set of 4)		W11510310	Stainless		W11450461	Harness, Bake and Broil
3	W11352018	Spreader, Flame (Left Front and Right Front)	7		Grate Kit			
				W10911970	Black		W10334923	Clip, Gas Wiring
	W11352020	Spreader, Flame (Right Rear)	8	W10673618	Screw		313438	Clip, Harness
			9	3196557	Screw		3196520	Clip, Wire
	W11352021	Spreader, Flame (Left Rear)	10	W11379945	Bracket, Anti-Tip		3196896	Clip, Wire
			11	7101P485-60	Screw, Anti-Tip Kit			
			12	W11368533	Burner Kit			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10920631	Module, Spark DSI	11	3196169	Screw
	W11130372	Black (Left)	6	W10516123	Bracket, Console Mounting	12		Control, Electronic (LCX)
	W11130379	Black (Right)					W11520695	Black
2	8053505	Shield, Heat	7	8523412	Bracket, Rear Cooktop	13	3196178	Screw
3		Panel, Control	8	W10198745	Cover, Upper	14	W10695491	Bracket, Control
	W10835288	Stainless	9	W10192841	Shield, Heat	15	W10475149	Module, Spark
4	W10762981	Bracket, Mounting	10	W10184370	Cover, Back	16	W10797001	Bracket, Ignitor


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	9	W10224921	Bracket, Aegis	24	W11428858	Electrode
2	W10949105	Bracket, Saddle Valve	10	3196385	Screw			(Left Front, Right
3	W11459257	Orifice Holder Assembly (15K)	11	3400016	Screw			Front, Right Rear and
		(Left Front)	12	8054078	Burner, Broiler			Center)
	W11459258	Orifice Holder Assembly (9.5K)	13	W10184491	Spreader, Flame (Oven)	W11428831		Electrode
		(Left Rear)	14	9758078	Burner, Bake			(Left Rear)
	W11459260	Orifice Holder Assembly (15K)	15	W11370883	Regulator			FOLLOWING PARTS
		(Right Front)	16	W10333842	Electrode, Broil	W11489399		NOT ILLUSTRATED
	W11459259	Orifice Holder Assembly (5K)	17	W10420040	Tube, Broiler Supply			LP 5 Orifice
		(Right Rear)	18	W11435700	Fitting, Broiler			Conversion Kit
	W11459261	Orifice Holder Assembly (8K)	19	W11485872	Orifice (15K)	W10566537		LP Bake and Broil Kit
		(Center)		W11485873	Orifice (9.5K)	W10400495		Orifice, LP Bake
4	W10215439	Tubing (Manifold to Regulator)		W11485871	Orifice (5K)	W10465080		Orifice, LP Broil
5	W11537754	Harness, Igniter (Includes Switches)		W11485874	Orifice (8K)	W10182767		Tie, Manifold Wire
6	W11450459	Electrode, Bake			(Center)			
7	W11510000	Manifold Assembly	20	W10137062	Spreader, Flame (Broiler)			
8	W11509685	Valve, Gas (Left Front and Right Front)	21	3196265	Screw			
	W11509686	Valve, Gas (Left Rear and Center)	22	W10362924	Screw			
	W11509687	Valve, Gas (Right Rear)	23	W10827923	Electrode, Spring			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	16	W10390008	Base Rail Assembly (Left)	28	W11544377	Light Assembly
2	8272747	Shield, Flue				29	W10571723	Bulb, Halogen 40 Watts
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	30	9761013	Front Door Latch Assembly
4		Panel, Side	17	9757239	Rod, Door Switch	31	W10078370	Rod, Push Latch
	W10162245	Black	18	W10031780	Screw	32	W10107820	Rear Door Latch Assembly
5	W10137382	Clip, Panel	19	W10379120	Screw	33	W10674705	Glide, Drawer Front
6	8523249	Bracket, Manifold	20	3400080	Screw	34	3196178	Screw
7	W10362924	Screw	21	W11491751	Seal, Door	35	W11173792	Rack, Oven
8	3196560	Screw	22	W10435470	Brace, Main Back			FOLLOWING PARTS NOT ILLUSTRATED
9	W10341186	Front Foot Assembly	23	W11379353	Retainer, Insulation (Left)		8524099	Insulation, Wrap
10	W10058460	Foot, Leveling		W11379943	Retainer, Insulation (Right)		W10180437	Insulation, Back
11	3195097	Bottom, Oven	24	3196560	Screw			
12	W10586204	Sensor	25	W10624590	Cord, Power			
13	8053967	Baffle, Burner Oven	26	W10289077	Receiver, Hinge			
14	8053969	Shield, Heat	27	W11511828	Switch, Door			
15	8053968	Shield, Lower						


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10031780	Screw	8	9758162	Glass, Inner	14	W11379944	Strap, Door
2	9761344	Liner, Door	9		Handle, Oven Door	15		Trim, Door
3	W10278991	Insulation, Door Strip		W10834521	Stainless		W10746436	Black (Left)
4	W10200660	Screw	10	9761357	Retainer, Insulation	16	W10316950	Frame, Glass
5	W10299224	Hinge, Active (With Spring)	11	W10480830	Screw	17		Trim, Door
6	W10612925	Badge	12		Glass Assembly, Outer Door		W10746435	Black (Right)
7		Trim, Oven Door Vent		W11167878	Stainless	18	W10299227	Hinge, Door (Passive)
	W11047800	Stainless	13	W10031790	Screw			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11190210	Panel, Drawer Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	3196165	Screw
3	W10688022	Drawer, Storage

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10674708	Glide, Drawer Rear
5	W10462909	Bracket, Mounting

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting