




ELECTRIC RANGE
(Stainless)

MODELS:

WEE745H0LZ4 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	W10547960	Bracket, Console (Left)	28	W10664705	Bumper
	W11509603	Owners Manual		W10547961	Bracket, Console (Right)	29	W10759327	Assembly, Display
	W11524749	Quick Start Guide				30	7201P077-60	Gasket, Infinite Switch
	W11523161	Tech Sheet	16		Console	31		Console, Lower Panel
2	W11600012	Spring, Element		W11527532	Stainless		W10570527	Black
3	3196178	Screw	17	W10437097	Switch, Infinite (Left Front)	32		Vent, Trim Top
4		Cooktop		W10437092	Switch, Infinite (Right Front)		W10636528	Black
	W10865119	Black		W10578768	Switch, Infinite (Right Rear)	33	W10598048	Bracket, Console (Center)
5	W11318371	Element (3000W) (Left Front)		W10437094	Switch, Infinite (Left Rear)	34	W10612719	Gasket, Console and Cooktop
6	W10342780	Element (1300W) (Left Rear)				35	W10689101	Gasket, Console
7	W10799048	Element, Warm Zone (Center Rear)	18	3196068	Lens, Indicator			FOLLOWING PARTS NOT ILLUSTRATED
8	W11282542	Element (3000W Dual) (Right Front)	19		Knob		W11454497	Harness, Main
				W10850027	Stainless		W11134658	Harness, Cooktop
9	W10248261	Element (1200W) (Right Rear)	20	W10689102	Gasket, Console Short		W10575120	Harness, Keypad
10	W11175271	Bracket, Radiant	21	W11527165	Control, Electronic (Maxwell)		W11172426	Harness, Display
11	W10536275	Pan, Radiant	22	W10702912	Gasket, Switch Stem		W11172417	Harness, Console
12	W10162253	Brace, Corner (Left)	23		Overlay, Active		W10664316	Clip, Harness (Cooktop)
	W10162252	Brace, Corner (Right)		W11527906	Black		313438	Clip, Harness
13	W10289170	Support, Cooktop (Left)	24	3196068	Lens, Indicator			
	W10289169	Support, Cooktop (Right)	25	W10558372	Bracket, Control			
14	3196173	Screw	26	7101P485-60	Screw, Anti-Tip Kit			
			27	W11379947	Bracket, Anti-Tip			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	21	W10245259	Block, Terminal	41	W10162255	Duct, Cover
2	W10362924	Screw	22	W11034869	Screw	42	W10162254	Duct, Cooling
3		Panel, Side	23	3196178	Screw	43	W11467246	Cooling Fan
	W10162245	Black	24	W11634772	Light Assembly	44	W11117035	Shield, Wire
4	3400029	Nut	25	W10571723	Bulb, Halogen 40 Watts	45	W10162241	Channel, Rear
5	W11491752	Gasket, Door	26	W10914589	Counterweight	46	W10162248	Cover, Wire
6	W10544952	Element, Broil	27	W10586204	Sensor	47	W11379354	Cover, Back
7	W10774342	Element, Bake	28	3196169	Screw	48	W10531060	Rack, Oven
8	W10362924	Screw	29	W10655441	Shield, Power Cord	49	W11661815	Basket, Airfry
9	W11122085	Assembly, Flue	30	W10031780	Screw	50	W11510561	Barrier Rail, Rubber (Front Left)
10	W10289168	Box, Burner SI	31	W10273192	Rod, Door Switch		W11510562	Barrier Rail, Rubber (Front Right)
11	W10341186	Front Foot Assembly	32	9758701	Spacer, Door	51	W11620269	Bracket, Front Frame
12	W10067840	Screw	33	W10774446	Bottom, Oven			FOLLOWING PARTS NOT ILLUSTRATED
13	W10541959	Shield, Bake	34	W11511828	Switch, Door			
14	W10137382	Clip, Panel	35	W10281322	Kit, Bare Wire Adapter Block			
15	W10390008	Base Rail Assembly (Left)	36	W10289145	Rack, Oven (Gull-Wing)		W10289173	Insulation, Wrap
	W10390007	Base Rail Assembly (Right)	37	W11353926	Convection Assembly		W10575374	Insulation, Bottom
16	W10058460	Foot, Leveling	38	W10346154	Cover, Convection		4820F015-59	Insulation, Strap
17	3196548	Fuse, Thermal	39	W10273002	Bracket, Oven Support		W10162240	Insulation, Back
18	3196172	Screw	40	W11379357	Bake Pan		7111P017-60	Clamp, Wire
19	W10035900	Support, Oven Bottom						
20	3186034	Bracket, Service						

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Vent
	W11519842	Stainless
2		Assembly, Door Handle
	W10918786	Stainless
3		Badge
	W10884775	Badge
4	W10297318	Liner, Door
5	W10031790	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10300487	Glass, Inner
7	W10440013	Hinge, Door (Active)
8	W10772958	Insulation, Door
9		Standoff, Handle
	W10917796	Black
10	3196560	Screw
11	W10294851	Rail, Door
12	W10031780	Screw
13	W10477496	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14		Assembly, Outer Door
	W10871829	Black
15	W10294853	Bracket, Glass Liner
16		Trim, Door
	W10334004	Black
17		Trim, Bottom Door
	W10334031	Black
18	W11440160	Door, Bottom Cover

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Drawer	5	W10441804	Slide, Drawer (Left)	6	3196560	Screw
	W10918786	Stainless		W10441805	Slide, Drawer (Right)	7	W10498399	Screw
2	W10688022	Drawer, Storage						
3	W10318026	Bracket, Mounting						
4		Panel, Drawer Front						
	W11449702	Stainless						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72032	Black
	72017	White
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	285006	Black
	350930	White
	4392901	Biscuit and Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS AND POLISHES
	31605	Kit, Cooktop Care
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10432539	Griddle
	W10432545	Kit, Grill
		TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless