




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

WRF532SMHW04 (White)

WRF532SMHB04 (Black)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11468670	Use and Care Guide
	W11308948	Energy Guide
	W11534593	Tech Sheet
2		Cabinet (Not a Servicable Part)
3		Cover, Top Hinge
		Left Hand
		(Includes Foil)
	W10337634	White
	W10337647	Black
4		Cover, Top Hinge
		Right Hand
	12962302W	White
	12962302B	Black
5		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
6	W10141622	Brake, Roller
7		Hinge, Top
	12963204ED	Left Hand
	12963205ED	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Shim, Top Hinge
	12999501	Left Hand
	12999502	Right Hand
9	12992602	Screw
10	688983	Screw
11	W10673840	Screw (Stainless)
12	12698403	Plate, Pivot
13	W10485986	Guide, Waterline
14	12992403	Screw
15		Hinge, Center
		Left Hand
	W10740148	White
	W10740149	Black
16		Hinge, Center
		Right Hand
	W10740144	White
	W10740145	Black
17		Cover, Corner
	12587703W	White
	12587703B	Black
18	W10709365	Screw
19	W10210979	Cover, Unit

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20		Grille, Toe
	W10534161	White
	W10534162	Black
21	W10208592	Cover, Valve
22	M0108107	Clamp, Tube
23	W10141645	Screw
24	12990504	Screw
25	W11046934	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)
26	W11446817	Valve, Inlet
27	12726003	Cover, Water Line
28	W11534847	Gasket


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	W10443023	Housing, Light	16	12791406SP	Thermistor
2	W10464766	Module, Light	9	W11468934	Light Module, LED			FOLLOWING PARTS NOT ILLUSTRATED
3	W11357424	Overlay, Control	10	W10847852	Switch, Rocker			
4	W11319776	Module, Control	11	12806801	Insert, Damper Cover	W11455469		Harness, Light (Includes Thermistor)
5	W11321360	Control, Electronic	12	12990604	Screw			
6	W11311953	Switch, Energy Saver	13	12806701	Cover, Damper			
7	W11132917	Cover, Light	14	13012402	Insulation, Damper			
			15	W10594330	Damper, Control			


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10277025	Module, Light	25		Bracket, Door
2	A3189392	Gasket, Foam	15	13058002	Clip, Evaporator Motor		W10330991	Left Hand
3	W11341630	Guide, Fill Tube	16	W10847849	Switch, Light		W10330993	Right Hand
4	12002497	Gear	17	12791409SP	Thermistor	26	12990521	Screw
5	13062901	Motor, Evaporator	18	W10662407	Assembly, Drain Funnel	27		Rail, Side
6	W10157765	Diverter, Air	19	M0500703	Seal		W11309374	Left Hand
7	W10802331	Shaft, Rack	20	A3189395	Gasket, Foam		W11309377	Right Hand
8	12815301	Cover, Thermistor	21	B8381501	Gasket, Drain	28	W10120018	Slide, Door
9	W11468934	Light Module, LED	22	13024803	Grille, Freezer Air	29		Adapter, Slide
10	W10171529N	Pan, Ice	23	13057901	Shroud, Evaporator Fan		W10284684	Left Hand
11	W10308415	Cover, Evaporator					W10284685	Right Hand
12	12990511	Screw	24	2169142	Blade, Fan	30	12990501	Screw
13	W10150583	Grommet, Fan Motor				31	W11456887	Assembly, Icemaker (Complete)


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	8		Gasket, Door	14	12918704	Bucket, Gallon (Clear)
		Left Hand			Left Hand	15	W10289497	Bucket, Gallon
	13107886W	White		W10830287	White	16	W10371194	Bucket, Medium
	13107886B	Black		W10830289	Black	17		Closure, Door
2		Door, Refrigerator	9		Handle, Door		12028505W	White
		Right Hand		W11101973	White		12028505B	Black
	13107885W	White		W11101974	Black	18		Latch, Door Closer
	13107885B	Black	10		Stop, Door			Right Hand
3	W11328753	Screw		12968202W	White		W10833738	White
4	12990504	Screw		12968202B	Black		W10725267	Black
5	W10351081	Bucket, Small	11	W10884773	Badge	19		Gasket, Door
6		Mullion, Door	12		Latch, Door Closer			Right Hand
	12722803W	White			Left Hand		W10830189	White
	12722803BN	Black		W10833740	White		W10830206	Black
7	12990204	Screw		W10725268	Black	20	12990518	Screw
			13	12996601	Clip, Bushing			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	2		Handle, Door	3		Gasket, Door
	12977869W	White		W11101982	White		W10443315	White
	12977869B	Black		W11101983	Black		W10436250	Black
						4	W11328753	Screw


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	21	W10815863	Clip, Condenser	28	W11332031	Compressor
2	12825803	Blade, Fan	22	W11337414	Evaporator			(Also Order the Following Lokring Parts)
3	W10480110	Basepan			(Also Order the Following Lokring Parts)			
4	12990511	Screw		W11504423	8/2 NR AL 00		W11504416	8.5/6 NR MS 00
5	W10350564	Capacitor			(Capillary Tube to Evaporator)			(Suction Tube to Compressor)
6	W11376383	Tube, Discharge		W11504415	8.5/8 NR MS 00		W11504431	7/5 NR MS 00
7	W11305541	Harness, Evaporator (Includes Defrost Thermostat)			(Suction Line to Evaporator)			(Discharge Tube to Compressor)
8	W10655367	Pan, Drain					W11506621	6 NK MS 00
9	W10622701	Screw	23	2169104	Insulation, Sound Deadening			(Charging Tube to Compressor)
10	W11287564	Heater, Defrost	24	W11373924	Motor, Condenser Fan		W11506635	Tube, Charging (1/4" w/ Schrader Valve)
11	W11379613	Strap, Bale	25	W11380964	Clip, Heater	29	10623002	Clip, Evaporator
12	W11359985	Device, Start	26	W11525276	Harness, Unit (Includes Power Cord)	30	12477202	Axle, Roller
13	W10137529	Grommet, Condenser	27	W11353156	Drier	31	W11463236	Shroud, Condenser Fan
14	W10236396	Strap, Compressor			(Also Order the Following Lokring Parts)	32	2319835	Grommet, Condenser
15	12477102	Roller		W11504445	5/4 NR MS 00	33	W10622099	Extension, Drain Tube
16	12992101	Screw			(Heat Loop to Drier)	34	W11244122	Gasket, Foam
17	10835903	Grommet		W11504447	5/1.8 NR MS 00			REFRIGERANT CHARGE
18	W11353138	Condenser			(Capillary Tube to Drier)			44 grams (R600a)
		(Also Order the Following Lokring Parts)						
	W11506623	5 NK MS 00						
		(Discharge Tube to Condenser)						
	W11504432	6/5 NR MS 00						
		(Heat Loop to Condenser)						
19	W10281329	Clip, Drier						
20	W11337772	Tray, Drip						

SHELF PARTS



SHELF PARTS

Illus.
No.

Part No.

Description

1	12204820	Glass, Pantry
2	13048601SP	Divider, Pantry Drawer
3	13048801	Trim, Pantry Glass
4	W10528936	Support, Glass
5	12802302SP	Front, Crisper
6	12531901	Track, Deli Drawer
7	W10311695	Divider, Basket (Upper)
8	W10241046	Divider, Basket (Upper)
9	12656902	Gasket, Pantry
10	13048301	Housing, Control
11	W10743546	Assembly, Shelf
12	13048401	Slide, Temperature
13	12990512	Screw
14	W10235370	Glide, Pantry
15	12990513	Screw

Illus.
No.

Part No.

Description

16		Endcap, Pantry
	W11186157	Left Hand
	W11185285	Right Hand
17	12530505SP	Pan, Crisper
18	12227303WD	Brace, Crisper Cover
19	W10231343	Trim, Crisper
20	W10671241	Frame, Crisper
21	12204822	Glass, Crisper
22	W10273463	Ladder, Center
23	W10251969	Ladder, Side
24	W10149389N	Lift, Bail Arm
25	W10215666	Screw
26	12990504	Screw
27	12530805SP	Slide, Humidity Control
28	13048201	Bar, Control
29	W11427807	Drawer, Pantry
30	12655204	Knob, Temperature Control

Illus.
No.

Part No.

Description

31	12656823	Lid, Pantry
32	W11028627	Bin, Lower
33	W10783763	Brace, Crisper Frame
34	W11115252	Basket, Freezer (Upper)
35		Gear, Spur
	W10474716	Left Hand
	W10474715	Right Hand
36	W10671238	Rail, Center Crisper
37	W10802339	Shaft, Rack
38		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
39	12531802	Hook, Ladder
40		Support, Crisper
	12531001	Left Hand
	12531002	Right Hand

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key