




30" FREESTANDING ELECTRIC RANGE

MODELS:

MER4600LS2 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10275048	Element (3000/1400W)	10	7101P485-60	Screw, Anti-Tip Kit
	W11459498	Owners Manual			(Left Front)	11	W10691223	Pan, Radiant Element
	W11523147	Quick Start Guide	6	W10248261	Element (1200W) (Left Rear and Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W11390998	Tech Sheet	7	W10248262	Element (2500W) (Right Front)		W11452624	Harness, Main
2	W10225448	Spring, Element	8	W10799048	Element, Warm Zone (Center)		W11134603	Harness, Cooktop (Left)
3	W10607641	Bracket, Cooktop (Left)					W11134551	Harness, Cooktop (Right)
	W10607642	Bracket, Cooktop (Right)	9	W11379945	Bracket, Anti-Tip		W11134592	Harness, Warm Zone
4		Cooktop						
	W11022824	Black						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	3196178	Screw	12	3196169	Screw
	W11130372	Black (Left)	6		Control, Electronic (LCX)	13	3196165	Screw
	W11130379	Black (Right)		W11527164	Black			
2	W10695491	Bracket, Control	7		Knob			
3		Panel, Console		W10858250	Stainless			
	W10885607	Stainless	8	W10134247	Shield, Heat			
4	W10434452	Switch, Infinite (Dual)	9	3400882	Screw			
		(Left Front)	10	8272473	Cover, Upper Rear			
	3148951	Switch, Infinite	11	W10525121	Bracket, Console Mounting			
		(Left Rear and Right Rear)						
	3148954	Switch, Infinite (Orange)						
		(Right Front)						


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	15	W10390008	Base Rail Assembly (Left)	27	W10181986	Sensor, Oven
2	3196154	Screw				28	3196169	Screw
3		Panel, Side		W10390007	Base Rail Assembly (Right)	29	W10326122	Cover, Terminal Block
	W10162245	Black				30	W10031780	Screw
4	3400029	Nut	16	W10058460	Foot, Leveling	31	W11173792	Rack, Oven
5	W10129032	Seal, Door	17	3196548	Fuse, Thermal	32	W10910404	Counterweight
6	9757340	Element, Broil	18	3196172	Screw	33	3196560	Screw
7	W11111743	Element, Bake	19	W10404688	Clip, Oven Support	34	W11510560	Barrier Rail, Rubber (Left & Right)
8	W11034869	Screw	20	3186034	Bracket, Service	35	W11464547	Bracket, Front Frame
9	W10134285	Tube, Vent	21	W10245259	Block, Terminal			
10	W10674705	Glide, Drawer Front	22	W10281322	Kit, Bare Wire Adapter Block			FOLLOWING PARTS NOT ILLUSTRATED
11	W10341186	Front Foot Assembly	23	3196178	Screw		8273263	Insulation, Wrap
12	W10067840	Screw	24	W11544377	Light Assembly		8272611	Insulation, Back
13	8054068	Retainer, Insulation	25	W10571723	Bulb, Halogen 40 Watts		W10333344	Insulation, Flue
14	W10137382	Clip, Panel	26	3400016	Screw			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Vent
	W11047800	Stainless
2	W10480830	Screw
3		Handle, Door
	W10834521	Stainless
4	9761344	Liner, Door
5	W10031790	Screw
6	W11367326	Glass, Inner

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	9761505	Retainer, Insulation
8	W10299225	Hinge, Active
9		Glass Assembly, Outer Door
	W11167878	Stainless
10		Trim, Side
	W10746436	Black (Left)
	W10746435	Black (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10327235	Screw
12	W10299227	Hinge, Door (Passive)
13	W10031780	Screw
14	W11379944	Strap, Door
15	W10200660	Screw
16	W10612925	Badge
17	W11440159	Trim, Bottom Door

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	2	W10688022	Drawer, Storage	4	W10674708	Glide, Drawer Rear
	W10330070	Stainless	3	W10462910	Bracket, Mounting Drawer	5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting