




Dishwasher

MODELS:

KDTM404KPS3 (Stainless)

KDTM404KBS3 (Black Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Rev.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Rev.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Rev.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Front Panel (includes A, F & H)	13		Toe Panel
	WH1323334	Owners Manual		WH1233333	Stainless	14	WH1354553	Screw
	WH1333311	Energy Guide		WH1233334	Black Stainless	15	3400000	Screw
	WH1356140	Tech Sheet	7	WH1516573	Nameplate	16	WH1345553	Stud Mounting
2		Arm, Hinge	8	WH0913553	Insulation, Multi-Layer	17	WH1316573	Screw
	WH1523332	Left Hand	9	WH1033554	Insulation, Single Layer	18		Handle Assembly
	WH1523370	Right Hand	10	WH1315553	Insulation, Front Panel		WH1417431	Stainless
3	WH1377165	Cross Brace, Door	11	WH062757	Barrel Nut, Front Panel	19	WH0637133	Set Screw
4	WH1103520	Light Pipe	12	WH1435573	Screws, Back			
5		Access Panel						
	WH1103575	Black						


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1		Console Assembly (Includes Insert)	8	3450071	Screw	13	W11553527	Seal, Console/Cool
	W11496608	Block	9	W11343403	Screw	14	W11553533	Hanger, Control
2	W11553419	Screw	10	W11553532	Inner Door Assembly	15	W11527547	Vent Assembly
3	W11356843	Juniper, Door	11	W11553521	Seal, Door Bottom	16	W11351509	Fuse, In-line
4	W10711284	Screw	12	W11543435	Wiring Harness, Main (Includes Thermostat & Fuse)	17	W13343408	Screw
5	W11551534	Latch Assembly (Includes Switch)	13	W11530826	Wiring Harness, Inner Door			
6	W11543290	Control, Electronic	14	W11552549	Dispenser Assembly			
7	W11525534	Seal, Vent						


TUB AND FRAME PARTS



TUB AND FRAME PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W11122458	Tub Assembly (includes gasket)	13	W11036176	Float Switch	24	W11062500	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
2	W11225744	Base, Terminal Box	14	W11184382	Plug, Tub	25		Tub Mount, Third Level Rack
3	W11035386	Gasket, Tub	15	W11425970	Water Inlet Assembly		W1101573	Left Hand
4	W11425974	NUL Water Inlet	16	W11455388	Leg, Leveling		W11255415	Right Hand
5	W11050487	Strike, Latch	17	3373125	Washer, Flanged Cup	26	W11036142	Heater Element Assembly
6	W11258374	Screw	18	3400014	Screw, Grounding	27	W11055333	Tub Mount, Upper Rack
7	W11165091	Seal, Cabinet	19	W10277003	Screw	28	3400032	Screw
8	W11025382	Drip Tray	20	W11225745	Cover, Terminal Box	29	W10920244	Mit. Tub
9	W11025383	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025388	Funnel Extension		W11050522	Left Hand			
11	3265145	Bracket, Undercounter		W10520120	Right Hand			
12	W11165063	Cover, Tub Corner	32	W11221821	Shield, Top Sound			
			33	W11132441	Terminal Block			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W11122133	Pump Assembly	13	W10900337	Hose, Bottom	24	W11122351	Camp. Hose
2	W11254332	Isolator, Front Motor	14	W110335723	Motor, Drain	25	W110335151	Hose
3	W10331545	Diffuser, Inlet	15	W11121134	Hose, Drain	26	W110335143	Clp. Hose
4	W11254335	Hanger, Front Motor	16	W10333433	Disc, Diverter	27	W13455555	Camp. Hose
5	5T41232	Screw	17	W11025553	Bracket, Rear Motor	28	W110335237	Hose, Inlet
6	W10331547	Check Valve, Drain	18	W11413271	Fastener	29	W11235575	Camp. Hose
7	W11043455	Wash Arm Assembly	19	W11125174	Indicator, Optical/Wash	30	W11033554	Grate
8	W11103555	Filter Assembly	20	370445	Camp. Hose	31	371305	Camp. Hose
9	W10330333	Reg. Valve	21	W11153475	Bracket, Thermostat	32		Diverter Valve Motor (Not Serviced)
10	W11345225	Motor & Pump Assembly	22	W11153055	Thermostat (Included with Main Wiring Harness)	33	W11034555	Burns (Includes Seal and O-Rings)
11	W11035553	Isolator, Rear Motor	23	W11033570	Fill Valve Assembly	34	W10753575	Capacitor
12	W11250335	Hose, Pressure				35	W10457002	Screw


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10374330	Feed Tube Assembly	4	W11174340	Upper Sprayer Assembly	6	W10852638	Retainer, Docking (2nd Level)
2	W11036638	Retainer	5	W10303455	Cover, Diverter	7	W10852639	Retainer, Docking (3rd Level)
3	W11036652	Sprayer, Third Level						


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W12347875	Distrack, Upper	7	W11441105	Track, Distrack	13	W11254812	Track Stop, Rear
2	W11312237	Clip, Stemware	8	W11265682	Handle, Distrack Front	14	W11049221	Wheel
3	W11100172	Leveler, Adjuster Arm	9	W11265687	Handle, Distrack Rear	17	W11376295	Screw
4	W11180603	Clip, Adjuster Arm	10	3741233	Screw			
5	W11357533	Button, Adjuster Arm	11	W11186522	Time Res. Fold Down			
6		Adjustment Assembly	12	W11173752	Clip, Foot			
	W11263090	Left Hand	13	W11173753	Posthole			
	W11263095	Right Hand	14	W11054574	Track Stop, Front			


LOWER RACK PARTS



LOWER RACK PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W1252546	Distrack, Lower	5	W1255622	Tine Rod, Flex Down	7	3741232	Screw
2	W11133747	Wheel & Transport Assembly	6	W11265658	Retainer, Flex Rod	8	W11352625	Handle, Distrack Front
3	W11251758	Structure Saddle Assembly	7	W11265657	Handle, Distrack Rear			
4	W11257175	Lid, Silverline Saddle						

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11127727	Rack, Third Level	7	9741232	Screw	15	W11034874	Track Stop, Front
2	W11441105	Track, Dishrock	8	W11200101	Cap Guard	16	W11034872	Track Stop, Rear
3	W11134071	Hanger, Tube	9	W11057523	Seawater Tray	17	W11040221	Wheel
4		Track Mount	10	W12330577	Bracket, Flange Hanger			
	W11231345	Left Hand	11	W12330523	Drive End Assembly			
	W11231348	Right Hand			Manifold			
5	W11382620	Handle, Dishrock	12	W11121885	Cover, Wash Tube			
		Front	13	W12331334	Tube, Wash			
6	W11233631	Handle, Dishrock Rear	14	W11278385	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
	4355277	Sensor Kit
	W11381554	External Drain Hose, 12 FT.
	W1135511	Power Cord Kit (Straight)
	W1135514	Power Cord Kit (Right Angle)
	4355573	Steam Relief, Power Cord (Metallic)
	W1355155	Compression Hose Fitting, (Water Line)
	W10275535RE	Fill Hose Kit