



ELECTRIC WALL OVEN


MODELS:

KOSE500EWH21 (White)

KOSE500ESS21 (Stainless)

KOSE500EBS21 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W10728475	Gasket, Rubber	16	W11223325	Cover, 30 IN Chassis Top Back
	W11340821	Owner's Manual	8	7101P426-60	Screw			
	W11382210	Quick Start Guide	9	7101P434-60	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W11382212	Tech Sheet	10	W10655463	Bracket, Blower (Left)			
2		Assembly, Control Panel (Includes Overlay)		W10655462	Bracket, Blower (Right)		W11245665	Harness, Main
	W11304102	White	11	4451758	Block, Foam		W11256622	Harness, Signal
	W11304093	Stainless	12		Skin, Control Panel		W11264646	Harness, Door Latch
	W11304098	Black Stainless		W10588746	White		W10562910	Harness, EOL
3	W11249218	Appliance Manager, Copernicus		W10588740	Stainless		4450800	Screw, Grounding
				W10776407	Black Stainless		W10487999	Clip, Harness
4	W11339492	Screw (Black)	13	W11179509	Tray, Electronic		W11132988	Strap, Lead Ground
5	W11397930	Blower	14	W11166802	Divider, Chassis Back		4448664	Clamp, Conduit
6	W11162063	Gasket, Rubber	15	W11244445	Cover, 30 IN Chassis Top Front		W10655464	Bracket, Harness
							W11547720	Bag, Hardware

OVEN PARTS



OVEN PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11165250	Duct, Chassis Back
2	W11085298	Tube, Vent
3	W11100732	Receiver, Hinge
4	W11558603	Spacer, Base
5	W11132456	Latch, Motorized
6	W11168071	Top, Chassis
7	W11205574	Assembly, Oven Light
8	W11245118	Foot, Base
9	W10904163	Deflector, Blower
10	W10254050	Screw
11	W11608108	Gasket
12	W11256424	Cover, Vent Exhaust
13	W11165274	Side, Chassis
14	W11223327	Back, Chassis
15		Liner, Oven (Not Serviceable)


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W11346074	Probe, Sensor
17	W11166315	Bumper and Screw
18	4449751	Thermostat (TOD)
19	W11135103	Base, Chassis
20		Assembly, Bottom Vent
	W11369885	White
	W11369882	Stainless
	W11369884	Black
21	W11244446	Duct, Bottom Chassis
22		Trim, Bottom Vent
	W11356753	Black
23	W11135135	Support, Air Channel
24	W11390667	Spacer, Chassis Bottom Duct
25	W11334857	Vent, Top 30 IN

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
26	8285593	Cover, Connector
27	7101P426-60	Screw
28	W10472386	Lens, Light
29		Cover, Side Trim
	W11235463	Black (Left)
	W11235462	Black (Right)
30	W11404000	Screw
31	W10472384	Bulb, Light
32	W11256423	Base, Vent Exhaust
33	W11249635	Screw
34	W11167419	Cover, Suction (Left)
	W11186675	Cover, Suction (Right)
35	W11533682	Cover, WIFI
		FOLLOWING PARTS NOT ILLUSTRATED
	W11188284	Insulation, Wrap
	W11234758	Insulation, Cavity


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302587	Liner Assembly	8	W11296036	Hinge, Door (Left)	12	W10319024	Washer, Door
2	7101P375-60	Screw		W11296037	Hinge, Door (Right)	13	W10518672	Badge
3	W11290045	Screw	9	3196183	Screw	14		Handle Assembly
4	W10618107	Glass, Inner	10	W11317731	Screw (Black)		W11241572	Stainless
5	W11302730	Spacer, Air Divider	11		Door Assembly	15	W10551026	Medallion, Handle
6	W11174095	Retainer, Air Divider Glass		W11264076	White	16	W10656499	Screw
7	7101P426-60	Screw		W11295957	Stainless			
				W11295959	Black Stainless			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	10	W11433702	Nut, Acorn (LH)	18	W10554531	Rack, Sliding
2	W10554526	Rack, Oven	11	W10546519	Element, Convection	19	9755542	Probe, Temperature
3	W10318198	Tray, Hidden Bake	12	W10819989	Baffle, Bow Tie	20	W10720084	Screw
4	7101P434-60	Screw		W10918895	Baffle, Bow Tie	21	W11398057	Cover, Convect Plate
5	7101P426-60	Screw			(For Black Stainless Models)	22	W11251715	Plate, Convect Motor
6	W10282957	Crossbar, Hidden Bake Tray	13	W11235537	Reflector, Broil	23	W11251716	Insulation, Convect Motor
7	W11292248	Element, Bake	14	W10588737	Shield, Broil Front			
8	W11398058	Convect Motor Assembly	15	W11252826	Jack, Meat Probe			
9	W11425715	Blade, Fan	16	W11033111	Nut, Locking			
			17	W10906658	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	285006	Black
	350938	Gray Primer
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
	4396923	Broiler Pan and Grid
W10123240		Rack, Broiler Pan and Roasting
	4378577	Stone, Brick Pizza
	8009	Light Bulb
		Built-In Oven Side Trim Kit
W10536160		Black Medallion, Handle
W10846205		Chrome
W10846206		Black
W10846207		Red
		Trim, Tall Vent
W11570323		Stainless
W11570325		Black