




ELECTRIC DRYER

MODELS:

YMED5030MW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W10414381	Switch, Rotary Encoder (2 Position)	20	W10414397	Switch, Rotary Encoder (3 Position)
	W11555817	Owners Manual	10	688983	Screw	21	9740848	Screw
	W11495041	Tech Sheet	11	3348629	Screw	22	343641	Screw
	W11466172	Quick Start Guide	12		Top	23	W10726632	Seal, Console
2	W11438904	Connector, Service Standalone		W10613389	White	24	W11486550	Harness, Upper Encoder RS
3	W11625654	Appliance Control Unit (ACU)	13	W10298336	Nut, "U"	25	W11437795	Harness, Upper Encoder
4	W10775189	Panel, Rear	14	W11328381	Knob, Large			
5	W11437792	Harness, Main	15	W11398762	Knob, Small			
6	8312709	Clip, Console	16		Assembly, Console			
7	3390663	Screw		W11576588	White			
8		Lint Screen	17	688805	Clip, Spring			
	W11538108	White	18	W10612925	Badge			
			19	W10662472	Collar, Lint Chute			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10529198	Cover, Door Catch	18		Cabinet	31	694415	Clip, Strain Relief
2	3390631	Screw		8530603	White	32	3404162	Clamp, Motor (With Shield)
3	693995	Screw	19		Panel, Front			
4	W10841728	Seal, Spill Guard		W10664697	White	33	W10121316	Clamp, Motor Mount
5	W11219688	Cover, Terminal Block	20	W11224633	Strike, Door	34	W10396029	Assembly, Motor
6	W10567345	Plug, Strike	21	W10803476	Assembly, Seal and Bearing	35	8066184	Pulley, Motor
7	W11598681	Panel, Rear	22	W11224630	Assembly, Door Catch	36	691366	Idler Assembly
8	8066092	Lock, Front Top	23	342055	Screw	37	W10131364	Belt, Drive
9	98234	Clip, Ground	24		Assembly, Hinge and Pin	38	348780	Base, Motor
10	W10569603	Switch, Door				39	3400500	Bolt
11	697773	Screw		W10362431	White	40	W10641296	Hinge, Top
12		Plug, Front Panel	25	W10730752	Seal, Door	41	W10316529	Seal, Foam
	W11308618	White	26	W10463967	Door, Inner	42	W10641295	Bracket, Rear
13	685203	Clip, Felt Pad	27		Door, Front	43	W10316619	Seal, Spill Guard
14	W10712173	Cord, Power		W10714510	White	44	9740848	Screw
15	W10775448	Clip, Front Panel	28		Handle, Door	45	W10653662	Pad, Foam
16	W10779369	Foot, Dryer		W10714516	White	46	W10529197	Bezel, Door Catch
17	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)	29	279393	Screw Kit, Terminal Block	47	343641	Screw
			30	W10773242	Screw			

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	17	W10724237	Element, Heater	32	692526	Bearing, Ring
2	339956	Seal	18	W10504381	Pad, Foam	33	W10219342	Screw
3	3388703	Washer	19	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	34	W10856781	Seal, Rear Drum
4	347139	Seal, Lint Chute				35	W10757750	Assembly, Drum (Complete)
5	90767	Screw	20	489463	Screw	36	692490	Baffle, Drum (Long)
6	W10389567	Shield, Exhaust	21	3390647	Screw	37	W11032820	Bracket, Support
7	3392519	Fuse, Thermal (91C)	22	3406124	Bulb, Light	38	90296	Nut, Push On
8	8577274	Thermistor	23	3402841	Lens, Drum Light	39	3403636	Baffle, Drum (Short)
9	W10900067	Kit, Thermal Cut-Off (Includes Thermostat)	24	W10512946	Washer, Tri Ring	40	W11424720	Pad, Sensor
10	694089	Wheel, Blower	25	W10359270	Shaft, Drum Roller - Left Hand Thread			
11	8577230	Housing, Blower	26	W10359269	Shaft, Drum Roller - Right Hand Thread			
12	3398161	Clip, Heater Box						
13	3390631	Screw	27	3397590	Roller, Support			
14	W11338355	Box, Heater	28	348197	Washer			
15	3977767	Thermostat, 221 F (105 C)	29	W10298789	Nut, Hex			
16	3977373	Bracket, Drum Light	30	W10714469	Bulkhead			
			31	W10214261	Socket, Light			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

279948	Kit, Dryer Repair
346764	Kit, Hold Down
8522199	Kit, Dryer Vent Testing
W10322470A	Dry Rack
W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
W10439655	Hose, Inlet (2')
3976300	Washer, Inlet Hose
W10336486	Connector, Hose -"Y"
W10242307	Washer, Hose

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

80047	Kit, Dryer Repair
3406839	Dry Rack
	Power Cords
PT600L	6', 30 Amp, 4 Wire, Dryer Cord
PT400L	4', 30 Amp, 4 Wire, Dryer Cord
PT220L	4', 30 Amp, 3 Wire, Dryer Cord
W10242307	Washer, Hose
W10336486	Connector, Hose -"Y"
3976300	Washer, Inlet Hose