




1.9 CUBIC FOOT MICROWAVE HOOD (Sensor Convection)

MODELS:

KMHC319EBS05 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2		Cover, Control
	W11401886	Installation Instructions		W10478239	Black
	W10847760	Use and Care Guide	3	W10533504	Duct, Cooling Front
	W10644756	Quick Reference Guide	4	W10540727	Background, Control
	W11482162	Tech Sheet	5	W11359586	PCBA, Appliance Control Unit
			6	W10540721	Seal, Control

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Complete
	W11205125	Black Stainless
2	W11202852	PCBA, User Interface
3	W10770970	Holder, UI
4	W10540298	Plate, UI Insulation
5	W10617743	Cover, UI
6	W10476546	Bracket, Door
7	W10604264	Assembly, Handle
8	W10540736	Cushion, Handle
9		Cover, Screw
	W10478657	Black
10		Bracket, Outer Door
	W10734943	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10891969	Body, Door (With Glass)
12	W10740455	Hooks, Door
13	W10542546	Cover, Screw
14		Frame, Back Decorating
	W10476550	Black
15	W10643448	Stopper, Door
16	W10897612	Frame, Inner
17		Assembly, Door Frame
	W10866701	Black Stainless
18	W10861345	Glass, Door
19	W10770972	Holder, Door Cable

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20	W11320318	Cable, Door User Interface
21	W10518673	Nameplate
22	W10770971	Bracket, Door Cable
23	W10478647	Plate, Steam Protection
24	W10509362	Cable, Touch Sensor


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10908578	Chassis	12	W10533502	Cover, Cooling Fan	25	W10561770	Capacitor, High Voltage
2	W10709921	Lamp, Halogen	13	W10533501	Housing, Cooling Fan	26	W11222648	Diode, High Voltage
3	W10525853	Bracket, Smart Pop	14	W11405831	Capacitor, Motor	27	W10510233	Terminal, PCBA Smart Pop
4	W10535950	Filter, Grease	15	W10536989	Thermistor, PCBA	28	W10259248	Cover, Thermostat
5	W10571126	Plate, Bottom	16	W10510235	Tube, Smart Pop Sound	29	W11268275	Thermostat, Convection
6	W10240330	Assembly, Lamp Glass and Holder	17	W10510234	Terminal, Smart Pop	30	8206223	Clip
7	W10510237	Spacer, Smart Pop	18	W10568805	Resistor, Cement	31	W11381433	PCBA, Smart Pop
8		Switches, Interlock (Not Serviced, Order Interlock Assemblies)	19	W10533486	Valve, Door	32	W10631701	Air Guide, Magnetron
9	W11187757	Assembly, Interlock (Includes Switches)	20	W10533107	Deflector, Air	33	W11169357	Motor, Cooling Fan
10	W10458325	Actuator	21	W10540718	Bracket, Cavity			
11	W10533480	Holder, NTC	22	W10533503	Wheel, Cooling Fan			
			23	W11465624	Transformer, High Voltage			
			24	W10633730	Bracket, Capacitor			


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10631698	Deflector, Air	12	W10210878	Socket, Cavity Lamp	21	W10715053	Shield, Finger
2	8206382	Cover, Lamp	13	W10632409	Baseplate, Air Guide	22	W10531724	Glass, Lamp
3	W10557536	Sensor, Humidity	14	W11293488	Cover, Right Duct	23	W10758887	Assembly, Airguide Grille
4	4393681	Lamp, Cavity 30 Watt	15	W10531156	Board, Filter	24	W10138793	Fuse
5	W11342402	Plate, Air Guide	16	W10810142	Socket, Motor Wire	25	W10591803	Thermostat, Magnetron
6	W11409088	Motor, Fan	17	W10533112	Outlet, Cavity (Back)			
7	W10712444	Housing, Damper	18	W11188557	Magnetron			
8	8206230	Filter, Charcoal	19	W10892383	Duct, Cavity (Front)			
9	W10571180	Seal, Foam	20	W10570209	Duct, Cavity (Front)			
10	W10654514	Thermostat, Cavity						
11	W10557537	Sensor, Convection						


TURNTABLE PARTS



TURNTABLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11361167	Cover, Waveguide	5	W10679313	Ring, Turntable	11	W10568148	Seal, Turntable Block
2	W10740485	Hook, Microwave (Left Front & Right Front)	6	W10337248	Driver, Turntable	12	W10573936	Hook, Microwave (Left Rear & Right Rear)
3	W10857799	Steamer	7	W10466420	Motor, Turntable			
4	W11358813	Turntable	8	W10637931	Rack, Microwave			
			9	8184109	Seal, Waterproof			
			10	W10440082	Rack, Convection			

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11025649	Plate, Mounting
2	W10748710	Damper
3	W10654511	Cord, Power
4		Case, Outer
	W11446919	Black
5		Grille, Vent
	W10701701	Black
6	W10571554	Assembly, Convection Motor and Fan
7	W10740434	Duct, Cooling (Upper)
8	W10533489	Duct, Cooling (Bottom)
9	W10570212	Air Duct, Turntable Motor
10	W11122643	Assembly, Mounting Nut
11		Holder, Vent Left Side
	W10703285	Black
12		Holder, Vent Right Side
	W10703283	Black
		FOLLOWING PARTS NOT ILLUSTRATED
	W10571450	Insulation, Back
	W10571451	Insulation, Top
	W10892377	Insulation, Bottom
	W10571453	Insulation, Side
		MISCELLANEOUS PARTS
	W10821385	Hardware, Installation
	W10190020	Template, Upper (English & Spanish)
	W10190018	Template, Upper (English & French)
	8169704	1/4-20x3" Panhead Screw
	W11298361	Harness, Main
	W11244782	Harness, Lamp Holder
	W10539840	Harness, PCBA Ground Wire
	W10508746	Harness, Smart Pop
	W10508741	Wire, Door Control Cable