




GAS RANGE
Finger Print Resistant

MODELS:

WFG975H0HZ6 (Stainless)

WFG975H0HV6 (Black Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Knob	16	W10879790	Grate Hinge Spacer
	W11427473	Quick Start Guide		W10917221	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
	W11448510	Use and Care Guide		W10917222	Black Stainless			
	W11565453	Tech Sheet	8		Grate Kit		W11458870	Harness, Main
	W11097305	Internet Connectivity Guide		W10865170	Black		W10753750	Harness, Bake and Broil
2		Burner Cap Kit	9		Hinge, Grate (Not Serviced)		3196896	Clip, Wire
	W11498499	Black (Set of 4) (Left Front, Left Rear, Right Front, Right Rear)	10	W11379946	Manifold Panel Bracket		3196520	Clip, Wire
3	W10067840	Screw	11	W11379358	Rear Gas Cooktop Bracket		W10334923	Clip, Gas Wiring
4	W11367107	Burner Kit	12	W11379945	Bracket, Anti-Tip		313438	Clip, Harness
5		Cooktop	13	7101P485-60	Screw, Anti-Tip Kit		7111P017-60	Clamp, Wire
	W11418087	Black	14	W11043399	Griddle			
6		Panel, Manifold	15		Bezel			
	W11025417	Stainless		W10917236	Stainless			
	W10874048	Black Stainless		W10917224	Black Stainless			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10198745	Cover, Upper	13	W10797001	Bracket, Ignitor
	W11213290	Black (Left)	6	W10192841	Shield, Heat	14		Bracket, Control (Includes Overlay)
	W11213292	Black (Right)	7	W11541197	Control, Electronic (Maxwell)		W10856354	Black
2	W10516123	Bracket, Console Mounting	8	W10762981	Bracket, Mounting	15		Bracket, Eye Brow
3		Console	9	W10184251	Cover, Back		W11443964	Black
	W10869991	Stainless	10	3196178	Screw	16	3196169	Screw
	W10881625	Black Stainless	11	W11516201	Antenna	17	W10551614	Spreader, Clip-Spring
4	W10920631	Module, Spark DSI	12	W11350452	Spark Module	18	W10888670	Assembly, WiFi


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	18	W10323077	Diffuser, Flame	33	W10874067	Motor, Fan (Convection)
2	9758701	Spacer, Door	19	3196178	Screw	34	W10346154	Cover, Convection
3	W10273002	Bracket, Oven Support	20	W10531060	Rack, Oven	35	W10362924	Screw
4		Panel, Side	21	W11491752	Gasket, Door	36	W10289145	Rack, Oven (Gull-Wing)
	W10162245	Black	22	W10031780	Screw	37	W10916847	Wifi Module
5	W10158780	Cover, Rear Fan	23	W10273195	Shield, Heat			FOLLOWING PARTS NOT ILLUSTRATED
6	W11511828	Switch, Door	24	W10273192	Rod, Door Switch			
7	W10137382	Clip, Panel	25	W10910642	Cord, Power			
8	W10919715	Gasket	26	W10035900	Support, Oven Bottom			
9	W10289077	Receiver, Hinge	27	W11379356	Pan, Bake		4820F015-59	Insulation, Strap
10	W10058460	Foot, Leveling	28	W11634772	Light Assembly		W10526208	Insulation, Wrap
11	W10211368	Bottom, Oven	29	W10571723	Bulb, Halogen 40 Watts		W10526209	Insulation, Main Back
12	W10586204	Sensor						
13	3601P356-45	Baffle, Bake Burner	30	W10341186	Front Foot Assembly			
14	3196178	Screw	31	W10390008	Base Rail Assembly (Left)			
15	W10435470	Brace, Main Back		W10390007	Base Rail Assembly (Right)			
16	W11040249	Assembly, Flue (Upper)	32	W10031790	Screw			
17	W10362924	Screw						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front and Right Front)	19	3196385	Screw
2	W11459263	Orifice Holder Assembly (18K) (Left Front)		W11352013	Valve, Gas (Left Rear, Center)	20	3400016	Screw
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)		W11352015	Valve, Gas (Right Rear) (Center)	21	W11428831	Electrode (Left Front, Left Rear, Center)
	W11459260	Orifice Holder Assembly (15K) (Right Front)	9	W10224921	Bracket, Aegis		W11428858	Electrode (Right Front and Right Rear)
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	10	W10439242	Burner, Broiler	22	W10673618	Screw
	W11459261	Orifice Holder Assembly (8K) (Center)	11	W10680035	Burner, Bake	23	W10827923	Electrode, Spring FOLLOWING PARTS NOT ILLUSTRATED
3	W10295996	Bracket, Saddle Valve	12	W10720102	Valve, Gas		W11489399	LP 5 Orifice Conversion Kit
4	W10510125	Tubing, Main Supply	13	W10324262	Igniter, Bake		W10566535	LP Conversion Kit (Bake and Broil)
5	W10783317	Switch, 5 Burner Manifold Harness	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
6	3601P336-45	Baffle, Broil Burner	15	W10776437	Fitting, Broil			
7	W11418925	Manifold Assembly	16	W10333842	Electrode, Broil			
			17	W11485988	Orifice (18K) (Left Front)			
				W11485873	Orifice (9.5K) (Left Rear)			
				W11485872	Orifice (15K) (Right Front)			
				W11485871	Orifice (5K) (Right Rear)			
				W11485874	Orifice (8K) (Center)			
			18	3196178	Screw			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11379948	Glass Spacer	9		Glass Assembly, Outer Door	15	W10884775	Badge
2	W11091878	Screw				16	W10319024	Washer, Door
3		Handle, Door		W10864214	Stainless			
	W10918786	Stainless			Black Stainless			
	W10903342	Black Stainless	10		Vent, Trim			
4	W10826568	Liner, Door		W10887939	Black			
5	W10031790	Screw	11	W10327235	Screw			
6	W11223202	Glass, Inner	12	W10813139	Rail, Vertical Support			
7	W10541911	Bracket, Glass Upper Handle	13	W10031780	Screw			
8	W10885519	Hinge, Door (Active)	14	W10813140	Rail, Horizontal Support			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10688022	Drawer, Storage	6		Handle, Door
	W11449702	Stainless	4	W10441804	Slide, Drawer (Left)		W10918786	Stainless
	W11449756	Black Stainless		W10441805	Slide, Drawer (Right)		W10903342	Black Stainless
2	3196169	Screw	5	W10318026	Bracket, Mounting	7	W10498399	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)