




VERTICAL FREEZER

MODELS:

WSZ57L18DM08 (Monochromatic Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Plug, Hole	15		Grille, Toe
	W11507042	Owner's Manual		W10520307	Grey		W10534165	Grey
	W11648966	Energy Guide	8		Roller Assembly	16	2150304	Roller
	W11510230	Tech Sheet		W10515763	Left Hand	17	2179826	Axle, Rivet
2	3-80675-105	Screw		W10515762	Right Hand	18	W11546560	Screw (Grey)
3	W11293957	Cover, Unit	9	3400113	Screw	19	487576	Washer, Plastic
4		Cover, Hinge	10	W11291514	Tube, Drain			
	2254510	Grey	11	W10709365	Screw			
5	W11638835	Assembly, Top Hinge	12		Cabinet (Not A Serviceable Part)			
6		Plate, Bottom Hinge	13	W10574325	Pin, Lower Hinge			
	W10574262	Grey	14	W10141622	Brake, Roller			


LINER PARTS



LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W11254095	Module, LED	13	W10574368	Gasket, Air Tower (Vertical)
2	W11555883	Assembly, Control	8	W10736055	Basket, Shallow	14	W10574564	Gasket, Air Tower (Horizontal)
3	W10384183	Thermistor	9	1-60123-001	Cover, Ice maker Hole			
4	W10608692	Cover, Thermistor	10	W10569274	Shelf, Deep			
5	W10574272	Air Tower	11	W10569275	Shelf, Shallow			
6	W11514900	Switch, Light	12	W10736043	Basket, Deep			

DOOR PARTS



DOOR PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2314293	Thimble
2	W10371194	Bucket, Medium
	W10351081	Bucket, Small
3	W10628869	Bracket, Door Stop
4		Handle, Door
	W10635689	Stainless
5		Gasket, Door
	W10574476	Grey


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Door Assembly
	W10578905	Stainless
7	W10884775	Badge
8	12557904	Retainer, Door
9	W10460893	Screw
10	12369502	Tray, Dairy
11	W10612074	Lid

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10574673	Door, Pizza Shelf
13	7101P356-60	Screw

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10574307	Cover, Evaporator	14	W11332031	Compressor (Also Order the Following Lokring Parts)	26	W10574278	Pan, Compressor
2	W11490402	Evaporator (Also Order the Following Lokring Parts)				27	2169104	Insulation, Sound Deadening
	W11504450	4/1.8 NR MS 00 (Capillary Tube to Evaporator)		W11504420	8/6 NR MS 00 (Suction Tube to Compressor)	28	W10574469	Shroud, Evaporator Fan
	W11504420	8/6 NR MS 00 (Suction Line to Evaporator)		W11504431	7/5 NR MS 00 (Discharge Tube to Compressor)	29	W11509373	Bracket, Condenser Fan
3	W11340536	Motor, Fan		W11506622	6.35 NK AL 00 (Charging Tube to Compressor)	30	W10909387	Motor, Condenser Fan
4	2169142	Blade, Fan		W11506635	Tube, Charging (1/4 in w/ Schrader Valve)	31	8533961	Screw
5	W11340898	Heater, Defrost				32	W10139483	Blade, Condenser Fan
6	W11483529	Shield, Heat				33	W10574289	Condenser Assembly (Also Order the Following Lokring Parts)
7	W10574291	Pan, Evaporator Drain	15	W11359985	Device, Start		W11578570	7/4.5 NR MS 00 (Discharge Tube to Condenser)
8	W10574305	Gasket, Evaporator Cover	16	W10805035	Drier (Service Drier Without Dye) (Also Order the Following Lokring Parts)		W11506623	5 NK MS 00 (Suction Line to Condenser)
9	1-80257-102	Screw		W11506623	5 NK MS 00 Drier to Condenser	34	W10248621	Clip, Condenser
10	W11526288	Harness, Unit (Includes Power Cord)		W11504448	5/1.8 NR AL 00 (Capillary Tube to Drier)	35	W11584490	Run Capacitor
11	13058002	Clip, Evaporator Motor				36	W11379613	Strap, Bale
12	W11546547	Screw				37	W10697017	Clip, Retaining
13	W10150583	Grommet, Fan Motor				38	W11437914	Clip, Evaporator Thermistor
			17	W10574274	Cover, Evaporator Fan	39	W10384183	Thermistor REFRIGERANT CHARGE 54 grams (R600a)
			18	W11435965	Harness, Evaporator Fan			
			19	W10142294	Screw			
			20	W10815861	Clip, Bottom Cover			
			21	10835903	Grommet			
			22	W10142287	Screw			
			23	W10720825	Screw			
			24	W11452250	Bracket, Evaporator			
			25	W11591093	Tube, Suction			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TOUCH-UP PAINT
	W10134625	Apollo Grey
		MISCELLANEOUS
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
		TORX SCREW WRENCH
	1117510	Torx Key
		FIELD INSTALLABLE ICE MAKER
	W11510803	Complete Icemaker Kit (Includes Valve & Ice Bin)