Whirlpool®

AUTOMATIC WASHER

MODELS:

WTW5015LW0 (White)

© 2022 Whirlpool Corporation
Part No. W11556905 Rev. C

TOP AND CABINET PARTS



TOP AND CABINET PARTS

Illus. No.	Part No.	Description
1		Literature Parts
	W11354658	Owners Manual
	W11430012	Energy Guide
	W11428538	Quick Start Guide
	W11428598	Tech Sheet
2		Top
	W11391547	White
3	W11403468	Bezel, Lid Lock
4	W11414731	Latch, Lid Lock Assembly
5		Bezel, Bleach Dispenser
	W11171193	White
6	W11396263	Bezel, Faucet
7	90016	Clip, Harness
8		Lid
	W11383034	White
9		Strike, Lid Lock
	W11391550	White
10	W10273971	Screw
11	91770	Hinge, Lid (Left)
	W11429864	Hinge, Lid (Right)
12	W10119872	Screw
13	8572266	Bumper, Door
14	W10512626	Channel, Top Rear
15		Channel, Top Front
	W11384398	White
16	W10660565	Screw
17	W10676061	Cover, Harness
18	3400076	Screw
19		Cabinet
	W10676680	White
20	8564458	Absorber, Impact
21	W10834527	Absorber, Impact
22	W11179235	Foot Assembly, Leveling
23	W11417173	Panel, Rear
24	W10763078	Hose, Inner Drain Assembly
25	9740848	Screw
26	W10339879	Tie, Cable
27	W10280024	U-Bend, Drain Hose
28	W11203364	Hose, Outer Drain Assembly
29	356138	Clamp, Hose
30	W11434928	Hinge, Spacer Left
31	W11434930	Hinge, Spacer Right

CONSOLE AND WATER INLET PARTS



CONSOLE AND WATER INLET PARTS

Illus. No.	Part No.	Description
1	W11391560	Console Assembly
2	W10298336	Nut, "U"
3	8312709	Clip, Console
4	W11374900	Encoder Assembly
5	9740848	Screw
6	W11335101	Harness, HMI
7	W11430050	Knob Assembly
8	688805	Clip, Spring
9	W11335102	Power Cord Assembly
10	3400076	Screw
11	W10611544	Panel, Console Rear Cover
12	W10660565	Screw
13	W11428994	Control Unit Assembly, Machine and Motor
14	693995	Screw
15	W11385821	Water Inlet Assembly (Complete)

BASKET AND TUB PARTS



BASKET AND TUB PARTS

Illus. No.	Part No.	Description
1	W10578859	Tub Ring
2	W10777969	Dispenser Assembly
3	W10625252	Screw
4	W11093899	Agitator
5	W11459622	Basket Assembly
6	W11183985	Basket, Lock Nut
7	W11089264	Filter, Drain Pump
8	8533928	Screw
9	W11219115	Tub
10	W11228718	Damper Assembly, Tub Suspension (Set Of 4-Includes Suspension Bushings and Suspension Balls)
11	W11335100	Harness, Lower
12	W10590949	Hose, Pressure Switch
13	W11284522	Clip, Harness

GEARCASE, MOTOR AND PUMP PARTS



GEARCASE, MOTOR AND PUMP PARTS

Illus. No.	Part No.	Description
1	W11164183	Gearcase Assembly
2	W10249633	Screw
3	W10677723	Motor, Drive
4	W10094780	Screw
5	W11398781	Actuator, Shift
6	9741052	Screw
7	W11162560	Capacitor, Motor Run
8	W10142728	Screw
9	W10721967	Splutch Kit (60Hz)
10	W10808317	Belt, Drive
11	W10604214	Nut
12	W10550173	Shield, Pulley Cover
13	357640	Screw
14	W11259498	Pump Assembly, Drain
15	W10004910	Screw
16	8317496	Clamp, Hose
17	W10763078	Hose, Inner Drain Assembly

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

Illus. No.	Part No.	Description
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus. No.	Part No.	Description
	350938	Gray Primer
	350930	White

PAINT, BULK (1 QT.)

Illus. No.	Part No.	Description
	799344	White (Uncut)

WATER SYSTEM PARTS

Illus. No.	Part No.	Description
	285835	Connector Assembly
	285863	4' Drain Hose w/Clamp
	285834	Siphon Break Kit
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter

SEALER

Illus. No.	Part No.	Description
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

COUPLING

Illus. No.	Part No.	Description
	384496	Coupling, Hose Extension Kit

ACCESSORY PARTS

Illus. No.	Part No.	Description
	W10135699	Affresh® Washer Cleaner
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose and One Blue Hose W/ Straight Ends and 4 Rubber Washers)
	8212487	Inlet Hoses, 5 Ft. (Two Braided Hoses W/Straight Ends and 4 Rubber Washers)
	8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft (Two Braided Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)