




30" ELECTRIC SLIDE-IN SELF-CLEAN RANGE

MODELS:

WEE515SALS1 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	7101P485-60	Screw, Anti-Tip Kit	20	W10854253	Bumper
	W11509607	Owners Manual	11	W10225448	Spring, Element	21	W10536275	Pan, Radiant
	W11508915	Quick Start Guide	12	W10162253	Brace, Corner (Left)	22	W11175271	Bracket, Radiant
	W11508781	Tech Sheet		W10162252	Brace, Corner (Right)	23	3196173	Screw
2	W10814305	Bracket, Console (Center)	13	W10814304	Support, Cooktop (Right)	24	W10612719	Gasket, Console and Cooktop
3	9780274	Screw		W10814303	Support, Cooktop (Left)	25	W10689101	Gasket, Console
4		Cooktop				26	W10689102	Gasket, Console Short
	W11523804	Black	14	3196169	Screw	27		Knob
5	8273994	Element (1200W) (Left Rear, Right Rear)	15	W10547960	Bracket, Console (Left)		W10850027	Stainless
6	W11282542	Element (3000W Dual) (Left Front, Right Front)		W10547961	Bracket, Console (Right)			FOLLOWING PARTS NOT ILLUSTRATED
			16		Console	W11453734		Harness, Main
7		Console, Lower Panel		W11512196	Stainless	W10664316		Clip, Harness (Cooktop)
	W10816943	Black	17	W10516115	Screw	W11171886		Harness, Cooktop
8		Vent, Trim Top	18	W11519912	Electronic, Control (LCX)	313438		Clip, Harness
	W10636528	Black				7111P017-60		Clamp, Wire
9	W11379947	Bracket, Anti-Tip	19	3196178	Screw	W11226230		Harness, Console
						3196520		Clip, Wire


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11092984	Screen, Vent	21	W10281322	Kit, Bare Wire Adapter Block	39	W11173792	Rack, Oven
2	W10162248	Cover, Wire				40	W10655441	Shield, Power Cord
3		Panel, Side	22	W10853401	Baffle, Upper Chassis	41	W10848443	Chassis, Upper Insulation
	W10162245	Black	23	W10586204	Sensor	42	W11122085	Assembly, Flue
4	W11491751	Seal, Door	24	W10362924	Screw	43	9758701	Spacer, Door
5	W10583047	Element, Broil	25	3400080	Screw	44	W10814301	Chassis, Support Upper
6	W10535148	Bake, Element	26	3196169	Screw			
7	W10031780	Screw	27	W10289077	Receiver, Hinge	45	W10866583	Clip-Panel, Ratcheting
8	3196178	Screw	28	W10627802	Switch, Door	46	W11379354	Cover, Back
9	3400029	Nut	29	W11370462	Rod, Door Switch	47	W10162241	Channel, Rear
10	W10341186	Front Foot Assembly	30	W11379943	Retainer, Insulation (Right)	48	W11181076	Bracket, Reinforcing
11	W10067840	Screw		W11379353	Retainer, Insulation (Left)	49	W10914589	Counterweight
12	W10312471	Tray, Insulation						FOLLOWING PARTS NOT ILLUSTRATED
13	W10137382	Clip, Panel	31	W11430367	Light Assembly			
14	W10390007	Base Rail Assembly (Right)	32	9761013	Front Door Latch Assembly			
	W10390008	Base Rail Assembly (Left)	33	W10078370	Rod, Push Latch	W10830993		Insulation, Wrap
15	W10058460	Foot, Leveling	34	W10107820	Rear Door Latch Assembly	W10815385		Insulation, Back
16	W10327235	Screw						
17	W10355173	Bracket, Oven Support	35	3196548	Fuse, Thermal			
18	3186034	Bracket, Service	36	3196172	Screw			
19	W10245259	Block, Terminal	37	3196560	Screw			
20	W11034869	Screw	38	W10571723	Bulb, Halogen 40 Watts			

DOOR PARTS



DOOR PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10031790	Screw
2	9761344	Liner, Door
3	W10278991	Insulation, Door Strip
4	W10465158	Screw
5	W10388635	Hinge, Door (Active)
6	W10200660	Screw
7	W10884775	Badge
8	9758162	Glass, Inner
9		Handle, Oven Door
	W11242950	Stainless
10	9761357	Retainer, Insulation
11	3196169	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10440013	Hinge, Door (Active)
13	8004P024-60	Spacer, Side Panel
14	W11379944	Strap, Door
15		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)
16	W10316950	Frame, Glass
17		Glass Assembly, Outer Door
	W11169624	Stainless
	W10884159	Black
18	W10673879	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W11096901	Mounting Bracket, Toe Panel (Left)
	W11096902	Mounting Bracket, Toe Panel (Right)
20	W10327235	Screw
21	W10031780	Screw
22		Panel, Toe
	W11037794	Stainless
23	W11039147	Bracket, Toe Panel

OPTIONAL PARTS

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting