




REFRIGERATOR

MODELS:

KUDR204KPA00 (Overlay)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W11568769	Cover Assembly, Evaporator	12	W11568794	Assembly, Switch Box
	W11533205	Use & Care Guide				13	W11371097	Screw
	W11537003	Energy Guide	7	W11375760	Screw	14	W11239541	Grille
2	W11568787	Connector, Cover	8	W11568776	Cover Piece, Evaporator	15	W11371095	Screw
3	W11359415	Fuse, Temperature				16	W11568948	Assembly, Separator
4	W11568792	Assembly, Trim	9	W11568783	Switch, Case	17	W11312450	Cover, LED
5	W11359416	Defrost Holder and Heater	10	W11568786	Switch, Door	18		Cabinet (Not a Servicable Part)
			11	4344763	Leg, Leveling			


UPPER DRAWER PARTS



UPPER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11568830	Top Foamed Door Assembly	8	W11360665	Gasket, Sash (Top/Bottom)	15	W11568841	Lamp Cover
2	W11568832	Drawer Box Assembly, Upper	9	W11568838	Door Gasket, Short	16	W11576360	Harness
3	W11568835	Mat, Upper Drawer	10	W10204808	Screw	17	W11568842	Support, Lead Wire
4	W11568836	Drawer Partition	11	W11568839	Plate, Door Handle	18	W11422709	Screw
5	W10204920	Nut	12	W11371095	Screw			FOLLOWING PARTS NOT ILLUSTRATED
6	W10204810	Screw	13	W11568936	Control Panel Assembly		W11577200	Complete, Door Assembly
7	W11568837	Gasket, Door	14	W11312450	Cover, LED		W11598387	Overlay Installation Kit


LOWER DRAWER PARTS



LOWER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11568937	Door Assembly, Lower	6	W10204920	Nut	12	W11568796	Plate, Push
2	W11568938	Drawer Box Assembly, Bottom	7	W10204810	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	W11568945	Mat, Lower Drawer	8	W11568947	Gasket			
4	W11568946	Bottom Drawer Partition	9	W11360665	Gasket, Sash (Top/Bottom)	W11576925		Complete, Door Assembly
5	W10204809	Screw	10	W11568838	Door Gasket, Short			
			11	W11422709	Screw			

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11576947	Clamp, Cord	10	W11360536	Assembly, Fan Motor	18	4344780	Bolt, Compressor
2	W11371097	Screw	11	W10805035	Drier (Service Drier Without Dye)	19	4344779	Grommet, Compressor
3	W11360241	Water Pan, Evaporator	12	W11265569	Clamp	20	W11498145	Cord, Power
4	W11375763	Screw	13	W11531824	Compressor			REFRIGERANT CHARGE
5	W11568810	Main PCB	14	W11422771	PTC Thermistor			46 grams (R600A)
6	W11577175	Tag, Power Cord	15	W11568812	Protector, Motor			
7	4344826	Screw	16	W11568820	Cover			
8	W11265570	Washer	17	W11360595	Compressor, Rubber			
9	W11313206	Cover, PCB						