




Dishwasher

MODELS:

KDFM404KPS3 (Stainless)

KDFM404KBS3 (Black Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Rev.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Rev.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Rev.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts:	5		Access Panel	3	W11036634	Insulation, Single Layer
	W11323334	Owners Manual		W11122573	Black	10	W10916633	Insulation, Front Panel
	W11333311	Energy Guide	6		Front Panel	11	W10632767	Barrier Nut, Front Panel
	W11366140	Tech Sheet			(Includes 4, 7, TL, 13 & UL Assembly)	12	W11433578	Screw, Black
2		Arm, Hinge		W11554532	Stainless	13		Top Panel
	W11552392	Left Hand		W11554533	Black Stainless		W11457712	Black
	W11552370	Right Hand	7		Handle	14	W11354553	Screw
3	W11377165	Cross Brace, Door		W11242122	Black	15	3400000	Screw
4	W113452133	Cover, Console	8	W10916633	Insulation, Muth-Layer			

CONTROL PANEL AND INNER DOOR PARTS




CONTROL PANEL AND INNER DOOR PARTS

Item No.	Part No.	Description
1		Console Cap
	W11531421	Black
2	W11263418	Screw
3	W11367355	Jumpet, LF
4	W15711384	Screw
5	W11091934	Latch Assembly (Includes Switch)
6	W11545203	Control, Black/Ink
7	W11026534	Bezel, Vent
8	3400271	Screw

Item No.	Part No.	Description
9	W10348405	Screw
10	W11006822	Inner Door Assembly
11	W11000231	Bezel, Door Bottom
12	W11049433	Wiring Harness, Main (Includes Thermostat & Fuse)
13	W11000225	Wiring Harness, Inner Door
14	W11002549	Dispenser Assembly
15	W11000327	Bezel, Console/Door

Item No.	Part No.	Description
16	W11000005	Hanger, Control
17	W11027347	Vent Assembly
18	W11351505	Fuse, In-line
19	W10348405	Screw


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11122458	Tub Assembly (includes gasket)	13	W11036176	Float Switch	24	W11362501	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
2	W11225744	Base, Terminal Box	14	W11184382	Plug, Tub	25		Tub Mount, Third Level Rack
3	W11036386	Gasket, Tub	15	W11429970	Water Inlet Assembly		W1101573	Left Hand
4	W11429974	NUL Water Inlet	16	W11433388	Leg, Leveling		W11255415	Right Hand
5	W11050487	Strike, Latch	17	3373125	Wasket, Pronged Cup	26	W11336142	Heater Element Assembly
6	W11258374	Screw	18	3400014	Screw, Grounding	27	W11035533	Tub Mount, Upper Rack
7	W11165081	Seal, Cabinet	19	W10277003	Screw	28	3400032	Screw
8	W11025382	Drip Tray	20	W11225745	Cover, Terminal Box	29	W10920244	Mit. Tub
9	W11025383	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025388	Funnel Extension		W11030522	Left Hand			
11	3265145	Bracket, Undercounter		W10920120	Right Hand			
12	W11165063	Cover, Tub Corner	22	W11221821	Shield, Top Sound			
			23	W11132441	Terminal Block			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W11122133	Pump Assembly	13	W10900337	Hose, Bottom	24	W11122351	Camp. Hose
2	W11254332	Isolator, Front Motor	14	W11033573	Motor, Drain	25	W110335151	Hose
3	W10331545	Diffuser, Inlet	15	W11121134	Hose, Drain	26	W110335143	Clp. Hose
4	W11254335	Hanger, Front Motor	16	W10333433	Disc, Diverter	27	W13455555	Camp. Hose
5	5T41232	Screw	17	W11025553	Bracket, Rear Motor	28	W110335237	Hose, Inlet
6	W10331547	Check Valve, Drain	18	W11413271	Fastener	29	W11235575	Camp. Hose
7	W11043455	Wash Arm Assembly	19	W11125174	Indicator, Optical/Flash	30	W11033554	Grate
8	W11103555	Filter Assembly	20	J70445	Camp. Hose	31	301305	Camp. Hose
9	W10330333	Reg. Valve	21	W11153415	Bracket, Thermostat	32		Diverter Valve Motor (Not Serviced)
10	W11345225	Motor & Pump Assembly	22	W11153055	Thermostat (Included with Main Wiring Harness)	33	W11034555	Burns (Includes Seal and Diverter)
11	W11035553	Isolator, Rear Motor	23	W11033570	Fill Valve Assembly	34	W15753575	Capacitor
12	W11250335	Hose, Pressure				35	W10457002	Screw

UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

Item No.	Part No.	Description
-------------	----------	-------------

- | | | |
|---|-----------|----------------------|
| 1 | W10374330 | Feed Tube Assembly |
| 2 | W11033338 | Retainer |
| 3 | W11033352 | Sprayer, Third Level |


Item No.	Part No.	Description
-------------	----------	-------------

- | | | |
|---|-----------|---------------------------|
| 4 | W11174340 | Upper Sprayer
Assembly |
| 5 | W10303455 | Cover, Diverter |

Item No.	Part No.	Description
-------------	----------	-------------

- | | | |
|---|-----------|----------------------------------|
| 6 | W10652638 | Retainer, Docking
(2nd Level) |
| 7 | W10652639 | Retainer, Docking (3rd
Level) |


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

Item No.	Part No.	Description	Item No.	Part No.	Description	Item No.	Part No.	Description
1	W12347875	Distrack, Upper	7	W11441105	Track, Distrack	13	W11254812	Track Stop, Rear
2	W11312237	Clip, Stemware	8	W11265682	Handle, Distrack Front	14	W11049221	Wheel
3	W11100172	Leveler, Adjuster Arm	9	W11265687	Handle, Distrack Rear	17	W11376295	Screw
4	W11180603	Clip, Adjuster Arm	10	3741233	Screw			
5	W11357533	Button, Adjuster Arm	11	W11186522	Time Res. Fold Down			
6		Adjustment Assembly	12	W11173752	Clip, Foot			
	W11268090	Left Hand	13	W11173753	Posthole			
	W11268095	Right Hand	14	W11054874	Track Stop, Front			


LOWER RACK PARTS



LOWER RACK PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W1252546	Distrack, Lower	5	W1255622	Tine Rod, Flex Down	7	3741232	Screw
2	W11133747	Wheel & Transport Assembly	6	W11265658	Retainer, Flex Rod	8	W11352625	Handle, Distrack Front
3	W11251758	Structure Saddle Assembly	7	W11265657	Handle, Distrack Rear			
4	W11257175	Lid, Silverado Saddle						

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11127727	Rack, Third Level	7	9741232	Screw	15	W11034874	Track Stop, Front
2	W11441105	Track, Dishrock	8	W11200101	Cap Guard	16	W11034872	Track Stop, Rear
3	W11134071	Hanger, Tube	9	W11057523	Sevenside Tray	17	W11040221	Wheel
4		Track Mount	10	W12330577	Bracket, Front Hanger			
	W11231345	Left Hand	11	W12330523	Drive Side Assembly			
	W11231348	Right Hand			Manifold			
5	W11382620	Handle, Dishrock	12	W11121885	Cover, Wash Tube			
		Front	13	W12331384	Tube, Wash			
6	W11233631	Handle, Dishrock Rear	14	W11278385	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>
	4355277	Sensor Kit
	WH1381554	External Drain Hose, 12 FT.
	WH135511	Power Cord Kit (Straight)
	WH135514	Power Cord Kit (Right Angle)
	4355573	Steam Relief, Power Cord (Metallic)
	WH555155	Compression Hose Fitting, (Water Line)
	WH0275535RE	Fill Hose Kit