




30" GAS FREESTANDING SELF CLEAN RANGE

MODELS:

AGR6603SFS4 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11450808	Owners Manual
	W11427467	Quick Start Guide
	W11326946	Wiring Diagram
2		Set, Burner Cap
	W11395131	Black (Set of 4)
3	W11352018	Spreader, Flame (Left Front, Right Front)
	W11352020	Spreader, Flame (Left Rear)
	W11352021	Spreader, Flame (Right Rear)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Cooktop
	W11418038	Black
5		Panel, Manifold
	8523855	Black
6		Knob, Control
	W10844796	Stainless
7		Grate Kit
	W10682667	Black (Set of 4)
8	7101P485-60	Screw, Anti-Tip Kit
9	W11379945	Bracket, Anti-Tip
10	8523249	Bracket, Manifold

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10673618	Screw
		FOLLOWING PARTS NOT ILLUSTRATED
	W11453753	Harness, Main
	W11450461	Harness, Bake/Broil
	3196896	Clip, Wire
	3196520	Clip, Wire
	W10334923	Clip, Gas Wiring
	313438	Clip, Harness
	7111P017-60	Clamp, Wire
	3196173	Screw (Grounding)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6	8523412	Bracket, Rear Cooktop	13	W10516463	Bracket, DSI
	W11130372	Black (Left)	7	W10198745	Cover, Upper	14	W10695491	Bracket, Control
	W11130379	Black (Right)	8	W10192841	Shield, Heat	15	8053505	Shield, Heat
2	W10110488	Module, Spark	9	W10184370	Cover, Back	16	W10797001	Bracket, Ignitor
3		Panel, Console	10	3196169	Screw			
	W11157105	Black	11		Control, Electronic (LCX)			
4	W10920631	Module, Spark DSI		W10845611	Black			
5	W10516123	Bracket, Console Mounting	12	3196178	Screw			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front, Right Front)	20	W11485872	Orifice (15K) (Left Front, Right Front)
2	W10295996	Bracket, Saddle Valve		W11352013	Valve, Gas (Left Rear)		W11485873	Orifice (10K) (Left Rear)
3	W11459253	Orifice Holder Assembly (Left Front)		W11352015	Valve, Gas (Right Rear)		W11485871	Orifice (5K) (Right Rear)
	W11459254	Orifice Holder Assembly (Left Rear)	9	W10827923	Spring, Electrode	21	W10137062	Spreader, Flame (Broiler)
	W11459255	Orifice Holder Assembly (Right Front)	10	3196265	Screw	22	W11450459	Electrode, Bake
	W11459256	Orifice Holder Assembly (Right Rear)	11	3196385	Screw	23	W11428831	Electrode (Left Front, Left Rear)
4	W10215439	Tubing (Manifold to Regulator)	12	8054078	Burner, Broiler		W11428858	Electrode (Right Front, Right Rear)
5	W10812380	Harness, Switch	13	W10184491	Spreader, Flame (Oven)			FOLLOWING PARTS NOT ILLUSTRATED
6	W10224921	Bracket, Aegis	14	9758078	Burner, Bake		W10182767	Tie, Manifold Wire
7	W11347743	Manifold Assembly	15	W11370883	Regulator		W10566537	LP Bake and Broil Kit
			16	W10333842	Electrode, Broil		W10400495	Orifice, LP Bake
			17	W10420040	Tube, Broiler Supply		W10465080	Orifice, LP Broil
			18	W11435700	Fitting, Broiler		W11489400	LP Conversion Kit
			19	3400016	Screw			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	14	W10390008	Base Rail Assembly (Left)	23	W10289077	Receiver, Hinge
2	8272747	Shield, Flue				24	W10379120	Screw
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	25	W11430367	Light Assembly
4		Panel, Side	15	W10362924	Screw	26	W10571723	Bulb, Halogen 40 Watts
	W10162245	Black	16	W10031780	Screw	27	3196560	Screw
5	3196178	Screw	17	W10107820	Rear Door Latch Assembly	28	W10674705	Glide, Drawer Front
6	3196169	Screw				29	W10627802	Switch, Door
7	W10341186	Front Foot Assembly	18	W11491751	Seal, Door	30	9761013	Front Door Latch Assembly
8	W10058460	Foot, Leveling	19	W10435470	Brace, Main Back	31	W11370462	Rod, Door Switch
9	3195097	Bottom, Oven	20	W11379353	Retainer, Insulation (Left)	32	W10078370	Rod, Push Latch
10	W10586204	Sensor		W11379943	Retainer, Insulation (Right)			FOLLOWING PARTS NOT ILLUSTRATED
11	8053967	Baffle, Burner Oven						
12	8053969	Shield, Heat	21	W10137382	Clip, Panel		8524099	Insulation, Wrap
13	8053968	Shield, Lower	22	W10624590	Cord, Power		W10180437	Insulation, Back

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top Vent
	W10310922	Black
2	W10163951	Screw
3		Handle, Door
	W10144883	Stainless
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner
7		Badge
	W10846752	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	9761357	Retainer, Insulation
10	W10299227	Hinge, Door (Passive)
11		Glass, Outer Door
	W11170209	Stainless
12		Trim, Door Side
	W10746436	Black (Left)
	W10746435	Black (Right)
13	W10327235	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10200660	Screw
15	W11379944	Strap, Door
16	W10031780	Screw
17	W10316950	Frame, Glass
18	W10299224	Hinge, Active (With Spring)

DRAWER AND BROILER PARTS



DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11173792	Rack, Oven	4	3196165	Screw	5		Panel, Drawer Front
2	W10688022	Drawer, Storage					W11190207	Stainless
3	W10462909	Bracket, Mounting				6	W10674708	Glide, Drawer Rear

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	285006	Black
	206922	Primer (White)
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	4396923	Grid, Broiler Pan and
	31617	Cleaner, Gas Grate & Drip Pan
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning
	W10275756	Cleaner, Granite
	4396096RB	Griddle
	4396927	Rack, Oven (Split)
	W10123240	Rack, Broiler Pan & Roasting