




Dishwasher

MODELS:

WDP370PAHB1 (Black)

WDP370PAHW1 (White)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	W10803537	Stiffener, Door	7	8268961	Sleeve, Friction
	W11444535	Energy Guide	4		Panel Front	8		Fastener
	W11384188	Owners Manual		W10299777	Black		W10503548	Black
	W11266092	Tech Sheet		W10299776	White	9	489470	Screw
2		Arm, Hinge	5		Access Panel			
	W10274922	Left Hand		W10441003	Black			
	W10274921	Right Hand	6	W10255097	Protector			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert and Vent Gasket)	3		Handle, Latch	7	W10919361	Control, Electronic
	W10921576	Black		W10716685	Black	8	W10825369	Brace, Connector
	W10921574	White		W10716686	White	9	W10274880	Switch, Door
2	W10825638	Box, Connector	4	W10274884	Bolt, Latch	10	W10350294	Button Tree
			5	W10348409	Screw	11	W10350295	Light Pipe
			6	8524471	Actuator, Latch	12	W10678341	Spring, Latch


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	5	W10919772	Deflector, Vent (Also Order Item 4)	9	8269296	Seal, Door/Console
2	W10274908	Inner Door (Also Order Item 4)	6	W10671905	Dispenser Assembly	10	W10462232	Bracket, Dispenser
3	W10482094	Cover, Dispenser	7	W10832781	Harness, Wiring	11	W10524920	Cap, Rinse Aid
4	W10254545	Gasket, Vent	8	W10177098	Screw			


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10346525	Float & Retainer Assembly
2	W10769066	Inlet Hose	6	371505	Clamp, Hose	10	304231	Screw
3	W10195536	Inlet, Water (Also Order Item 4)	7	W11130744	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
4	8531323	Gasket	8	304392	Screw	12	W10316267	Standpipe, Overfill


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10266935	Tube Assembly (Includes Heater Assembly)	10	8575897	Wheel Assembly	15	W10477552	Nut, Heater Element
2	W10321574	Shield, Thermostat	11	W10539489	Clip, Thermostat	16	3378128	Washer, Pronged Cup
3	W10524469	Seal, Tub	12	3371618	Thermostat	17	3400014	Screw, Grounding
4	W10341745	Screw	13	W10732961	Bracket, Heater Support			
5	8580309	Strike, Latch	14	W10441445	Heater Element Assembly			
6	8268990	Bushing, Door Spring			(Includes Heater Washer & Nut)			
7	W10271695	Bottom Support			NOTE: If heater element is removed, it must be replaced.			
8	W10619352	Leveler, Leg						
9	W10337934	Spring, Door Balance						


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	5	W10837401	Sump & Motor Assembly	10	W10348407	Screw
2	W10482462	Sump With Seal (Also Order Items 9 & 13)	6	W10372113	Tab, Sump	11	W10195086	Motor, Isolator
3	W10463906	Screen	7	W10789806	Filter Cup Assembly	12	W10723295	Indicator, Optical Wash
4	W10805386	Motor (Also Order Items 9 & 13)	8	W10724439	Pump, Drain	13	W11182008	Grommet
			9	W10445975	Hose Assembly (Includes 2 Clamps)	14	W10169167	Clamp, Hose
						15	W10491331	Sprayarm


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10671930	Feed Tube Assembly	3	W10498900	Sprayarm
2	W10165274	Screw	4	W10340681	Manifold


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826745	Dishrack, Upper	3	3385089	Track, Dishrack	4	8565925	Stop, Track (Non-Removable)
2	W10845760	Mount, Wheel Assembly				5	W10306228	Track, Spacer


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8561705	Dishrack, Lower
2	8268645	Wheel & Transport Assembly
3	8268866	Basket, Silverware

CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Shell Assembly (Includes Items 4, 10 & 21)
	W10356268	Black
	W10356269	White
2	W10545283	Coupler, Hose Assembly
3	3400892	Screw
4	3378109	Saddle, Hose
5		Shroud, Caster
	W10270163	Black
	W10270155	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	371505	Clamp, Hose
7	6-013783	Washer
8	W10219673	Housing, Hose
9	W10496105	Power Cord
10	W10219682	Protector, Edge Divider
11	3373329	Screw
12	3371644	Screw
13	3370826	Screw
14	3373199	Panel, Top
15	304428	Screw
16	302251	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	8559933	Caster
18	W10254672	Adapter, Faucet
19	W10213953	Screw
20	8559928	Frame, Assembly
21	W10254751	Protector, Edge Short
22	W10328716	Bar, Blocker
23	W10001330	Screw
24	W10266781	Bracket, Tub

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit and Bisque

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis VINYL TOUCH-UP (4oz)
	676453	White
	4396853	Silver Atlantis SIDE PANEL KITS
	4378867	White
	4378868	Black
	4378869	Almond

CONVERSION KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PORTABLE TO UNDERCOUNTER
	W10322576	Black
	W10322578	White

AIR GAP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	300096	Air Gap Kit (Prevents Back Siphoning of Contaminated Water Into Dishwasher)