




ELECTRIC COMBO WALL OVEN

MODELS:

KOCE507ESS21 (Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	7101P426-60	Screw	16	W10681157	Cover, Combo Blower
	W11382204	Owner's Manual	9	4450118	Nut			FOLLOWING PARTS NOT ILLUSTRATED
	W11382210	Quick Start Guide	10	W10655463	Bracket, Blower (Left)			
	W11340885	Tech Sheet		W10655462	Bracket, Blower (Right)		W11245670	Harness, Main
2		Assembly, Control Panel (Includes Overlay)	11	4451758	Block, Foam		W11256627	Harness, Signal
	W11304125	Stainless	12		Skin, Control Panel		W11264646	Harness, Door Latch
3	W11249218	Appliance Manager, Copernicus		W10588741	Stainless		W11229448	Harness, Communication
4	W11339492	Screw (Black)	13	W10283025	Side, Bracket		313438	Clip, Harness
5	W11397930	Blower	14	W11166802	Divider, Chassis Back		4450800	Screw, Grounding
6	W10655467	Chassis, Combo Side	15	W10318159	Chassis, Cover Top Front 27 In		W11226264	Strap, Ground
7	W11037652	Chassis, Cover Top Back 27 In WIFI					4448664	Clamp, Conduit
							W10017410	Fuse, Time Delay
							4454949	Holder, Fuse
							W11394923	Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11134657	Duct, Lower Chassis Back	17	W11167419	Cover, Suction (Left)	31	W11245118	Foot, Base
2	W11085298	Tube, Vent		W11186675	Cover, Suction (Right)	32	8285593	Cover, Connector
3	W11239070	Receiver, Hinge (Left)	18	4449751	Thermostat (TOD)	33	W11256423	Base, Vent Exhaust
	W11239072	Receiver, Hinge (Right)	19	W11244454	Base, Chassis	34	W10472384	Bulb, Light
4	W11156710	Spacer, Base	20		Assembly, Bottom Vent	35		Sidetrilm, Bended
5	W11132456	Latch, Motorized		W11369886	Stainless		W11235457	Black (Left)
6	W11244456	Top, Chassis	21	W11244446	Duct, Bottom Chassis		W11235458	Black (Right)
7	W11205574	Assembly, Oven Light	22	W10283021	Support, Base (Right)	36	W11404000	Screw
8	W10283020	Support, Base (Left)	23	W11135135	Support, Air Channel	37	W11249635	Screw
9	W10904163	Deflector, Blower	24	W11390667	Spacer, Chassis Bottom Duct	38	W11245114	Foot, Chassis (Left)
10	W11518348	Vent, 27 In Combo Center	25	W11166315	Bumper and Screw		W11245116	Foot, Chassis (Right)
11	W11608109	Gasket, Cavity	26	W10472386	Lens, Light			FOLLOWING PARTS NOT ILLUSTRATED
12	W11256424	Cover, Vent Exhaust	27	7101P426-60	Screw	W11244474		Insulation, Wrap
13	W11165274	Side, Chassis	28	W11186391	Deflector, Chassis (Left)	W11244475		Insulation, Back
14		Back, Chassis (Not Serviced)		W11186398	Deflector, Chassis (Right)			
15		Liner, Oven (Not Serviceable)	29	W10254050	Screw			
16	W11346074	Probe, Sensor	30		Trim, Bottom Vent			
				W11356754	Black			


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	8	W11296054	Hinge, Door (Left)	14		Handle Assembly
2	7101P375-60	Screw		W11296055	Hinge, Door (Right)		W11241574	Stainless
3	W11290045	Screw	9	3196183	Screw	15	W10551026	Medallion, Handle
4	W10618123	Glass, Inner	10	W11317731	Screw (Black)	16	W10656499	Screw
5	W11302731	Spacer, Air Divider	11		Door Assembly			
6	W11204277	Retainer, Air Divider Glass		W11295967	Stainless			
7	7101P426-60	Screw	12	W10319024	Washer, Door			
			13	W10518672	Badge			


INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	10	W11425715	Blade, Fan	20	W11033111	Nut, Locking
2	W10554529	Rack, Oven	11	W11433702	Nut, Acorn (LH)	21	W11251715	Plate, Convect Motor
3	W10318198	Tray, Hidden Bake	12	W10546519	Element, Convection	22	W11251716	Insulation, Convect Motor
4	7101P434-60	Screw	13	W10819989	Baffle, Bow Tie	23	W11398057	Cover, Convect Plate
5	7101P426-60	Screw	14	W10554532	Rack, Sliding	24	W11198518	Back, 27 In Cavity Baffle Bowtie
6	W10282957	Crossbar, Hidden Bake Tray	15	W10588737	Shield, Broil Front			
7	W11292248	Element, Bake	16	W10720084	Screw			
8	W11235537	Reflector, Broil	17	W10906658	Screw			
9	W11398058	Convect Motor Assembly	18	9755542	Probe, Temperature			
			19	W11252826	Jack, Meat Probe			


TOP VENTING PARTS



TOP VENTING PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11235470	Rail, Side (Left)	5	W11244451	Side, Combo Chassis (Right)	7	W11171004	Cover, Combo Chassis Back Duct
2	W11235471	Rail, Side (Right)	6	7101P426-60	Screw	8	W10283023	Support, Crossbar
3	7101P653-60	Screw						
4	W11171909	Side, Combo Chassis (Left)						


CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11289998	Manager, Appliance	17	W10490593	Holder, Lamp	37	461967750494	Support
2	423107845441	Sensor, Convection	18	W10795595	Lamp, Halogen	38	W11213889	Arm, Sliding
3	461967848711	Heater, Convection Element	19	W10358241	Assembly, Interlock Switch	39	423107570871	Spring, Release Rod
4	W11453899	Blade, Fan	20	461967848881	Switch	40	W10769147	Sealing, Lamp
5	W10120233	Nut, Speed	21	W10876593	Holder, Switch	41	461967825781	Screw (Shoulder)
6	W11505129	Filter, Noise	22	423107022541	Reflector	42	W10128850	Assembly, Sliding Arm
7	461967754821	Duct, Magnetron	23	423107720491	Lens, Lamp	43	W11591019	Housing, Upper Inverter
8	461967017511	Trim, Side (Left)	24	W11440819	Clip, Spring	44	W11591018	Housing, Lower Inverter
	W11044584	Trim, Side (Right)	25	W11334717	Vent, Top			MISCELLANEOUS PARTS
9	461967825321	Screw	26	W10460457	Sensor, Humidity			
10	461967848621	Transformer, Light (20V)	27	461967008461	Support, Bottom			
11	461967842541	Thermoactuator	28	W11319465	Hinge, Door	W11539494		Harness, Inverter
12	241908600053	Fuse	29	W11233698	Motor, Convection Fan	W11555168		Harness, Interlock
13	4375231	Block, Fuse	30	W11131760	Cooling Fan Assembly	W11454022		Harness, Fan and Turntable
14	461967846741	Thermostat, Magnetron	31	W11504539	Inverter	W11539527		Jumper Harness, Communication
15	W11504545	Magnetron	32	461967825971	Screw			
16	W10465869	Spring, Lamp	33	461967750464	Rod, Push			
			34	241960100002	Sensor, Temperature			
			35	461967510191	Bushing			
			36	461967570351	Spring, Torsion			


MICROWAVE DOOR PARTS



MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8304588BL	Cap, Screw	5	W11317731	Screw (Black)	8		Handle Assembly
2	7101P338-60	Screw	6		Door Assembly		W11241574	Stainless
3	W11328749	Inner Door Assembly		W11300493	Stainless	9	W10551026	Medallion, Handle
4	W10359769	Foam, Door Handle	7	W10319024	Washer, Door	10	W10656499	Screw

INTERNAL MICROWAVE PARTS



INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461968977491	Plate, Crisp	7	W10367316	Ring, Turntable	13	461967753742	Adapter, Turntable Motor
2	W10796139	Steamer	8	W10545578	Drive, Turntable	14	252262898008	Support, Spring Lock Grill
3	W10748279	Rack, Low Convection	9	461968929542	Handle, Pan			
4	W10750839	Plate, Baking	10	W10387651	Element, Grill			
5	461967848971	Motor, Turntable	11	461967451001	Plate, Cover			
6	W11340343	Turntable	12	461967753871	Support, Element			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORY PARTS
	4396923	Broiler Pan and Grid
W10123240		Rack, Broiler Pan and Roasting
	4378577	Stone, Brick Pizza
	8009	Light Bulb
		Assembly, Bottom Vent
W11369893		Black
		Combo Oven Microwave Side Trim Kit
W10536162		Black
W10495945		Combo Oven Deflector Kit
		Medallion, Handle
W10846205		Chrome
W10846206		Black
W10846207		Red
		Deflector, Warming Drawer Heat
W10536338		Stainless