




GAS RANGE

MODELS:

WFG775H0HB5 (Black)

WFG775H0HW5 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Knob	15	W11043399	Griddle
	W11427474	Quick Start Guide		W10912202	Black	16		Bezel
	W11448510	Use & Care Guide		W10918417	White		W10912201	Black
	W11565452	Tech Sheet	8		Grate Kit		W10918523	White
2		Burner Cap Kit		W10865170	Black	17	W10879790	Grate Hinge Spacer
	W11498499	Black (Set of 4)	9	W10673618	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	W10067840	Screw	10	W11379946	Manifold Panel Bracket		W11458869	Harness, Main
4	W11367106	Burner Kit	11	W11379358	Rear Gas Cooktop Bracket		W10753750	Harness, Bake/Broil
5		Cooktop	12	W11379945	Bracket, Anti-Tip		W10334923	Clip, Gas Wiring
	W11418087	Black					313438	Clip, Harness
	W11418088	White	13	7101P485-60	Screw, Anti-Tip Kit		7111P017-60	Clamp, Wire
6		Panel, Manifold	14		Hinge, Grate (Not Serviced)		3196896	Clip, Wire
	W10867880	Black					3196520	Clip, Wire
	W10867879	White						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10920631	Module, Spark DSI	11	W10856361	Bracket, Control
	W11213290	Black (Left)	5	W10198745	Cover, Upper	12	W10475149	Module, Spark (5+0)
	W11213292	Black (Right)	6	W10192841	Shield, Heat	13	W10797001	Bracket, Ignitor
	W11213291	White (Left)	7		Control, Electronic (LCX)	14	W10901802	Panel, Backer
	W11213293	White (Right)				15		Bracket, Eye Brow
2	W10516123	Bracket, Console Mounting		W11520692	Black		W11443964	Black
			8	W10762981	Bracket, Mounting		W11443963	White
3		Console	9	W10184251	Cover, Back	16	3196169	Screw
	W10869986	Black	10	3196178	Screw	17	W10551614	Spreader, Clip-Spring
	W10869987	White						


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	17	W10362924	Screw	32	3196560	Screw
2	9758701	Spacer, Door	18	W10323077	Diffuser, Flame	33	W10389555	Fan, Convection
3	W10273002	Bracket, Oven Support	19	3196178	Screw	34	W10346154	Cover, Convection
4		Panel, Side	20	3196165	Screw	35	W10362924	Screw
	W10162245	Black	21	W11491752	Gasket, Door	36	W10289145	Rack, Oven (Gull-Wing)
	W10575396	White	22	W10031780	Screw	37	W10531060	Rack, Oven
5	W10158780	Cover, Rear Fan	23	W10273195	Shield, Heat			FOLLOWING PARTS NOT ILLUSTRATED
6	W11511828	Switch, Door	24	W10273192	Rod, Door Switch			
7	W10137382	Clip, Panel	25	W10910642	Cord, Power			
8	W10919715	Gasket	26	W10035900	Support, Oven Bottom		4820F015-59	Insulation, Strap
9	W10289077	Receiver, Hinge	27	W11379356	Pan, Bake		W10526208	Insulation, Wrap
10	W10058460	Foot, Leveling	28	W11544377	Light Assembly		W10526209	Insulation, Main Back
11	W10211368	Bottom, Oven	29	W10571723	Bulb, Halogen 40 Watts			
12	W10586204	Sensor						
13	3601P356-45	Baffle, Bake Burner	30	W10341186	Front Foot Assembly			
14	3196178	Screw	31	W10390008	Base Rail Assembly (Left)			
15	W10435470	Brace, Main Back		W10390007	Base Rail Assembly (Right)			
16	W11040249	Assembly, Flue (Upper)						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front and Right Front)	19	3196385	Screw
2	W11459263	Orifice Holder Assembly (18K) (Left Front)		W11352013	Valve, Gas (Left Rear and Center)	20	3400016	Screw
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)		W11352015	Valve, Gas (Right Rear)	21	W11428831	Electrode (Left Front, Left Rear, Center)
	W11459260	Orifice Holder Assembly (15K) (Right Front)	9	W10224921	Bracket, Aegis		W11428858	Electrode (Right Front & Right Rear)
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	10	W10439242	Burner, Broiler	22	W10827923	Electrode, Spring
	W11459261	Orifice Holder Assembly (8K) (Center)	11	W10680035	Burner, Bake			FOLLOWING PARTS NOT ILLUSTRATED
			12	W10720102	Valve, Gas		W11489399	LP 5 Orifice Conversion Kit
			13	W10324262	Igniter, Bake		W10566535	LP Conversion Kit (Bake/Broil)
			14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)		W10182767	Tie, Manifold Wire
3	W10295996	Bracket, Saddle Valve	15	W10776437	Fitting, Broil			
4	W10510125	Tubing, Main Supply	16	W10333842	Electrode, Broil			
5	W10783317	Switch, 5 Burner Manifold Harness	17	W11485988	Orifice (18K) (Left Front)			
6	3601P336-45	Baffle, Broil Burner		W11485873	Orifice (9.5K) (Left Rear)			
7	W11418925	Manifold Assembly		W11428753	Orifice (15K) (Right Front)			
				W11485871	Orifice (5K) (Right Rear)			
				W11485874	Orifice (8K) (Center)			
			18	3196178	Screw			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Vent, Trim
	W10880611	Black
	W10880612	White
2	W10477496	Screw
3		Handle, Door
	W11022643	Black
	W11022644	White
4	W10297318	Liner, Door
5	W10031790	Screw
6	W10300487	Glass, Inner
7	W10294853	Bracket, Glass Liner
8	W10440013	Hinge, Door (Active)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9		Glass Assembly, Outer Door
	W10871829	Black
	W10871830	White
10		Trim, Side
	W10334004	Black
	W10334003	White
11	W10327235	Screw
12		Trim, Bottom
	W10334031	Black
	W10333990	White
13	W10031780	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10294851	Rail, Door
15	W10317886	Screw
16		Standoff, Handle
	W10917796	Black
	W10917797	White
17	W10772958	Insulation, Door
18	W10884775	Badge

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10688022	Drawer, Storage	6		Handle, Door
	W11449686	Black	4	W10441804	Slide, Drawer (Left)		W11022643	Black
	W11449681	White		W10441805	Slide, Drawer (Right)		W11022644	White
2	3196169	Screw	5	W10318026	Bracket, Mounting	7	W10498399	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)