



ELECTRIC COMBO WALL OVEN


MODELS:

KOCE500EWH23 (White)

KOCE500ESS23 (Stainless)

KOCE500EBS23 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W10588732	Chassis, Cover Top Back 30 IN	15	W10318158	Chassis, Cover Top Front 30 IN
	W11382204	Owner's Manual	8	7101P426-60	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W11382210	Quick Start Guide	9	W10681157	Cover, Combo Blower			
	W11340885	Tech Sheet	10	W10655463	Bracket, Blower (Left)		W11659368	Harness, Main
2		Assembly, Control Panel (Includes Overlay)		W10655462	Bracket, Blower (Right)		W11256627	Harness, Signal
	W11304132	White	11	4451758	Block, Foam		W11264646	Harness, Door Latch
	W11304123	Stainless	12		Skin, Control Panel		W11229448	Harness, Communication
	W11304126	Black Stainless		W10588746	White		3400015	Screw, Grounding
3	W11249218	Appliance Manager, Copernicus		W10588740	Stainless		W11226264	Strap, Ground
4	W11339492	Screw (Black)		W10776407	Black Stainless		4448664	Clamp, Conduit
5	W11397930	Blower	13	4450118	Nut		313438	Clip, Harness
6	W10655467	Chassis, Combo Side	14	W11166802	Divider, Chassis Back		W11394923	Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11171004	Cover, Combo Chassis Back Duct	18	4449751	Thermostat (TOD)	32	8285593	Cover, Connector
2	W11085298	Tube, Vent	19	W11135103	Base, Chassis	33	W11256423	Base, Vent Exhaust
3		Trim, Bottom Vent	20		Assembly, Bottom Vent	34	W10472384	Bulb, Light
	W11356753	Black		W11369885	White	35		Trim, Side
4	W11558603	Spacer, Base		W11369882	Stainless		W11235457	Black (Left)
5	W11132456	Latch, Motorized		W11369884	Black		W11235458	Black (Right)
6	W11168071	Top, Chassis	21	W11244446	Duct, Bottom Chassis	36	W10283022	Support, Crossbar
7	W11205574	Assembly, Oven Light	22	W10283021	Support, Base (Right)	37	W10283024	Side, Bracket
8	W10283020	Support, Base (Left)	23	W11135135	Support, Air Channel	38	W11627410	Siderail, Combo (Left)
9	W10904163	Deflector, Blower	24	W11390667	Spacer, Chassis Bottom Duct	39	W11627411	Siderail, Combo (Right)
10	W11518347	Vent, Combo Center	25	W11166315	Bumper and Screw	40	W11245118	Foot, Base
11	W11608108	Gasket	26	W10472386	Lens, Light	41	W11245114	Foot, Chassis (Left)
12	W11256424	Cover, Vent Exhaust	27	7101P426-60	Screw		W11245116	Foot, Chassis (Right)
13	W11165274	Side, Chassis	28	W11186391	Deflector, Chassis (Left)	42	W11249635	Screw
14	W11223327	Back, Chassis		W11186398	Deflector, Chassis (Right)	43	7101P633-60	Screw (Black)
15		Liner, Oven (Not Serviceable)				44	W11134657	Duct, Lower Chassis Back
16	W11346074	Probe, Sensor	29	W11404000	Screw	45	W11533682	Cover, WIFI
17	W11171909	Side, Combo Chassis (Left)	30	W11167419	Cover, Suction (Left)			FOLLOWING PARTS NOT ILLUSTRATED
	W11171919	Side, Combo Chassis (Right)		W11186675	Cover, Suction (Right)	W11188284		Insulation, Wrap
			31	9755542	Probe, Temperature	W11234758		Insulation, Cavity


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302587	Liner Assembly	9	W10254050	Screw	16		Handle Assembly
2	7101P375-60	Screw	10	W11296036	Hinge, Door (Left)		W11241572	Stainless
3	W11290045	Screw		W11296037	Hinge, Door (Right)	17	W10551026	Medallion, Handle
4	W10618107	Glass, Inner				18	W10656499	Screw
5	W11302730	Spacer, Air Divider	11	3196183	Screw			
6	W11174095	Retainer, Air Divider Glass	12	W11317731	Screw (Black)			
7	7101P426-60	Screw	13		Door Assembly			
8	W11239070	Receiver, Hinge (Left)		W11264076	White			
	W11239072	Receiver, Hinge (Right)		W11295957	Stainless			
				W11295959	Black Stainless			
			14	W10319024	Washer, Door			
			15	W10518672	Badge			


INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	11	W11425715	Blade, Fan	20	W11251716	Insulation, Convect Motor
2	W10554526	Rack, Oven	12	W10546519	Element, Convection	21	W11398057	Cover, Convect Plate
3	W10318198	Tray, Hidden Bake	13	W10819989	Baffle, Bow Tie	22	W11252826	Jack, Meat Probe
4	7101P434-60	Screw		W10918895	Baffle, Bow Tie			
5	7101P426-60	Screw			(For Black Stainless Models)			
6	W10282957	Crossbar, Hidden Bake Tray	14	W10554531	Rack, Sliding			
7	W11292248	Element, Bake	15	W10588737	Shield, Broil Front			
8	W11235537	Reflector, Broil	16	W10720084	Screw			
9	W11398058	Convect Motor Assembly	17	W10906658	Screw			
10	W11433702	Nut, Acorn (LH)	18	W11033111	Nut, Locking			
			19	W11251715	Plate, Convect Motor			


CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11289998	Manager, Appliance	16	W10465869	Spring, Lamp	35	461967510191	Bushing
2	423107845441	Sensor, Convection	17	W10490593	Holder, Lamp	36	461967570351	Spring, Torsion
3	461967848711	Heater, Convection Element	18	W10795595	Lamp, Halogen	37	461967750494	Support
4	W11453899	Blade, Fan	19	W11555168	Harness, Interlock	38	W11213889	Arm, Sliding
5	W10128850	Assembly, Sliding Arm	20	461967848881	Switch	39	423107570871	Spring, Release Rod
6	W11505129	Filter, Noise	21	W10876593	Holder, Switch	40	W10769147	Sealing, Lamp
7	461967754821	Duct, Magnetron	22	423107022541	Reflector	41	461967825781	Screw (Shoulder)
8	461967017491	Trim, Side (Left)	23	423107720491	Lens, Lamp	42	W11591019	Housing, Upper Inverter
	461967017481	Trim, Side (Right)	24	W11440819	Clip, Spring	43	W11591018	Housing, Lower Inverter
9	461967825321	Screw	25	W11334716	Vent, Top Microwave	44	W10120233	Nut, Speed
10	461967848621	Transformer, Light (20V)	26	W10460457	Sensor, Humidity			MISCELLANEOUS PARTS
11	461967842541	Thermoactuator	27	461967008461	Support, Bottom		W11454022	Harness, Fan and Turntable
12	241908600053	Fuse	28	W11319465	Hinge, Door		W11539527	Jumper Harness, Communication
13	4375231	Block, Fuse	29	W11233698	Motor, Convection Fan		W11539494	Harness, Inverter
14	461967846741	Thermostat, Magnetron	30	W11131760	Cooling Fan Assembly			
15	W11504545	Magnetron	31	W11504539	Inverter			
			32	461967825381	Screw			
			33	461967750464	Rod, Push			
			34	241960100002	Sensor, Temperature			


MICROWAVE DOOR PARTS



MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8304588BL	Cap, Screw	6	W10319024	Washer, Door	8		Handle Assembly
2	7101P338-60	Screw	7		Door Assembly		W11241572	Stainless
3	W11639555	Inner Door Assembly		W11300492	White	9	W10551026	Medallion, Handle
4	W10359769	Foam, Door Handle		W11300490	Stainless	10	W10656499	Screw
5	W11317731	Screw (Black)		W11300496	Black Stainless			

INTERNAL MICROWAVE PARTS



INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461968977491	Plate, Crisp	7	W10367316	Ring, Turntable	13	461967753742	Adapter, Turntable Motor
2	W10796139	Steamer	8	W10545578	Drive, Turntable	14	252262898008	Support, Spring Lock Grill
3	W10748279	Rack, Low Convection	9	461968929542	Handle, Pan			
4	W10750839	Plate, Baking	10	W10387651	Element, Grill			
5	461967848971	Motor, Turntable	11	461967451001	Plate, Cover			
6	W11340343	Turntable	12	461967753871	Support, Element			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	4396923	Broiler Pan and Grid
W10123240		Rack, Broiler Pan and Roasting
	4378577	Stone, Brick Pizza
	8009	Light Bulb
		Pro Door Handle
W10246102A		Stainless
		Medallion, Handle
W10846205		Chrome
W10846206		Black
W10846207		Red
		Deflector, Heat
W10536339		Stainless
W10727416		Black Stainless
		Trim, Tall Vent
W11570325		Black
W11570323		Stainless
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic