




GAS DRYER

MODELS:

WGD4815EW4 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10556829	Panel, Rear (Console)	16		Top
	W11361424	Owners Manual	7	W10661453	Switch, Temperature		8559800	White
	W11355746	Quick Start Guide	8		End Cap (Right)	17	W10117655	Switch, Push To Start
	W10876312	Wiring Diagram		W10520780	White	18		Assembly, Control Knob
	W11366444	Cycle Guide	9	693995	Screw		W10576636	White/Metallic
2		Assembly, Panel & Bracket	10		Lint Screen	19		Assembly, Timer Knob
	W10692607	White		W11451394	White		W10576634	White/Metallic
3	694419	Buzzer, Mini	11	688805	Clip, Spring	20	W10185981	Assembly, Timer (60 Hz.)
4		End Cap (Left)	12	693995	Screw	21	W11523106	Harness, Wiring
	W10520782	White	13	688983	Screw	22	3400818	Screw
5	8312709	Clip, Console	14	W10773242	Screw			
			15	3348629	Screw			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10773242	Screw	16	98234	Clip, Ground	29	W10803476	Assembly, Seal and Bearing
2	3390631	Screw	17	8066092	Lock, Front Top	30	W11224633	Strike, Door
3	693995	Screw	18		Panel, Front	31	W10869141	Cord, Power
4	W10841728	Seal, Spill Guard		W10664698	White	32	W10775448	Clip, Front Panel
5	8558833	Cover, Terminal Block	19	685203	Clip, Felt Pad	33	8066217	Hinge, Top
6	3404162	Clamp, Motor (With Shield)	20	W11224630	Assembly, Door Catch	34	691366	Idler Assembly
7	W11598681	Panel, Rear	21	W10730752	Seal, Door	35	W10131364	Belt, Drive
8	W10529198	Cover, Door Catch	22	343641	Screw	36	348780	Base, Motor
9	W10237959	Switch, Door	23	341029	Clamp, Pipe	37	3400500	Bolt
10	697773	Screw	24		Assembly, Hinge and Pin	38	8066184	Pulley, Motor
11	342055	Screw		W10362431	White	39	W10396029	Assembly, Motor
12	W10567345	Plug, Strike	25		Hinge Hole Cover	40	W10121316	Clamp, Motor Mount
13	W10561321	Foot, Dryer		W11308618	White	41	W10727507	Clamp, Pipe
14		Plug, Front Panel	26	W10463967	Door, Inner	42	W10529197	Bezel, Door Catch
	8564457	White	27		Door, Outer	43	W11564940	Burner Assembly (60 Hz) (Type 1)
15		Cabinet		W10714510	White			
	8530603	White	28		Handle, Door			
				W10714516	White			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	14	8530285	Box, Heater (96C)	24	W10512946	Washer, Tri Ring
2	489463	Screw	15	W10754607	Thermostat, High Limit SPST (180F)	25	W10359270	Shaft, Drum Roller - Left Hand Thread
3	3388703	Washer	16	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	26	W10359269	Shaft, Drum Roller - Right Hand Thread
4	347139	Seal, Lint Chute	17	3390647	Screw	27	3397590	Roller, Support
5	90767	Screw	18	8066049	Funnel, Burner	28	348197	Washer
6	339956	Seal	19	3403636	Baffle, Drum (Short)	29	W10298789	Nut, Hex
7	3392519	Fuse, Thermal (91C)	20	90296	Nut, Push On	30	W10714466	Bulkhead
8	W10856781	Seal, Rear Drum	21	W11032820	Bracket, Support	31	338906	Sensor, Radiant
9	3387134	Thermostat	22	W10757750	Assembly, Drum (Complete)	32	692490	Baffle, Drum (Long)
10	694089	Wheel, Blower	23	W10389567	Shield, Exhaust	33	692526	Bearing, Ring
11	8577230	Housing, Blower				34	W10219342	Screw
12	3398161	Clip, Heater Box						
13	3390631	Screw						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564940	Burner Assembly (60 Hz) (Type 1)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9		Orifice, Burner			
4	686590	Ignitor		234826	Type 1 (Natural)	W11581316		Kit, LP Conversion
5	W10366705	Screw	10	W11564943	Valve, Gas (60 Hz)			
6	343641	Screw	11	W10295523	Pipe Plug			
			12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	72017	White
--	-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	799344	White (Uncut)
--	--------	---------------

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	279948	Kit, Dryer Repair
--	--------	-------------------

	346764	Kit, Hold Down
--	--------	----------------

	W10242307	Washer, Hose
--	-----------	--------------

	3976300	Washer, Inlet Hose
--	---------	--------------------

	W10336486	Connector, Hose -"Y"
--	-----------	----------------------

	W10636192	Dry Rack
--	-----------	----------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

	350930	White
--	--------	-------

	350938	Gray Primer
--	--------	-------------