


KitchenAid®

REFRIGERATOR

MODELS:

KRFG7B4PBS05 (Black Stainless)


CABINET PARTS



CABINET PARTS

<u>RM#</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>RM#</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>RM#</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts Tech Sheet	14	WH0731474	Screw	30	WH000000	Cover, Unit
	WH0040200	English	15		Hinge, Corner Left Hand	31	WH000000	Clamp, Tube
	WH0040201	French		WH000000	Black	32	WH000000	Tube, Ice Maker Water (Includes Seal)
	WH000000	Owners Manual	16		Hinge, Corner Right Hand		WH000000	Tube, Dispenser Water (Includes Seal)
	WH000000	Energy Guide		WH000000	Black	33	WH000000	Lib. RV
2	12000000	Screw	17		Cover, Corner	34	WH000000	Refrigerator Door
3	WH0040310	Block, Floor		12000000	Black	35		Cabinet (Not a Serviceable Part)
4	WH000000	Feet, Sound	18	WH000000	Valve, Water	36	549100	Cable, Power Cord
5	WH0040000	Control, Electronic	19	WH000000	Switch, Reed	37		Assembly, Inner Air Tunnel (Includes Gasket)
6	WH0040000	Gasket, Air Box	20	WH000000	Screw		WH000000	Black
7		Appendix, Sales	21		Cylinder, Air	38	WH000000	Assembly, Hinge Side
	WH000000	Left Hand		WH000000	Reel	39	WH000000	Cover, Valve
	WH000000	Right Hand		WH000000	Bottom	40	12000000	Screw
8	WH000000	State, Roller		WH000000	Reel (Short)	41	WH000000	Gasket
9	12000000	Screw	22		Tube, Top			
10		Hinge, Top		WH000000	Black			
	WH000000	Left Hand	23	12000000	Screw			
	WH000000	Right Hand	24		Assembly, Outer Air Tunnel (Includes Gasket)			
11	WH000000	Screw (Stainless)		WH000000	Black			
12		Cover, Top Hinge Left Hand (Includes Pin)	25	WH000000	Screw			
	WH000000	Black	26	12000000	Screw			
13		Cover, Top Hinge Right Hand	27	WH000000	Bushing			
	WH000000	Black	28	WH000000	Cover, Control Box			
			29	WH000000	Screw			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1		Liner (incl. A Sealable Pan)	18	W13886302	Cover, Air Filter	26	W10901793	Gasket, Sealing
2	W10706473	Housing, Water Tank	19	W10280335	Thermistor	28	W10818451	Gasket, Evaporator to D40
3	W10795565	Strip, LED	20	W10813883	Cup, Filter	29	W11553554	Assembly, Heat Shield
4	W11481355	Reservoir, Water (Includes Filter Header, Wire Ties, and Sealing Gaskets)	21	W11473754	Assembly, Evaporator Cover (Includes Fan Motor, Wire Assembly, and Thermistor)	32	W10821475	Gasket, Heat Shield
5	W11403337	Valve, Out Water	22	W11237775	Assembly, Evaporator (Add Order the Following Leaking Parts)	33	10533003	Cup, Evaporator
6	W11481355	Housing, Water Filter (Includes Filter Header and Sealing Gaskets)		W11504450	4" I.D. NR. MB. 30 (Delivery Tube to Evaporator)	34	W11485745	Heater, Defrost
7	W10660211	Cover, Water Valve		W11506513	3" NK MB. 30 (Suction Line to Evaporator)	35	W11455451	Cup, Evaporator Heater
8	W11517895	Type, Water Filter				36	W11307147	Cover, Filter
9	W10315965	Cover, Cooling Duct						FOLLOWING PARTS NOT ILLUSTRATED
10	W11255417	Cover, Tank	23	W11443570	Strip, LED		W11445335	Assembly, Valve Wire
11	W10830805	Filter, Water	24	W10831305	Insulator, Foam			
12	W10315185	Filter, Air	25	W10215955	Base, Tank Cover			
13	W10706474	Bracket, Filter	26	W10840335	Harness, Air Tank Jumper			
14	W12115255	Screw	27	12950501	Screw			
15	12950513	Screw	28	W11500503	Heater, Filter			
16	W11345341	Insulation, Under Filter						
17	W10017431	Assembly, Air Filter						


FREEZER LINER PARTS



FREEZER LINER PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1		Liner (not A Reversible Part)	4	WH1205447	Assembly, Evaporator Cover (includes Fan Motor and drive assembly)	12	WH1435635	Assembly, Evaporator Heater (the included thermostat)
2	WH194335	Assembly, Evaporator (also Order the Following Locking Parts)	5	12050511	Screw	14	WH0605212	Assembly, Drain Funnel
	WH1505520	2 NK AL 00 (Capillary Tube to Evaporator - Cut/Seal on Aluminum portion of the Evaporator)	5	WH124684	Heater Defrost	15	M0500703	Seal
			7	WH0547555	Switch, Light	16	50351901	Gasket, Drain
			8	10502002	Cup, Evaporator	17	WH0757068	Thermostat
			9	WH1405745	Cup, Defrost-Heater	18	WH0770553	Seal, Drain Front
	WH1505520	2 NK AL 00 (Suction Line to Evaporator)	10	WH1405066	Shield, FC Heat	19	WH1205628	Assembly, Access.Pan
3	WH1233140	Assembly, LED Light Module	11	WH0533140	Gasket, Cup Tray Reel	20	WH0511355	Assembly, Evaporator Jumper Wire
			12		Door, Air			
				WH1405025	Left Hand			
				WH0550155	Right Hand			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

Part No.	Description	Part No.	Description	Part No.	Description
1	Door, Refrigerator Left Hand	9	Assembly, Fill Tube (Not Service) (Included with LH Door)	18	WT1423275 Assembly, Spindle User Interface
WT1515035	Black Stainless (Rtr Order Item # 15)	10	Bumper, Door	19	WT0808413 Gasket, Cooling Duct
2	Door, Refrigerator Right Hand	WT0407187	Black	20	Bin, Door
WT0736232	Black Stainless	11	WT0736524 Lin. Utility Bin	WT0736709	Gasket
3	WT0336318 Screw	12	WT1300753 Screw	21	WT1518275 Tube, Dispenser Water
4	WT1554923 Assembly, Ice Door	13	WT0736503 Trim, Ice Compartment Door	22	Gasket, Door
5	WT0736415 Bracket, Door Stop	14	Bin, Door	WT0917212	Black
6	Station, Door	WT0808837	Medium	23	WT0823512 Trim, Gasket
WT1523634	Black	15	WT0434232 Release, Door Duct	24	WT0736538 Assembly, Utility Bin
7	WT090204 Screw	16	WT0808441 Gasket, Ice Door	25	WT0736523 Base, Utility Bin
8	Handle, Door	17	WT0714507 Left Hand	26	WT0808536 Door, Utility Bin (Includes Gasket)
WT1339182	Stainless	WT0714508	Right Hand	27	WT0736523 Gasket, Utility Bin


FREEZER DOOR PARTS



FREEZER DOOR PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1		Door, Freezer (Includes Door Gasket)	7	12855-8	Screw	15		Gasket, Door
	W10755125	Back, Stainless	8	W11052387	Assembly, Top Pan		W10557147	Blade
2	W11357171	Handle, Door Stainless	9	W10277156	Coiler, Outer	16	W105573512	Bar, Support
3	W11323752	Screw	10	12851401	Screw	17	W10574002	Roller
4	W10551555	Shaft, Rock	11	W10459777	Support, Pan	18	W105555001	Axis, Roller
5		Assembly, Bracket	12	1355343	Screw (Stainless)	19	W105005553	Roll, Guide
	W10755543	Left Hand	13	W10755523	Assembly, Lower Half Pan	20	W10557096	Roller
	W10755547	Right Hand	14		Stop, Pan	21	W10511572	Blade
6	W107555291	Assembly, Bottom Pan		W10755525	Left Hand			
				W10755532	Right Hand			

UNIT PARTS




UNIT PARTS

Qty./ No.	Part No.	Description
1	W10141525	ScREW
2	W13620034	SCREW
3	W11443152	SEAL/CLIP
4	1255251	SCREW
5	W13650130	Assembly, Drain Extension
6	W11507052	Assembly, 3-Way Valve (Add Order the Following Locking Parts)
	W11506625	3 NK MS-00 (3-Way Valve to RC Capillary Tube & Out-Solice Heat ex Value body)
	W11506626	3 NK MS-00 (3-Way Valve to FC Capillary Tube & Out-Solice Heat ex Value body)
	W11504445	3/4 NR MS-00 (3-Way Valve to Drain)
7	W11452115	FEET, SOUND
8	W11450337	TRAY, EXPANSION
9	W13630700	Gasket, Condenser Fan
10	W11417341	SCREW
11	2313626	GRIMMET, CONDENSE
12	W11454423	Assembly, Cord Box(Include Wiring Harness, for Compressor and Power Cord)

Qty./ No.	Part No.	Description
13	W10774849	Roller
14	12552101	SCREW
15	13620033	GRIMMET
16	W11405772	Condenser (Add Order the Following Locking Parts)
	W11504445	3/4 NR MS-00 (Heat Load to Condenser)
	W11504431	1/2 NR MS-00 (Suction Line to Condenser)
17	W10251375	BRACKET, VALVE
18	W11136354	Cook, Housing
19	W10141545	SCREW
20	W10722941	Filter, EMV
21	W11515000	Assembly, Inverter Box
22	215B104	Insulation, Sound Dampening
23	W11039667	Assembly, Suction Tube
24	W11440033	Harness, Unit (Condenser Fan)

Qty./ No.	Part No.	Description
25	W13606005	Order (Service Order Without D/E) (Add Order the Following Locking Parts)
	W11534445	3/4 NR MS-00 (Heat Load to Drain)
	W11506625	3 NK MS-00 (3-Way Valve to Drain)
26	W11515412	Compressor (Add Order the Following Locking Parts)
	W11504431	1/2 NR MS-00 (Suction Tube to Compressor)
	W11504415	3-5/8 NR MS-00 (High Pressure Side to Compressor)
	W11506621	3 NK MS-00 (Charging Tube to Compressor)
	W11506635	Tube, Charging (1/4" x 3/8 Sch40) 16ft.
27	W11502151	Assembly, Condenser Fan
28	12477322	AXIS RULER REFRIGERANT CHARGE 50 grams (R600a)

SHELF PARTS




SHELF PARTS

Qty. No.	Part No.	Description
1	W10794883	Base, Pantry
2	W10838134	Eng. Handle
3	W10347066	Assembly, Filter Door
4	W10732132	Insulation, Filter Hooding
5	2223577	Latch, Push
6	W10733467	Assembly, 13" Full Shelf
7	W11114715	Assembly, 12" Full Shelf
8	W10357755	Assembly, Tuck Shelf
9		Assembly, Block
	W10317522	Front Left/Back Right
	W10317521	Front Right/Back Left
10	W10836883	Part, Pantry
11	W10357730	Assembly, Filter Shelf
12		Slide, Platter
	W10343722	Left Hand
	W10314352	Right Hand
13	W10836841	Spacer, Handle

Qty. No.	Part No.	Description
14	W10804339	Glass, Crisper Cover
15		Slide, Crisper
	W10218501	Left Hand
	W10214357	Right Hand
16	W10903331	Handle
17	W10313345	Assembly, Crisper Pan
18	W10901221	Assembly, Light
19	W10903379	Screw
20	W10825105	Assembly, Produce Presenter
21	W11444735	Pin, Under Shelf
22	W10734571	Glass, Platter
23	W10840313	Flange, Side Support
24	W10840320	Knob, Side Support
25	W10795553	Assembly, Hair Storage (Includes Lid and Gasket)
26	W10847399	Screw
27	W1084577	Screw
28	W10794555	Support, Pantry
29	W10794557	Cover, Pantry

Qty. No.	Part No.	Description
30	W10794250	Bin, Support
31	W10834713	Cover, Wiring Harness
32	W10793001	Assembly, Pantry Mix (Includes Thermistor)
33	W10794333	Assembly, Center Support
34	W10794347	Frame, Crisper Cover
35	W10794335	Gasket, Crisper Cover (Rear)
36	W10794242	Gasket, Crisper Cover (Front)
37	W10835355	Lumens, Crisper LED
38	W10834845	Cover, Wiring Harness
39		Support, Side
	W10794352	Left Hand
	W10794353	Right Hand
40	W10834233	Screw (Grey)


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

Qty. No.	Part No.	Description	Qty. No.	Part No.	Description	Qty. No.	Part No.	Description
1		Housing, Dispenser (Not Serviced)	7		Tray, Drip	18	W10698793	Gasket, User Interface Adapter
2	W10435155	Assembly, Filter User Interface	8	W10752135	Black	19	W10698704	Assembly, Ice Door/ Door Bracket
3		Black Dispenser Face	9		Panel, Ice Dispenser	17	W10693685	Part, Sound
	W10752135	Black	10	W10403752	Switch, Limit	18	W10753583	Heater, Dispenser
4		Beedis, Water Dispenser	11	W10572573	Spring, Torsion	19	W10757459	Bracket, User Interface Adapter
	W10693682	Chrome	12	W10693682	Spring, Torsion	20	W10690295	Guide, Light
5		Exterior	13	W10754133	Assembly, Paddle Jumper Wire			
	W10693685	Black	14	W10690295	Gasket			
6	W10337330	Gate, Drip						

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

Rev. No.	Part No.	Description
1	W102T2364	Screw
2	W10T33357	Plate, Ice Guide
3	W10231305	Gasket
4	W11475258	Ice Container Assembly

Rev. No.	Part No.	Description
2	W11333574	Shaft Motor
3	W11133741	Motor, Dispenser
7	323T123	Screw (Stainless)

Rev. No.	Part No.	Description
2	W11351234	Ice Maker Assembly
3	W10000335	Thermistor

OPTIONAL PARTS

Item No.	Part No.	Description
		TOUCH-UP PAINT
	12000	Black PAINT PRESSURIZED SPRAY (12.0oz)
	160008	Exempt, Back
	268006	Black Important: The spray paint is not to be used where the paint may make contact with the door gaskets.
		MISCELLANEOUS
	212040	Bealer, Gum (4 Feet)
	478900	Tap, Vinyl (3/4 x 108")
	878370	Insulation G Pieces, 3" x 24" x 48"
	878308	Insulation K2 (14 Pieces, 3" x 24" x 48")
	878541	Insulation Fiberglass (53-1/2" x 55-1/2" x 2 5/8")
	878029	K2 Foam Gap (20" x 32-1/2" x 1-1/2")
	804327	Bealer, Metal (1 Qt)
	803636	Coil, Beale
	842638	Glass, Beale (1/2 Qt)
	842638	Glass, Automatic (1 1/4 Qt)
	833638	K2, Thermal Connector
	8003RP	K2, Valve, Seal
		TORX SCREW WRENCH
	11175-0	Torx Key