




30" FREE STANDING GAS RANGE CONVECTION

MODELS:

MGR8800HK0 (Cast Iron Black)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	14	W10298664	Spreader, Flame
	W11122621	Instructions, Installation		W10884167	Black	15		Bezel
	W11122603	Guide, Use and Care	5		Panel, Manifold		W10876919	Stainless
	W10538797	Sheet, Tech (English)		W10724449	Black	16	W10673618	Screw
	W10400066	Guide, Quick Start (English)	6		Knob, Control	17	W10347385	Kit, Griddle
				W10858253	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
			7		Kit, Grate			
				W10655132	Black		W10797419	Harness, Main
2		Kit, Burner Cap	8	3400701	Screw		W10753750	Harness, Bake/Broil
	W10850506	Black (Set of 4)	9	3196557	Screw		W10809927	Harness, Cooktop
3	W10515455	Assembly, Burner (17.5K)	10	W10306542	Bracket, Anti-Tip		W10811691	Harness, Igniter (Includes Switches)
		(Left Front & Right Front)	11	7101P485-60	Screw, Anti-Tip Kit			
			12	W11194809	Electrode		3196520	Clip, Wire
	W10515454	Assembly, Burner (9.5K)			(Left Front, Left Rear, Right Front)		3196896	Clip, Wire
		(Left Rear & Center)			(Center)		W10334923	Clip, Gas Wiring
				W10515459	Electrode		313438	Clip, Harness
	W10515453	Assembly, Burner (6K)			(Right Rear)			
		(Right Rear)	13	8273062	Screw			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10920631	Module, Spark DSI	10	W10184251	Cover, Back
	W11130372	Black (Left)	6	W10516123	Bracket, Console Mounting	11	3196169	Screw
	W11130379	Black (Right)				12	W10340325	Control, MRC
2	W10551614	Spreader, Clip-Spring	7	W10530070	Bracket, Rear Gas Cooktop	13	3196178	Screw
3		Panel, Control	8	W10198745	Cover, Upper	14	W10158780	Cover, Rear Fan
	W11205020	Black	9	W10192841	Shield, Heat	15	W10475149	Module, Spark (5+0)
4	W10762981	Bracket, Mounting				16	W10797001	Bracket, Ignitor


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	6	3601P336-45	Baffle, Broil Burner	16	W10333842	Electrode, Broil
2	W10473936	Assembly, Orifice Holder (15K)	7	W10859728	Assembly, Manifold	17	W10178934	Orifice (12K)
		(Left Front)	8	W10247744	Valve, Gas		W10732136	Orifice (5K)
	W10732140	Assembly, Orifice Holder (9.5K)		W10279614	Valve, Gas		W10170507	Orifice (8K)
		(Left Rear)		W10279615	Valve, Gas		W10347414	Orifice (15K)
	W10732137	Assembly, Orifice Holder (15K)			(Left Front & Right Front)		W10657947	Orifice (8K)
		(Right Front)		W10850894	Valve, Gas			(Center)
	W10732139	Assembly, Orifice Holder (5K)			(Center)	18	3196178	Screw
		(Right Rear)	9	W10224921	Bracket, Aegis	19	3196385	Screw
	W10836764	Assembly, Orifice Holder (8K)	10	W10439242	Burner, Broiler	20	3400701	Screw
		(Center)	11	W10680035	Burner, Bake			FOLLOWING PARTS NOT ILLUSTRATED
			12	W10720102	Valve, Gas		W11087531	Kit, LP 5 Orifice Conversion
3	W10295996	Bracket, Saddle Valve	13	W10324262	Igniter, Bake		W10566535	Kit, LP Conversion (Bake/Broil)
4	W10510125	Tubing, Main Supply	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
5	W10811691	Harness, Igniter (Includes Switches)	15	W10776437	Fitting, Broil			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	16	W11040249	Assembly, Flue (Upper)	31	W10390008	Assembly, Base Rail (Left)
2	9758701	Spacer, Door	17	W10362924	Screw		W10390007	Assembly, Base Rail (Right)
3	W10273002	Bracket, Oven Support	18	W10323077	Diffuser, Flame	32	3196560	Screw
4		Panel, Side	19	3196178	Screw	33	W10289145	Rack, Oven (Gull-Wing)
	W10162245	Black	20	W10874067	Motor, Fan (Convection)			FOLLOWING PARTS NOT ILLUSTRATED
5	W10346154	Cover, Convection	21	W10162385	Gasket, Door		W10526208	Insulation, Wrap
6	W10627802	Switch, Door	22	W10031780	Screw		W10526209	Insulation, Main Back
7	W10501599	Clip, Front Frame Cover	23	W10273195	Shield, Heat			
8	W10531060	Rack, Oven	24	W10273192	Rod, Door Switch			
9	W10289077	Receiver, Hinge	25	W10624590	Cord, Power			
10	W10058460	Foot, Leveling	26	W10035900	Support, Oven Bottom			
11	W10211368	Bottom, Oven	27	W10273204	Pan, Bake			
12	W10586204	Sensor	28	W11175594	Assembly, Light			
13	3601P356-45	Baffle, Bake Burner	29	W10571723	Bulb, Halogen 40 Watts			
14	3196178	Screw	30	W10341186	Assembly, Front Foot			
15	W10435470	Brace, Main Back						


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10766562	Insulation, Door	10	W10826568	Liner, Door	17	W10541911	Bracket, Glass Upper Handle
2		Glass, Outer Door	11	W10813140	Rail, Horizontal Support	18	9780274	Screw
	W10693388	Stainless	12	W10675397	Scoop, Door	19	W10813142	Spacer, Glass
3	W10885519	Hinge, Door (Active)	13		Glass Assembly, Outer Door	20	W10319024	Washer, Door
4	W10031790	Screw		W11205027	Black			
5	W10362924	Screw	14		Handle, Door			
6	W10813616	Glass, Inner		W10834521	Stainless			
7	W10137382	Clip, Panel	15	W10162385	Gasket, Door			
8	W10813139	Rail, Vertical Support	16	W10612925	Badge			
9	W10241367	Screw						

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10441804	Slide, Drawer (Left)	4	W10688022	Drawer, Storage
	W11205029	Black		W10441805	Slide, Drawer (Right)	5	3196165	Screw
2	W10318026	Bracket, Mounting						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	350938	Gray Primer
	350942	White Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	31605	Kit, Cooktop Care
	W10355049	Wipes, Stainless Steel Cleaning
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	W10432019	Alt Cleaning Kit
	WA906B	Scraper, Cooktop
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	4396096RB	Griddle
	W10205524	Split Oven Rack
	W10289145	Rack, Oven (Gull-Wing)
	4396923	Grid, Broiler Pan and
	W10123240	Rack, Broiler Pan & Roasting