




ELECTRIC WALL OVEN

MODELS:

WOD51EC7HB21 (Black)
WOD51EC7HW21 (White)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Skin, Control Panel	17	W11244459	Cover, Top Back 27 IN Chassis
	W11340821	Owner's Manual		W11026968	Black			
	W11419188	Quick Start Guide		W11026967	White			FOLLOWING PARTS NOT ILLUSTRATED
	W11419201	Tech Sheet	8	7101P426-60	Screw			
2		Assembly, Control Panel (Includes Overlay)	9	4451758	Block, Foam		W11245673	Harness, Main
	W11304439	Black	10	W10655463	Bracket, Blower (Left)		W11245677	Harness, Signal
	W11304441	White		W10655462	Bracket, Blower (Right)		W11264646	Harness, Door Latch
3	W11253187	Appliance Manager, Copernicus	11	W11162062	Gasket, Rubber (652mm)		W10562910	Harness, EOL
	W11253188	Manager, Appliance (Without Power Supply)	12	W10728475	Gasket, Rubber		W11233570	Harness, Console
4	W11339492	Screw (Black)	13	W11179509	Tray, Electronic		4448664	Clamp, Conduit
5	W11397930	Blower	14	W11166802	Divider, Chassis Back		W10655464	Bracket, Harness
6	W11409842	Antenna	15	W10351295	Bumper		313438	Clip, Harness
			16	W11244469	Cover, Top Front 27 IN Chassis		4450800	Screw, Grounding
							W10487999	Clip, Harness
							W11394923	Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10254050	Screw	22		Trim, Bottom Vent	39	W11256421	Cover, Top Back Exhaust
2	W11085298	Tube, Vent		W11356754	Black	40	W11256420	Base, Top Back Exhaust
3	W11100732	Receiver, Hinge (Upper)	23	W11135135	Support, Air Channel	41	W11256431	Cover, Lower Back Exhaust
4	W11156710	Spacer, Base	24	W11390667	Spacer, Chassis Bottom Duct	42	W11256430	Base, Lower Back Exhaust
5	W11132456	Latch, Motorized	25	W11166315	Bumper and Screw	43	W11256432	Deflector, Lower Back Exhaust
6	W11244456	Top, Chassis	26	8285593	Cover, Connector	44	W11167419	Cover, Suction (Left)
7	W11246615	Assembly, Light	27	7101P426-60	Screw		W11186675	Cover, Suction (Right)
8	W11245118	Foot, Base	28	W11256423	Base, Vent Exhaust	45	W11404000	Screw
9	W10904163	Deflector, Blower	29	W11344645	Hat Bracket, Vent	46		Liner, Oven (Not Serviceable)
10	W11219304	Duct, Chassis Back (Lower)	30	W11342780	Bracket, Top Front	47	W11239070	Receiver, Hinge (Left)
11	W11608109	Gasket, Cavity	31	W11186652	Bracket, U-Shape		W11239072	Receiver, Hinge (Right)
12	W11256424	Cover, Vent Exhaust	32	W11235483	Vent, Center 27"			(Lower)
13	W11165274	Side, Chassis	33	W11334858	Vent, Top 27 in			FOLLOWING PARTS NOT ILLUSTRATED
14	W11442210	Back, Chassis	34	W11165250	Duct, Chassis Back (Upper)			
15	W11297361	Lens, Light	35	W11245114	Foot, Chassis (Left)			
16	W11346074	Probe, Sensor		W11245116	Foot, Chassis (Right)			
17	W11297362	Bulb, Light	36	W11211345	Foam, U-Bracket			
18	4449751	Thermostat (TOD)	37	W11249635	Screw		W11244474	Insulation, Wrap
19	W11244454	Base, Chassis	38	W11235460	Cover, Side Trim (Left)		W11244475	Insulation, Back
20		Assembly, Bottom Vent		W11235461	Cover, Side Trim (Right)			
	W11369893	Black						
	W11369894	White						
21	W11244446	Duct, Bottom Chassis						


UPPER OVEN DOOR PARTS



UPPER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	8	W11296079	Hinge, Door (Left)	13		Handle Assembly
2	7101P375-60	Screw		W11296080	Hinge, Door (Right)		W11022641	Black
3	W11290045	Screw	9	3196183	Screw		W11022642	White
4	W10618123	Glass, Inner	10	W11317731	Screw (Black)			
5	W11302731	Spacer, Air Divider	11		Door Assembly			
6	W11204277	Retainer, Air Divider Glass		W11286345	Black			
7	7101P426-60	Screw		W11286343	White			
			12	W10319024	Washer, Door			






LOWER OVEN DOOR PARTS



LOWER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	8	W11296079	Hinge, Door (Left)	13	W10884775	Badge
2	7101P375-60	Screw		W11296080	Hinge, Door (Right)	14		Handle Assembly
3	W11290045	Screw	9	3196183	Screw		W11022641	Black
4	W10618123	Glass, Inner	10	W11317731	Screw (Black)		W11022642	White
5	W11302731	Spacer, Air Divider	11		Door Assembly			
6	W11204277	Retainer, Air Divider Glass		W11286345	Black			
7	7101P426-60	Screw		W11286343	White			
			12	W10319024	Washer, Door			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238160	Element, Broil	4	7101P434-60	Screw	6	W10282957	Crossbar, Hidden Bake Tray
2	W10317431	Rack, Oven	5	7101P426-60	Screw	7	W11292248	Element, Bake
3	W10318198	Tray, Hidden Bake						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
		Deflector, Heat
	W11173685	Black
	W11173681	White
	W10536338	Stainless
		Kit, Built-In Double Oven Side Trim
	W10536161	Black
		Trim, Tall Vent
	W11406624	Stainless