




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

WRF954CIHW01 (White)

WRF954CIHB01 (Black)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	13		Cover, Top Hinge	27	W10858468	Assembly, Jumper Wire
		Tech Sheet			Right Hand	28	W10754144	Cover, Control Box
	W11097245	English		W10895450	White	29	W10141645	Screw
	W11097246	French		W10895446	Black	30	W10669259	Cover, Unit
	W11307651	Use and Care Guide	14	W10731474	Screw	31	M0108107	Clamp, Tube
	W11112987	Energy Guide	15		Hinge, Center	32	W10853597	Tube, Ice maker Water (Includes Seal)
2	12990302	Screw			Left Hand		W10853599	Tube, Dispenser Water (Includes Seal)
3	W10840310	Block, Pivot		W10691676	White	33	W10768379	Lid, HV
4	W10838044	Pad, Sound		W10691674	Black	34	W10705239	Retainer, Door
5	W11533212	Control, Electronic (Includes Dispenser User Interface)	16		Hinge, Center	35		Cabinet (Not a Servicable Part)
					Right Hand			
6	W10415341	Gasket, HV Box		W10691702	White			
7		Assembly, Roller		W10691700	Black			
	W11084045	Left Hand	17		Cover, Corner	36	549193	Clamp, Power Cord
	W11084046	Right Hand		12587703W	White	37		Assembly, Outer Air Tunnel (Includes Gasket)
8	W10846099	Brake, Roller		12587703B	Black			
9	12990521	Screw	18	W11095287	Valve, Water		W10835553	White
10		Hinge, Top	19	W11105994	Switch, Reed		W10835554	Black
	W11032616	Left Hand	20	W10709365	Screw			Assembly, Inner Air Tunnel (Includes Gasket)
	W11032620	Right Hand	21		Divider, Air	38		
11	W10673840	Screw (Stainless)		W10878918	Rear		W10835556	White
12		Cover, Top Hinge		W10878920	Bottom		W10835557	Black
		Left Hand	22		Grille, Toe	39	W10208592	Cover, Valve
		(Includes Foil)		W10821307	White	40	W11243631	Gasket
	W10895447	White		W10821308	Black	41	12990702	Screw
	W10868791	Black	23	12992601	Screw			
			24	W10831587	Bushing			
			25	W10141645	Screw			
			26	12990511	Screw			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	16	W10839501	Insulation, Under Filter	29	W10818463	Gasket, Evaporator Air Dam
2	W10708473	Housing, Water Tank	17	W10766881	Assembly, Air Filter	30	W10901792	Gasket, Sealing
3	W10921470	Gasket, Heat Shield	18	W10704470	Cover, Air Filter	31	W11396537	Assembly, Manifold Jumper Wire
4	W11024082	Reservoir, Water	19	W11090564	Assembly, Heat Shield	32	W11127384	Heater, Defrost
5	W11490564	Valve, Dual Water	20	W10719253	Cap, Filter	33	10623002	Clip, Evaporator
6	W11024083	Housing, Water Filter	21	W11327993	Assembly, Evaporator Cover (Includes Fan Motor, Wire Assembly and Thermistor)	34	W11307147	Cover, Filter
7	W10900010	Cover, Water Valve						FOLLOWING PARTS NOT ILLUSTRATED
8	W10789102	Tube, Water Filter	22	W11130330	Assembly, Evaporator	W10871610		Assembly, Valve Wire
9	W10718061	Cover, Cooling Duct	23	W11391988	Assembly, Side Lamp			
10	W11259413	Cover, Tower	24	W10831305	Insulator, Foam			
11	W10680605	Filter, Water	25	W10716179	Base, Tower Cover			
12	W10315189	Filter, Air	26	W10909562	Clip, Evaporator Heater			
13	W10708474	Bracket, Filter	27	12990501	Screw			
14	W10119266	Screw	28	W10877761	Heater, Filter			
15	12990518	Screw						


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	9	W10683507	Clip, Defrost Heater	16	B8381501	Gasket, Drain
2	W11032200	Assembly, Evaporator	10	W10683540	Gasket, Drip Tray Rear	17	W10797088	Thermistor
3	W11228040	Assembly, LED Light Module	11	W10668191	Shield, Heat	18	W10770923	Seal, Crisp Front
4	W11209447	Assembly, Evaporator Cover (Includes Fan Motor and Wire Assembly)	12	W10668201	Dam, Air Left Hand	19	W11206828	Assembly, Icebox Fan
5	12990511	Screw		W10668198	Right Hand	20	W10911358	Assembly, Evaporator Jumper Wire
6	W10668195	Heater, Defrost	13	W11396530	Assembly, Evaporator Heater Wire (Includes Thermistor)			
7	W10847853	Switch, Light	14	W10503218	Assembly, Drain Funnel			
8	10623002	Clip, Evaporator	15	M0500703	Seal			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	7	12990204	Screw	18	W11227915	Assembly, User Interface
		Left Hand	8		Handle, Door	19	W10720073	Gasket, Cooling Duct
	W10882867	White (Also order item # 18)		W11025073	White	20		Bin, Door
	W10882869	Black (Also order item # 18)	9	W11032814	Switch, Rocker Arm		W10697272	Gallon, Half
2		Door, Refrigerator	10		Bumper, Door	21	W10883965	Tube, Water
		Right Hand		W10407175	White	22		Gasket, Door
	W10882872	White		W10407187	Black		W10917311	White
	W10882871	Black	11	W10884773	Badge		W10917312	Black
3	W10238319	Screw	12	W11328753	Screw	23	W10917894	Assembly, Fill Tube (Icemaker)
4	W11554921	Assembly, Ice Door	13	W10697307	Trivet, Ice Compartment Door	24	W10010140	Set Screw (Silver)
5	W10763415	Bracket, Door Stop	14		Bin, Door	25		Closer, Door
6		Mullion, Door		W10883264	Medium		W10714907	Left Hand
	W10920944	White	15	W10720065	Retainer, Door Duct		W10714908	Right Hand
	W11034029	Black	16	W10853439	Gasket, Ice Door			
			17	W11315302	Clip, Tube			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Door Gasket)	5		Adapter Assy-FC.Slide	12	489443	Screw (Stainless)
	W11043903	White		W11114790	Left Hand	13	W10874021	Roller, Pan
	W11043904	Black		W11114789	Right Hand	14		Stop, Pan
2		Handle, Door	6	W10795850	Assembly, Bottom Pan		W10485096	Left Hand
	W11025097	White	7	12990518	Screw		W10485089	Right Hand
	W11025096	Black	8	W11128244	Assembly, Top Pan	15		Gasket, Door
3	W11328753	Screw	9	W10277361	Collar, Gear		W11563146	White
4	W10851956	Shaft, Rack	10	W10643690	Axle, Roller		W11563147	Black
			11	W10469177	Support, Pan	16	W10697812	Bar, Support


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw	16	W11199416	Condenser	31	W11323726	Tube, Process
2	W10820084	Screw	17	W10391376	Bracket, Valve	32	2223913	Clip
3	W10658357	Baseplate	18	W11198954	Cover, Housing	FOLLOWING PARTS NOT ILLUSTRATED		
4	12990511	Screw	19	W10141645	Screw			
5	W10860180	Assembly, Drain Extension	20	W10792503	Filter, EMI	978025		Valve, Access (1/4")
6	W11084143	Assembly, 3 Way Valve	21	W10701009	Cover, Terminal	978026		Valve, Access (5/16")
7	W10838081	Pad, Sound	22	2169104	Insulation, Sound Deadening	978027		Valve, Access (3/8")
8	W10877573	Tray, Evaporator	23	W11199420	Assembly, Suction Tube	978029		Valve, Access (5/8")
9	W10884826	Grommet, Condenser	24	W11396531	Harness, Unit (Condenser Fan)	978030		Valve, Access (3/4")
10	W10697007	Bolt	25	W10805035	Drier (Service Drier Without Dye)	876764		Valve, Access (3/16")
11	W10697017	Clip, Retaining	26	W11393142	Compressor	REFRIGERANT CHARGE		
12	W11317283	Assembly, Orion Box(Include Wiring Harness for Compressor and Power Cord)	27	W10883082	Assembly, Condenser Fan			
13	W10774846	Roller	28	12477202	Axle, Roller	4.50 oz. (R-134A)		
14	12992101	Screw	29	W10709318	Coil, 3 Way Valve			
15	W10836504	Grommet, Compressor	30	W10683708	Gasket, Condenser Fan			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10794287	Base, Pantry	12		Glide, Platter	19	3400065	Screw (Stainless)
2	W10717577	Handle		W10881160	Left Hand	20	W10878157	Frame, Crisper Cover
3	W11347066	Assembly, Filter Door		W10881121	Right Hand	21	W10804977	Screw
4	W10834719	Cover, Wiring Harness	13	W10779301	Assembly, Pantry Wire (Includes Thermistor)	22	W10881120	Glass, Platter
5	2223877	Latch, Push	14	W10878598	Glass, Crisper Cover	23	W10840918	Flange, Side Support
6	W10882961	Assembly, 15" Full Shelf	15		Glide, Crisper	24	W10840922	Knob, Side Support
7	W11165615	Assembly, 12" Full Shelf		W10892559	Left Hand	25	W10880762	Assembly, Center Support
8	W10883831	Assembly, Tuck Shelf		W10892561	Right Hand	26	W10758351	Bar, Support
9		Assembly, Block	16	W10794252	Left Hand	27	W10792132	Insulation, Filter Housing
	W10753430	Front Left/Back Right		W10794258	Right Hand	28	W10794289	Support, Pantry
	W10753431	Front Right/Back Left	17		Assembly, Crisper Pan	29	W10878186	Cover, Pantry
10	W10881589	Pan, Pantry		W10881536	Left Hand			
11	W10881141	Assembly, Platter Shelf		W10881531	Right Hand			
			18	W10901221	Assembly, Light			



DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	7		Tray, Dispenser Slide	15	W10696713	Gasket, User Interface Adapter
2	W11225783	Assembly, Triton User Interface		W11026724	White	16	W10696704	Assembly, Ice Door Motor Bracket
				W11026725	Black			
3		Wall, Dispenser False	8		Ring, Trim	17	W10663699	Pad, Sound
	W10879586	White		W10757512	Chrome	18	W10752689	Heater, Dispenser
	W11085969	Black	9		Paddle, Ice Dispenser	19	W10882291	Gasket, Foam
4		Paddle, Water Dispenser		W10672575	Silver	20	W10680037	Arm, Water Paddle
				W11102448	Black	21	W10864907	Foil, Dispenser Well
	W10678156	Silver	10	W10403752	Switch, Limit	22	W10831765	Gasket, Dispenser Trim
	W11102429	Black	11	W10672578	Spring, Torsion			
5		Seperator	12	W10663682	Spring, Torsion			
	W11085970	White	13	W10704135	Assembly, Paddle Jumper Wire			
	W11086000	Black	14	W10757499	Bracket, User Interface Adapter			
6		Tray, Drip						
	W10757513	Chrome						

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw	5	W11363574	Shaft-Motor	7	8281163	Screw (Stainless)
2	W10682175	Plate, Ice Chute	6	W11185741	Motor, Dispenser	8	W11026493	Assembly, Icemaker
3	W10291905	Gasket						
4	W10903433	Assembly, Ice Container						

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key