




MICROWAVE

MODELS:

KMBD104GSS02 (Stainless)


DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W11646236	Hook, Left Latch	17	W11201777	Gear, Drawer
	W11103357	Installation Instructions	7	W11646237	Spring, Latch	18	W10278647	Screw
	W11103355	Use and Care Guide	8	W11646234	Hook, Right Latch	19	W11209971	Panel, Door
	W11109162	Cooking Guide (English)	9	W11201775	Slide, Drawer			FOLLOWING PARTS NOT ILLUSTRATED
	W11101482	Tech Sheet	10	8205835	Screw	W11199540		Cord, Power
2	W11214965	Tray, Oven	11	W11199897	Stopper, Door	W11362536		Harness, Main
3	W11201390	Cover, Support	12	W10278632	Screw			
4	W11201870	Cover, Choke	13	W10278889	Nut			
5	W11315618	Assembly, Drawer	14	W11209960	Support, Side			
			15	W11201804	Piston, Door Stop			
			16	W11201393	Support, Bottom			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8205835	Screw	3	W11199889	Bracket, Panel	6	W11330996	Control, Electronic
2	W11199895	Harness, Touch Control	4	8185369	Screw	7	W11199896	Wire, Ground
			5	W11199894	Cushion, Control	8	W11209952	Panel, Control


OVEN CAVITY PARTS



OVEN CAVITY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11199864	Bushing, Power Cord	11	W11201748	Holder, Relay	21	W11201789	Cover, Stirrer
2	W10278632	Screw	12	W11209950	Bracket, Left	22	W11362541	Clip, Cover
3	W11199863	Bracket, Power Cord	13	W11199547	Cut-Out, Thermal	23	W11201857	Panel, Bottom Partition
4	W10278891	Screw	14	W11362534	Motor, Stirrer	24	W11201855	Glass, Lamp
5	W11201389	Cover, Rear	15	W11201787	Bracket, Control Panel	25	W11362542	Shaft, Stirrer Motor
6	W11199812	Case, Outer	16	W11363045	Bracket, Right	26	W10278721	Screw, Wood
7	W11201800	Panel, Partition	17	W11209962	Cover, Faceplate	27	W11199861	Cover, Latch
8	8185369	Screw	18	W11201790	Cover, Lamp			
9	W11199539	Relay, Power	19	W10278184	Assembly, Lamp			
10	8205835	Screw	20	W11362539	Blade, Stirrer			

SWITCH PARTS




SWITCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11199805	Microswitch
2	8185326	Screw
3	W11201860	Latch, Door (Left)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W11201858	Latch, Door (Right)
5	W11305909	Switch, Monitor

INTERIOR PARTS




INTERIOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11362533	Motor, Fan
2	W11199545	Filter, Noise
3	W11315605	Fuse (20A)
4	W11201861	Cushion, Fan Motor Support
5	W11331002	Duct, Magnetron

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W11201793	Cushion, Inlet
7	W11301135	Magnetron
8	W11201852	Duct, Sensor
9	W10278023	Assembly, Sensor
10	W11201803	Cushion, Duct
11	W10278632	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W11201854	Duct, Exhaust
13	W11201796	Cushion, Exhaust Duct
14	W11201802	Cushion, Air Flow
15	W11199810	Assembly, Drawer Gear

BASE PLATE PARTS



BASE PLATE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11199538	Supply. Power	5	W11201396	Bracket, Capacitor	8	W11202128	Cover, Waveguide
2	8185369	Screw	6	W11201794	Cushion, Transformer	9	W10278632	Screw
3	W11201745	Holder, Control	7	W11199548	Transformer, High Voltage	10	W11201391	Plate, Base
4	W11362530	Capacitor, High Voltage				11	8205835	Screw