




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR Fingerprint Resistant

MODELS:

KRFF507HBS04 (Black Stainless)

KRFF507HPS04 (Stainless Steel)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts Tech Sheet	11	W10673842	Screw (Black)	22		Grille, Toe
	W11590311	English		W10673840	Screw (Stainless)		W10637669	Black
	W11590312	French	12	W10415341	Gasket, HV Box		W10637671	Grey
	W11502338	Owners Manual	13	W10141645	Screw	23	12992601	Screw
	W11223076	Energy Guide	14	W10731474	Screw	24	W10768379	Lid, HV
2	W11161172	Board, Control	15		Hinge, Center	25	W10336736	Cover, Roller
3	W10344432	Block, Pivot		W10248705	Black	26	12990511	Screw
4	549193	Clamp, Power Cord		W10248706	Grey	27	W11296599	Tube, Water
5		Cover, Top Hinge Left Hand (Includes Foil)	16		Hinge, Center Right Hand	28	W10754144	Cover, Control Box
	W10471617	Black		W10248702	Black	29	W10847853	Switch, Light
	W10471618	Grey		W10248703	Grey	30	W11364644	Assembly, Unit Cover
6		Cover, Top Hinge Right Hand	17		Cover, Corner	31	M0108107	Clamp, Tube
	W10407157	Black		12587703B	Black	32	12990302	Screw
	W10407158	Grey		12587703AP	Grey	33	W10505294	Coupler, Door
7	A3076901	Plug, Button	18	W11460084	Valve, Water	34	W10212137	Retainer, Door
8	W10141622	Brake, Roller	19		Assembly, Roller	35		Cabinet (Not a Servicable Part)
9	12992602	Screw		W10515763	Left Hand	36	W11534848	Gasket
10		Hinge, Top		W10515762	Right Hand			
	W11456644	Left Hand	20	W10709365	Screw			
	W11456643	Right Hand	21	12990702	Screw			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10706850	Heater, Fill Tube	29	W10280988	Gasket, Rear Supply
2	W11281629	Housing, Water System	15	12990518	Screw	30	W10635022	Adapter, Icebox
3	W11306460	Tube, Fill	16	W10598013	Cover, Icebox	31	W11234022	Harness, LED Wire (Includes LED lights)
4	W11296598	Reservoir, Water (Also Order Wire Tie Part 8567668)	17	W11547436	Assembly, Icebox (Foamed)	32	W11229041	Assembly, LED Module
5	W11255718	Valve, Dual Water	18	W10530312	Cover, Damper	33	W10479155	Damper, Control
6	W11293954	Housing, Water Filter	19	W11125218	Cover, Air Diffuser	34	W10438957	Cover, Thermistor
7	W11391457	Enclosure, Water Valve	20	W10505516	Trim, Icebox	35	W10320706	Gasket, Rear Return
8	W10669663	Cover, Waterbox	21	W10833801	Fan, Icebox			FOLLOWING PARTS NOT ILLUSTRATED
9	2223877	Latch, Push	22	W11175631	Locking Ring (5/16)			
10	W10277949	Door, Filter Access	23	W10392172	Gasket, Fan		W11306925	Harness, Dual Valve
11	W10680605	Filter, Water	24	W11369503	Wire Assembly, Jumper		W11298842	Wire Assembly, Ice Box
12	W10315189	Filter, Air	25	W10553630	Assembly, Fascia (Includes Heater)			
13	W11517687	Waterline, Valve to Hinge	26	W10847853	Switch, Light			
			27	W11373777	Assembly, Air Tower			
			28	W10280983	Insulation			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	12990504	Screw	14	W10503218	Assembly, Drain Funnel
2	A3189392	Gasket, Foam	9	W10496613	Grille, Air (Freezer)	15	M0500703	Seal
3	W11228040	Assembly, LED Light Module	10	W10363507	Shroud, Evaporator Fan	16	B8381501	Gasket, Drain
4	W11408170	Cover, Evaporator (Freezer)	11	12986101	Blade, Fan	17	W10405166	Cover, Thermistor
5	12990511	Screw	12	12951101	Grommet, Fan Motor	18	W10531268	Gasket, Dual Evaporator
6	12956601	Clip, Fan Motor	13	W11402610	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)	19	W10280385	Thermistor
7	W10847849	Switch, Light						


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	6		Mullion, Door	18	W10518658	Board, Receiver Circuit
		(Includes Door Gasket)		W10698196	Black	19	W10258510	Cover, Receiver
		Left Hand	7	12990204	Screw	20	2198635	Spring, Door
	W11405207	Black Stainless	8		Handle, Door	21	W10258502	Cover, Emitter
	W11405209	Stainless Steel		W11339138	Stainless	22	W10258540	Slide, Icemaker Shut Off
2		Door, Refrigerator	9	12990504	Screw	23	W10832970	Board, Emitter Circuit
		(Includes Door Gasket)	10		Bumper, Door	24	W10400825	Retainer, Ice Chute
		Right Hand		W10407187	Black	25	W10347087	Gasket, Ice Chute
	W11036468	Black Stainless		W10407188	Grey	26	W10646855	Vent, Thermistor
	W11377901	Stainless	11	W10394073	Tube, Water	27	W10791180	Bucket, Gallon
3	W10238319	Screw	12	W11328753	Screw	28		Gasket, Door
4		Latch, Door	13	W10791182	Trivet, 2 Liter		W10873939	Black
	W10712952	Left Hand	14	2198634	Pin, Door		W10873938	Grey
5		Latch, Door	15	489214	Screw	29	W10258520	Door, Emitter
	W10712953	Right Hand	16	W10347085	Gasket, Ice Compartment Door	30	W11249249	Door, Ice
			17	W11315302	Clip, Tube			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Door Gasket)	6	W10594047	Assembly, Lower Pan	14	W10469177	Support, Pan
	W11024129	Black Stainless	7	12990518	Screw	15	489443	Screw (Stainless)
	W11377893	Stainless	8	W10704090	Bin, Upper	16		Nameplate
2		Handle, Door	9	W10709748	Clip, Shaft		W10765861	Grey
	W11222205	Stainless	10	W10507444	Divider, Lower	17	W10248555	Roller, Pan
3	W11328753	Screw	11		Gasket, Door	18	W10643690	Axle, Roller
4	W10503522	Shaft		W10248748	Black			
5		Assembly, Bracket		W10248749	Grey			
	W10795770	Left Hand	12		Stop, Pan			
	W10795768	Right Hand		W10485096	Left Hand			
				W10485089	Right Hand			
			13	W10485654	Divider, Upper			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141518	Screw	18	W11408656	Tray, Drip	26	W11545349	Compressor
2	2188935	Blade, Fan	19	W10174384	Strap, Bale			(Also Order the Following Lokring Parts)
3	W11411853	Baseplate, Compressor	20	W11394386	Assembly, Evaporator			
4	12990511	Screw			(Also Order the Following Lokring Parts)	W11504431	7/5 NR MS 00	(Compressor to Condenser)
5	W10776917	Extension, Drain		W11506620	8 NK AL 00	W11504415	8.5/8 NR MS 00	(Suction Tube to Compressor)
6	2169104	Insulation, Sound Deadening			(Suction Line to Evaporator)	W11506621	6 NK MS 00	(Charging Tube to Compressor)
7	W10303521	Sleeve		W11504450	4/1.8 NR MS 00			
8	W10660727	Tray, Evaporator			(Capillary Tube to Evaporator)	W11506635	Tube, Charging (1/4" w/ Schrader Valve)	
9	W10622701	Screw	21	2223913	Clip	27	W10142294	Screw
10	W11553968	Heater, Defrost	22	W10909387	Motor, Condenser Fan	28	12477202	Axle, Roller
11	W11541370	Device, Combination Start (Start Relay and Overload)	23	W11380964	Clip, Heater	29	W10406719	Shroud
12	W10248621	Clip, Condenser	24	W11306948	Harness, Unit (Includes Power Cord)	30	W10738415	Cord, Power
13	12477102	Roller	25	W10805035	Drier (Service Drier Without Dye)	31	W10278140	Cover, Condenser (Bottom)
14	12992101	Screw			(Also Order the Following Lokring Parts)	32	W10815861	Clip, Bottom Cover
15	10835903	Grommet		W11504445	5/4 NR MS 00	33	W10141625	Screw
16	W11411956	Condenser			(Heat Loop to Drier)	34	W11323444	Tube, Suction
		(Also Order the Following Lokring Parts)		W11504447	5/1.8 NR MS 00	35	W11417341	Screw
	W11504445	5/4 NR MS 00			(Capillary Tube to Drier)	36	W10281329	Clip, Drier
		(Heat Loop to Condenser)						REFRIGERANT CHARGE
	W11504431	7/5 NR MS 00						56 grams (R600a)
		(Compressor to Condenser)						
17	W10350564	Capacitor						

SHELF PARTS



SHELF PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10789433	Front, Pantry
2	W10530317	Plate, Slide Center
3	W11124673	Support, Pantry
4	W10248516	Ladder, Center
5	W10893769	Glass, Pantry
6	W10847999	Screw
7	W10624433	Pan, Crisper
8	W10737427	Shelf, Tuck
9	W10789490	Front, Crisper
10	W10654844	Pan, Pantry
11	W10756310	Shelf, Fixed
12	W10512596	Knob, Pantry Temperature Control
13	W10372170	Ladder, Side
14	W10893773	Glass, Crisper
15	W11133643	Cover, Crisper


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
16		Rail, Side
	W11133647	Left Hand
	W11133648	Right Hand
17	W10467416	Plate, Pantry Front
18		Plate, Side Pantry
	W10498906	Left Hand
	W11124810	Right Hand
19		Slide, Pantry
	W10499289	Left Hand
	W10499294	Right Hand
20	W10432697	Insulation, Sideplate
21		Plate, Crisper
	W11315181	Left Hand
	W11315180	Right Hand
22	W10530316	Plate, Side
23	W10467415	Plate, Crisper Front

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10530307	Track, Center
25	W10248819	Slide, Crisper
26	12990518	Screw
27	W10530315	Support, Crisper
28	W10423560	Screw
29	W11457209	Assembly, Platter Shelf
30	W11169584	Glass, Platter
31	W11124643	Assembly, Pantry Front Cover
32	W10554285	Cover, Pantry Top
33	W11210629	Housing, Pantry Temperature Control
34	W10248856	Bucket, Gallon


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10394101	Assembly, Separator	11	W10542708	Grate, Drip Tray
2		Assembly, User Interface	6	W10238083	Assembly, LED	12	W10205979	Motor, Ice Door
	W11501508	Black	7	W10606117	Assembly, Ice Door			
3		Wall, Dispenser False	8		Insert, Drip Tray			
	W10486344	Black		W10400889	Black			
	W10486346	Grey		W10402269	Grey			
4		Assembly, Pad	9	W10435760	Guide, Ice			
	W10317253	Black	10		Tray, Dispenser			
	W10346924	Grey		W10400884	Black			
				W10400887	Grey			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10347055	Plate, Ice Chute
3	2198628	Seal
4	W10347120	Clip, Retainer
5	W11363576	Shaft, Motor

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W11185741	Motor, Dispenser
7	8281163	Screw (Stainless)
8	W10347093	Assembly, Ice Container

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10291905	Gasket
10	W11485529	Assembly, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10134625	Apollo Grey
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key