




GAS DRYER

MODELS:

WGD4616FW3 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	688983	Screw	15	3389682	Spacer, Toe Panel
	W11361424	Owners Manual	9		Top	16	W11523109	Harness, Main
	W11355746	Quick Start Guide		8559800	White	17	W10112578	Bracket, Harness
	W10876312	Wiring Diagram	10		Knob, Push To Start	18	W10112603	Seal, Harness
	W11366444	Cycle Guide		W10453947	White	19	W10316616	Seal, Foam
2	693995	Screw	11	W10436302	Timer Assembly (60 Hz.)	20	W10298336	Nut, "U"
3	8312709	Clip, Console			Assembly, Console	21	W10420747	Switch, Rotary
4	W10416486	Panel, Rear Console	12			22	694419	Buzzer, Mini
5		Lint Screen		W10862185	White	23	3348629	Screw
	W11451394	White	13		Assembly, Timer Knob			
6	8536939	Clip, Spring		W10711289	White			
7	90767	Screw	14	W10446920	Switch, Push to Start			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8066217	Hinge, Top	16	W10561321	Foot, Dryer	29	W10396029	Assembly, Motor
2	343641	Screw		W10570316	Foot - Package of 4 (Not Included)	30	3400500	Bolt
3	693995	Screw				31	348780	Base, Motor
4	W10841728	Seal, Spill Guard	17	W10773242	Screw	32	W10131364	Belt, Drive
5	8558833	Cover, Terminal Block	18		Cabinet	33	W11224633	Strike, Door
6	3404162	Clamp, Motor (With Shield)		8530603	White	34	691366	Idler Assembly
7	W11598681	Panel, Rear	19	98234	Clip, Ground	35	W10463967	Door, Inner
8	W10567345	Plug, Strike	20	8066092	Lock, Front Top	36		Door, Front
9		Plug, Front Panel	21		Panel, Front		W10714510	White
	8564457	White		W10664698	White	37		Handle, Door
10	W10569603	Switch, Door	22	8066184	Pulley, Motor		W10714516	White
11	697773	Screw	23	685203	Clip, Felt Pad	38	W10803476	Assembly, Seal and Bearing
12		Hinge Hole Cover	24	W11224630	Assembly, Door Catch	39	W10727507	Clamp, Pipe
	W11308618	White	25	W10730752	Seal, Door	40	W10529198	Cover, Door Catch
13	W10121316	Clamp, Motor Mount	26	W10869141	Cord, Power	41	W10529197	Bezel, Door Catch
14	341029	Clamp, Pipe	27	342055	Screw	42	W11564940	Burner Assembly (60 Hz) (Type 1)
15	W10775448	Clip, Front Panel	28		Assembly, Hinge and Pin			
				W10362431	White			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	16	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	29	W10298789	Nut, Hex
2	489463	Screw	17	3390647	Screw	30	W10714468	Rear Bulkhead
3	3388703	Washer	18	8066049	Funnel, Burner	31	338906	Sensor, Radiant
4	347139	Seal, Lint Chute	19	W10214261	Socket, Light	32	3402841	Lens, Drum Light
5	90767	Screw	20	3406124	Bulb, Light	33	692526	Bearing, Ring
6	W10389567	Shield, Exhaust	21	8578825	Bracket, Drum Light	34	W10219342	Screw
7	3392519	Fuse, Thermal (91C)	22	90296	Nut, Push On	35	W10856781	Seal, Rear Drum
8	3403636	Baffle, Drum (Short)	23	339956	Seal	36	W10757750	Assembly, Drum (Complete)
9	3387134	Thermostat	24	W10512946	Washer, Tri Ring	37	692490	Baffle, Drum (Long)
10	694089	Wheel, Blower	25	W10359270	Shaft, Drum Roller - Left Hand Thread	38	W11032820	Bracket, Support
11	8577230	Housing, Blower	26	W10359269	Shaft, Drum Roller - Right Hand Thread			
12	3398161	Clip, Heater Box	27	3397590	Roller, Support			
13	3390631	Screw	28	348197	Washer			
14	8530285	Box, Heater (96C)						
15	W10754607	Thermostat, High Limit SPST (180F)						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564940	Burner Assembly (60 Hz) (Type 1)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9		Orifice, Burner			
4	686590	Ignitor		234826	Type 1 (Natural)	W11581316		Kit, LP Conversion
5	W10366705	Screw	10	W11564943	Valve, Gas (60 Hz)			
6	343641	Screw	11	W10295523	Pipe Plug			
			12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

279948	Kit, Dryer Repair
3406839	Dry Rack
8522199	Kit, Dryer Vent Testing