




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

KRFF507HWH00 (White)

KRFF507HBL00 (Black)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts Tech Sheet	12		Cover, Top Hinge Left Hand	19		Assembly, Roller
	W11203256	English		W10471615	White		W10515763	Left Hand
	W11203267	French		W10471617	Black	20	W10709365	Right Hand
	W11218735	Use and Care Guide			Right Hand	21	12990702	Screw
	W11223076	Energy Guide		W10248562	White	22		Grille, Toe
2		Cabinet (Not a Servicable Part)		W10407157	Black		W10637668	White
3	W10344432	Block, Pivot	13	W10141645	Screw		W10637669	Black
4	W10505487	Gasket	14	W10731474	Screw	23	12992601	Screw
5	W11161172	Board, Control	15		Hinge, Center	24	W10768379	Lid, HV
6	W10415341	Gasket, HV Box		W10248434	White	25	W10141645	Screw
7	A3076901	Plug, Button		W10248705	Black	26	12990511	Screw
8	W10141622	Brake, Roller			Right Hand	27	W10913008	Tube, Water
9	12992602	Screw		W10248433	White	28	W10754144	Cover, Control Box
10		Hinge, Top		W10248702	Black	29	W10847849	Switch, Light
	W10248410	Left Hand	16	W10336736	Cover, Roller	30	W10577369	Cover, Unit
	W10248409	Right Hand	17		Cover, Corner	31	M0108107	Clamp, Tube
11	W10673841	Screw (White)		12587703W	White	32	12990302	Screw
				12587703B	Black	33	W10505294	Coupler, Door
			18	W10394076	Valve, Water	34	W10212137	Retainer, Door
						35	549193	Clamp, Power Cord


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13	W10674102	Waterline, Valve To Hinge	25	W10553630	Assembly, Fascia (Includes Heater)
2	W10826118	Housing, Water System	14	W10706850	Heater, Fill Tube	26	W10847853	Switch, Light
3	W10736144	Tube, Fill	15	12990518	Screw	27	W11124428	Assembly, Air Tower
4	W10711460	Reservoir, Water (Also Order Wire Tie Part 8567668)	16	W10598013	Cover, Icebox	28	W10280983	Insulation
5	W10341329	Valve, Dual Water	17	W10811686	Assembly, Icebox (Foamed)	29	W10723352	Waterline
6	W11165806	Housing, Water Filter	18	W10280988	Gasket, Rear Supply	30	W10635022	Adapter, Icebox
7	W10811115	Enclosure, Water Valve	19	W10320706	Gasket, Rear Return	31	W10722983	Connector, Water Tube
8	W10669663	Cover, Waterbox	20	W10505516	Trim, Icebox	32	W10713934	Bracket, Connector
9	2223877	Latch, Push	21	W10833801	Fan, Icebox	33	W10479155	Damper, Control
10	W10277949	Door, Filter Access	22	W10843339	Assembly, LED Module	34	W10438957	Cover, Thermistor
11	W10680605	Filter, Water	23	W10392172	Gasket, Fan	35	W10530312	Cover, Damper
12	W10315189	Filter, Air	24	W10843828	Harness, LED Wire (Includes LED lights)	36	W11125218	Cover, Air Diffuser


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	12990504	Screw	14	W10503218	Assembly, Drain Funnel
2	A3189392	Gasket, Foam	9	W10496613	Grille, Air (Freezer)	15	M0500703	Seal
3	W10843353	Assembly, LED Light Module	10	W10363507	Shroud, Evaporator Fan	16	B8381501	Gasket, Drain
4	W10513424	Cover, Evaporator	11	12986101	Blade, Fan	17	W10405166	Cover, Thermistor
5	12990511	Screw	12	12951101	Grommet, Fan Motor	18	W10531268	Gasket, Dual Evaporator
6	12956601	Clip, Fan Motor	13	W11215582	Motor, Evaporator (Includes Harness, Thermistor, and Defrost Thermostat)	19	W10280385	Thermistor
7	W10847853	Switch, Light						

REFRIGERATOR DOOR PARTS




REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	W10624489	White
	W10561914	Black
2		Door, Right
	W10624492	White
	W10341282	Black
3	W10238319	Screw
4	W11176526	Door, Ice
5		Latch, Door
	W10712952	Left Hand
	W10712953	Right Hand
6		Mullion, Door
	W10698195	White
	W10698196	Black
7	12990204	Screw
8		Handle, Door
	W10704121	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	12990504	Screw
10		Bumper, Door
	W10407175	White
	W10407187	Black
11	W10394073	Tube, Water
12	W10460893	Screw
13	W10791182	Trivet, 2 Liter
14	2198634	Pin, Door
15	489214	Screw
16	W10347085	Gasket, Ice Compartment Door
17	W10245516	Clip, Tube
18	W10518658	Board, Receiver Circuit
19	W10258510	Cover, Receiver
20	2198635	Spring, Door
21	W10258502	Cover, Emitter

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
22	W10258540	Slide, Icemaker Shut Off
23	W10832970	Board, Emitter Circuit
24	W10400825	Retainer, Ice Chute
25	W11134502	Gasket, Ice Chute
26	W10646855	Vent, Thermistor
27	W10791180	Bucket, Gallon
28		Gasket, Door
	W10873940	White
	W10873939	Black
29	W10258520	Door, Emitter


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	7	12990518	Screw	14	W10469177	Support, Pan
	W10708430	White	8	W10704090	Bin, Upper	15	489443	Screw (Stainless)
	W10708431	Black	9	W10709748	Clip, Shaft	16		Nameplate
2		Handle, Door	10	W10507444	Divider, Lower		W10765861	Grey
	W10736970	Stainless	11		Gasket, Door	17	W10248555	Roller, Pan
3	W10460893	Screw		W10587578	White	18	W10643690	Axle, Roller
4	W10503522	Shaft		W10248748	Black			
5		Assembly, Bracket	12		Stop, Pan			
	W10795770	Left Hand		W10485096	Left Hand			
	W10795768	Right Hand		W10485089	Right Hand			
6	W10594047	Assembly, Lower Pan	13	W10485654	Divider, Upper			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141518	Screw	16	W10627646	Assembly, Condenser	28	12477202	Axle, Roller
2	2188935	Blade, Fan	17	W10281329	Clip, Drier	29	W10406719	Shroud
3	W10570074	Baseplate	18	W10342573	Tray, Drip	30	W10738415	Cord, Power
4	12990511	Screw	19	W10141625	Screw	31	W10278140	Cover, Condenser (Bottom)
5	W10776917	Extension, Drain	20	W10248589	Assembly, Evaporator	32	W10815861	Clip, Bottom Cover
6	2169104	Sealer, Insulation	21	W10350564	Capacitor	33	W10491355	Gasket, Airdam
7	W10303521	Sleeve	22	W10909387	Motor, Condenser Fan	34	W10463542	Tube, Suction
8	W10660727	Tray, Evaporator	23	10428101	Clip, Heater	35	W10236396	Strap, Compressor
9	W10622701	Screw	24	W11171078	Harness, Unit (Includes Power Cord)	36	W10650382	Strap, Bale
10	12729128	Heater, Defrost	25	W10177049	Drier			REFRIGERANT CHARGE
11	W10796752	Device, Start	26	W10391109	Compressor (Also Order 876765 Tube Kit)			5.50 oz. (R-134A)
12	W10248621	Clip, Condenser	27	W10142294	Screw			
13	12477102	Roller						
14	12992101	Screw						
15	10835903	Grommet						

SHELF PARTS



SHELF PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10789433	Front, Pantry
2	W10530317	Plate, Slide Center
3	W11124673	Support, Pantry
4	W10248516	Ladder, Center
5	W10893769	Glass, Pantry
6		Rail, Side
	W11133647	Left Hand
	W11133648	Right Hand
7	W10624433	Pan, Crisper
8	W10737427	Shelf, Tuck
9	W10789490	Front, Crisper
10	W10654844	Pan, Pantry
11	W10756310	Shelf, Fixed
12	W11133656	Assembly,Platter Shelf
13	W10372170	Ladder, Side


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10893773	Glass, Crisper
15	W11133643	Cover, Crisper
16	W10512596	Knob, Pantry Temperature Control
17	W10467416	Plate, Pantry Front
18		Plate, Side Pantry
	W10498906	Left Hand
	W11124810	Right Hand
19		Slide, Pantry
	W10499289	Left Hand
	W10499294	Right Hand
20	W10432697	Insulation, Sideplate
21		Plate, Crisper
	W10530318	Left Hand
	W10530306	Right Hand

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
22	W10530316	Plate, Side
23	W10467415	Plate, Crisper Front
24	W10530307	Track, Center
25	W10248819	Slide, Crisper
26	12990518	Screw
27	W10530315	Support, Crisper
28	W10423560	Screw
29	W11169584	Glass, Platter
30	12990204	Screw
31	W11124643	Assembly, Pantry Front Cover
32	W10554285	Cover, Pantry Top
33	W11210629	Housing, Pantry Temperature Control
34	W10248856	Bucket, Gallon


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10394101	Assembly, Separator	11	W10542708	Grate, Drip Tray
2		Assembly, User Interface	6	W10238083	Assembly, LED	12	W10205979	Motor, Ice Door
	W11171229	Black	7	W10606117	Assembly, Ice Door			
			8		Insert, Drip Tray			
3		Wall, Dispenser False		W10347142	White			
	W10486345	White		W10400889	Black			
	W10486344	Black	9	W10435760	Guide, Ice			
4		Assembly, Pad	10		Tray, Dispenser			
	W10317250	White		W10347140	White			
	W10317253	Black		W10400884	Black			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10347055	Plate, Ice Chute
3	2198628	Seal
4	W10347120	Clip, Retainer
5	W10347114	Shaft, Motor

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10215646	Motor, Dispenser
7	8281163	Screw (Stainless)
8	W10347093	Assembly, Ice Container

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10291905	Gasket
10	W11109572	Assembly, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	W10917540	Midnight Grey
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key