




**ELECTRIC RANGE**  
**(Even-Heat True Convection)**

**MODELS:**

KSIS730PSS0 (Stainless)


# COOKTOP AND DUCT PARTS



# COOKTOP AND DUCT PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u>     | <u>Part No.</u> | <u>Description</u>          |
|-----------------------------|-----------------|-----------------------------------|-----------------------------|-----------------|-------------------------------|---------------------------------|-----------------|-----------------------------|
| 1                           |                 | Literature Parts                  | 10                          | 7101P485-60     | Screw, Anti-Tip Kit           | 20                              | W11616082       | Spring (Cantilever)         |
|                             | W11637353       | Use and Care Guide                | 11                          | W11379947       | Bracket, Anti-Tip             | 21                              | W10598048       | Bracket, Console (Center)   |
|                             | W11637366       | Tech Sheet                        | 12                          | W10162253       | Brace, Corner (Left)          | 22                              | W10558372       | Bracket, Control            |
|                             | W11637354       | Quick Start Guide                 |                             | W10162252       | Brace, Corner (Right)         | 23                              | W11355689       | Keypad Shield               |
|                             | W11637361       | Dimension Guide                   | 13                          | W10289169       | Support, Cooktop (Right)      | 24                              | W10612719       | Gasket, Console and Cooktop |
| 2                           |                 | Console, Lower Panel              |                             | W10289170       | Support, Cooktop (Left)       | FOLLOWING PARTS NOT ILLUSTRATED |                 |                             |
|                             | W10743276       | Stainless                         |                             |                 |                               | W11631333                       |                 | Harness, Main               |
| 3                           | 3196178         | Screw                             | 14                          |                 | Vent, Trim Top                | W11172426                       |                 | Harness, Display            |
| 4                           |                 | Cooktop                           |                             | W10636529       | Stainless                     | W10575120                       |                 | Harness, Keypad             |
|                             | W11625481       | Black                             | 15                          |                 | Endcap                        | 313438                          |                 | Clip, Harness               |
| 5                           | W11610925       | Pan, Induction (Lower)            |                             | W10555937       | Stainless (Left)              | W10653092                       |                 | Suppressor                  |
| 6                           | W11610960       | Assembly, Induction Side Duct     |                             | W10555940       | Stainless (Right)             | 7103P027-60                     |                 | Nut                         |
| 7                           | W11610945       | Duct, Recirculation Plate (Left)  | 16                          |                 | Console                       |                                 |                 |                             |
|                             | W11610944       | Duct, Recirculation Plate (Right) |                             | W11633376       | Black                         |                                 |                 |                             |
|                             |                 |                                   | 17                          | W10664705       | Bumper                        |                                 |                 |                             |
| 8                           | W10759325       | Assembly, Display                 | 18                          | W11636877       | Control, Electronic (Maxwell) |                                 |                 |                             |
| 9                           | W10555923       | Bracket, User Interface           | 19                          | 3196068         | Lens, Indicator               |                                 |                 |                             |


# INDUCTION ASSEMBLY PARTS



# INDUCTION ASSEMBLY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                      | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-----------------------------|-----------------|---------------------------------------------------------|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|------------------------------------|
| 1                           | W11683059       | User, Interface                                         | 6                           | W11683054       | Element, Induction | 8                           | W11683063       | Strain Relief, Cable               |
| 2                           | W11683057       | Assembly, Induction<br>Module                           |                             |                 | (Right Front)      |                             |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED |
| 3                           | W11683058       | Fan, Cooling                                            | 7                           | W11683056       | Element, Induction |                             | 313438          | Clip, Harness                      |
| 4                           | W11683061       | Locking Pin, User<br>Interface                          |                             |                 | (Right Rear)       |                             | W11683062       | Harness, UI to Module              |
| 5                           | W11683055       | Element, Induction<br><br>(Left Front and Left<br>Rear) |                             |                 |                    |                             | W11615923       | Harness, Induction<br>Cooktop      |
|                             |                 |                                                         |                             |                 |                    | 0                           |                 | Pan, Induction (Upper)             |


# CHASSIS PARTS



# CHASSIS PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-----------------------------|-----------------|----------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|------------------------------------|
| 1                           | W10289077       | Receiver, Hinge            | 22                          | 3196560         | Screw                        | 42                          | W10818358       | Shield, Wire                       |
| 2                           | W10362924       | Screw                      | 23                          | 3196178         | Screw                        | 43                          | W10624592       | Cord, Power                        |
| 3                           |                 | Panel, Side                | 24                          | W11544377       | Light Assembly               | 44                          | W10162260       | Shield, Heat                       |
|                             | W10162245       | Black                      | 25                          | W10571723       | Bulb, Halogen 40 Watts       | 45                          | W10162241       | Channel, Rear                      |
| 4                           | 3400029         | Nut                        | 26                          | 3400016         | Screw                        | 46                          | W10162248       | Cover, Wire                        |
| 5                           | W11491752       | Gasket, Door               | 27                          | W10586204       | Sensor                       | 47                          | W11379354       | Cover, Back                        |
| 6                           | W10544952       | Element, Broil             | 28                          | 3196169         | Screw                        | 48                          | W10603482       | Rack, Ladder                       |
| 7                           | W10774342       | Element, Bake              | 29                          | W10655441       | Shield, Power Cord           | 49                          | W10554007       | Rack, Steam                        |
| 8                           | W10362924       | Screw                      | 30                          | W10346153       | Baffle, Full Convection      | 50                          | W10645947       | Grommet                            |
| 9                           | W11122085       | Assembly, Flue             | 31                          | W10273192       | Rod, Door Switch             | 51                          | W11620269       | Bracket, Front Frame               |
| 10                          | W10289168       | Box, Burner SI             | 32                          | 9758701         | Spacer, Door                 | 52                          | W11510561       | Barrier Rail, Rubber (Front Left)  |
| 11                          | W10341186       | Front Foot Assembly        | 33                          | W10774446       | Bottom, Oven                 |                             | W11510562       | Barrier Rail, Rubber (Front Right) |
| 12                          | W10067840       | Screw                      | 34                          | W11511828       | Switch, Door                 | 53                          | W11661815       | Basket, Airfry                     |
| 13                          | W10541959       | Shield, Bake               | 35                          | W10281322       | Kit, Bare Wire Adapter Block |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED    |
| 14                          | W10137382       | Clip, Panel                | 36                          | W10554006       | Rack, Maximum Capacity       |                             | W10289173       | Insulation, Wrap                   |
| 15                          | W10390008       | Base Rail Assembly (Left)  | 37                          | W11353932       | Convection Assembly          |                             | W10655490       | Insulation, Main Back              |
|                             | W10390007       | Base Rail Assembly (Right) | 38                          | W10686408       | Kit, Reservoir (Steam Rack)  |                             | W10655442       | Insulation, Heat Shield            |
| 16                          | W10058460       | Foot, Leveling             | 39                          | W10273002       | Bracket, Oven Support        |                             | W10575374       | Insulation, Bottom                 |
| 17                          | 3196548         | Fuse, Thermal              | 40                          | W11379357       | Bake Pan                     |                             | 4820F015-59     | Insulation, Strap                  |
| 18                          | 3196172         | Screw                      | 41                          | W10911366       | Rack, Sliding                |                             | 7111P017-60     | Clamp, Wire                        |
| 19                          | W10035900       | Support, Oven Bottom       |                             |                 |                              |                             |                 |                                    |
| 20                          | 3186034         | Bracket, Service           |                             |                 |                              |                             |                 |                                    |
| 21                          | W10246624       | Block, Terminal            |                             |                 |                              |                             |                 |                                    |

# DOOR PARTS




# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    |
|-----------------------------|-----------------|-----------------------|
| 1                           | W11379948       | Glass Spacer          |
| 2                           |                 | Assembly, Door Handle |
|                             | W11669501       | Stainless             |
| 3                           | W10518672       | Badge                 |
| 4                           | W10826568       | Liner, Door           |
| 5                           | W10031790       | Screw                 |
| 6                           | W11223202       | Glass, Inner          |
| 7                           | W10885519       | Hinge, Door (Active)  |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          |
|-----------------------------|-----------------|-----------------------------|
| 8                           | W10541911       | Bracket, Glass Upper Handle |
| 9                           | W10813139       | Rail, Vertical Support      |
| 10                          | 9780274         | Screw                       |
| 11                          | W10813140       | Rail, Horizontal Support    |
| 12                          | W10031780       | Screw                       |
| 13                          | W10319024       | Washer, Door                |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 14                          |                 | Assembly, Outer Door |
|                             | W10634271       | Stainless            |
| 15                          |                 | Scoop, Door          |
|                             | W10613791       | Black                |
| 16                          | W11440161       | Bottom, Door Cover   |

# DRAWER PARTS



# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|---------------------|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|--------------------|
| 1                           |                 | Handle, Drawer      | 5                           | W10441804       | Slide, Drawer (Left)  | 6                           | 3196560         | Screw              |
|                             | W11669501       | Stainless           |                             | W10441805       | Slide, Drawer (Right) | 7                           | 3823F017-45     | Spacer, Handle     |
| 2                           | W10688022       | Drawer, Storage     |                             |                 |                       |                             |                 |                    |
| 3                           | W10318026       | Bracket, Mounting   |                             |                 |                       |                             |                 |                    |
| 4                           |                 | Panel, Drawer Front |                             |                 |                       |                             |                 |                    |
|                             | W10541954       | Stainless           |                             |                 |                       |                             |                 |                    |

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 72017           | White                   |
|                             | 72032           | Black                   |
|                             | 4392899         | Biscuit and Bisque      |
|                             | 511873          | White Porcelain (2 oz.) |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 285006          | Black              |
|                             | 4392901         | Biscuit and Bisque |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |

## REFINISHING MATERIAL

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-----------------------------|-----------------|---------------------------|
|                             | 242756          | Oven Liner Touch Up Paint |

## INSULATION

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-----------------------------|-----------------|----------------------------------|
|                             | 261514          | Insulation (1-1/2 x 24 x 120 in) |
|                             | 240132          | Insulation (2-1/2 x 22 x 120 in) |

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-----------------------------|-----------------|--------------------------------|
|                             |                 | CLEANERS AND POLISHES          |
|                             | 31605           | Kit, Cooktop Care              |
|                             | W10355051       | Cleaner, Cooktop               |
|                             | W10355016       | Cleaner, Stainless Steel       |
|                             | WA906B          | Scraper, Cooktop               |
|                             | W10432019       | Alt Cleaning Kit               |
|                             | W10391473       | Pad, Cooktop Cleaning          |
|                             |                 | MISCELLANEOUS                  |
|                             | 4396923         | Broiler Pan and Grid           |
|                             | W10123240       | Rack, Broiler Pan and Roasting |
|                             | W10432539       | Griddle                        |
|                             | W10432545       | Kit, Grill                     |
|                             |                 | TRIM KITS                      |
|                             | W10675026       | Black                          |
|                             | W10675027       | White                          |
|                             | W10675028       | Stainless                      |
|                             |                 | BACKSPLASH ASSEMBLY            |
|                             | W10655449       | Black                          |
|                             | W10655448       | White                          |
|                             | W10655450       | Stainless                      |