




GAS RANGE

MODELS:

KFGG500ESS7 (stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Cooktop	14		Bezel
	W11645717	Owners Manual		W10294800	Stainless		W10785119	Stainless (Kit of 5)
	W11645711	Quick Start Guide	6		Panel, Manifold			FOLLOWING PARTS NOT ILLUSTRATED
	W11565451	Tech Sheet		W10724442	Stainless			
2		Burner Cap Kit	7		Knob		W11461074	Harness, Main
	W10183374	Black		W10786063	Stainless		W10753750	Harness, Bake and Broil
3	W10067840	Screw	8		Grate Kit (Set of 2)			
4	W10515455	Assembly, Burner (17.5K)		W11241654	Black		W10809928	Harness, Cooktop
		(Left Front and Right Front)	9	3400701	Screw		W10334923	Clip, Gas Wiring
	W10515454	Assembly, Burner (9.5K)	10	W10289096	Bracket, Manifold (Left)		313438	Clip, Harness
		(Left Rear and Center)		W10106419	Bracket, Manifold (Right)		3196520	Clip, Wire
	W10515453	Assembly, Burner (6K) (Right Rear)	11	W10432544	Griddle		3196896	Clip, Wire
			12	W11379945	Bracket, Anti-Tip			
			13	7101P485-60	Screw, Anti-Tip Kit			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6	W10192841	Shield, Heat	13	W10797001	Bracket, Ignitor
	W11404310	Black (Left)	7	W11642873	Control (Maxwell)	14	3196169	Screw
	W11404311	Black (Right)	8	W10762981	Bracket, Mounting	15	W10551614	Spreader, Clip-Spring
2	W10516123	Bracket, Console Mounting	9	W10184251	Cover, Back	16	8523412	Bracket, Rear Cooktop
3		Assembly, Console	10	3196178	Screw			
	W10645848	Stainless	11		Assembly, Active Overlay			
4	W10920631	Module, Spark DSI		W10692150	Black			
5	W10198745	Cover, Upper	12	W11350452	Spark Module			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	17	3196560	Screw	31	W10874067	Motor, Fan (Convection)
2	9758701	Spacer, Door	18	W10323077	Diffuser, Flame	32	W10158780	Cover, Rear Fan
3	W10273002	Bracket, Oven Support	19	3196178	Screw	33	W10531060	Rack, Oven
4		Panel, Side	20	W11379351	Box-Burner, Gas Sealed	34	W10289145	Rack, Oven (Gull-Wing)
	W10162245	Black	21	W11491752	Gasket, Door	35	W10501599	Clip, Front Frame Cover
5	W10346153	Baffle, Full Convection	22	W10031780	Screw			FOLLOWING PARTS NOT ILLUSTRATED
6	W11511828	Switch, Door	23	W10273195	Shield, Heat		W10526208	Insulation, Wrap
7	W10137382	Clip, Panel	24	W10273192	Rod, Door Switch		W10526209	Insulation, Main Back
8	W10341186	Front Foot Assembly	25	W10910642	Cord, Power		4820F015-59	Insulation, Strap
9	W10289077	Receiver, Hinge	26	W10035900	Support, Oven Bottom			
10	W10058460	Foot, Leveling	27	W11379356	Pan, Bake			
11	W10211368	Bottom, Oven	28	W11634772	Light Assembly			
12	W10586204	Sensor	29	W10571723	Bulb, Halogen 40 Watts			
13	3601P356-45	Baffle, Bake Burner	30	W10390008	Base Rail Assembly (Left)			
14	W10362924	Screw		W10390007	Base Rail Assembly (Right)			
15	W10435470	Brace, Main Back						
16	W11040249	Assembly, Flue (Upper)						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	9	W10224921	Bracket, Aegis	22	8273062	Screw
2	W10473934	Assembly, Orifice Holder (15.5 K)	10	W10439242	Burner, Broiler			FOLLOWING PARTS NOT ILLUSTRATED
		(Left Front)	11	W10680035	Burner, Bake			
	W10732140	Assembly, Orifice Holder (9.5K)	12	W10720102	Valve, Gas	W11600783		LP 5 Orifice Conversion Kit
		(Left Rear)	13	W10324262	Igniter, Bake	W10566535		LP Conversion Kit (Bake and Broil)
	W10732137	Assembly, Orifice Holder (15K)	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)	W10465078		Orifice, LP Broil
		(Right Front)	15	W10776437	Fitting, Broil	W10400494		Orifice, LP Bake
	W10732139	Assembly, Orifice Holder (5K)	16	W10333842	Electrode, Broil	W10182767		Tie, Manifold Wire
		(Right Rear)	17	W10170510	Orifice (15.5 K)			
	W10732141	Assembly, Orifice Holder (8K)		W10170507	Orifice (8K)			
		(Center)		W10178934	Orifice (12K)			
3	W10295996	Bracket, Saddle Valve		W10732136	Orifice (5K)			
4	W10510125	Tubing, Main Supply			(Right Rear)			
5	W10811693	Harness, Switch Spark		W10251991	Orifice (7K)			
6	3601P336-45	Baffle, Broil Burner			(Center)			
7	W10811696	Assembly, Manifold	18	W10362924	Screw			
8	W10748102	Valve, Gas	19	3196385	Screw			
		(Left Front and Right Rear)	20	3400016	Screw			
	W10748103	Valve, Gas	21	W11194809	Electrode			
		(Left Rear and Right Front)			(Left Front, Left Rear, Right Front)			
	W10748105	Valve, Gas			(Center)			
		(Center)		W10515459	Electrode			
					(Right Rear)			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Outer Door
	W10830225	Stainless
2	W11091878	Screw
3		Handle, Door
	W10551000	Stainless
4	W10826568	Liner, Door
5	W11223202	Glass, Inner
6	9780274	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10675397	Scoop, Door
8	W10518672	Badge
9	W11379948	Glass Spacer
10	W10885519	Hinge, Door (Active)
11	W10813140	Rail, Horizontal Support
12	W10813139	Rail, Vertical Support
13	W10319024	Washer, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10766562	Insulation, Door
15	W10541911	Bracket, Glass Upper Handle
16	W10693388	Glass, Outer Door (Stainless)

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front
	W11449673	Stainless
2	3196169	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10688022	Drawer, Storage

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10441804	Slide, Drawer (Left)
	W10441805	Slide, Drawer (Right)
5	W10318026	Bracket, Mounting

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	4392901	Biscuit and Bisque
	285006	Black
	350956	Almond
	350938	Gray Primer
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10423113RPKit	Oven Cleaning
	W10432019	Alt Cleaning Kit
	W10205524	Split Oven Rack
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting