




REFRIGERATOR

MODELS:

KRFF305EBS07 (Black Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	11	W10673840	Screw (Stainless)	22		Grille, Toe
	W11623343	Tech Sheet	12	W10296541	Lid, HV Control Box		W10534153	Black
	W11580822	Owners Manual				23	12991604	Screw
	W11647518	Energy Guide	13		Cabinet (Not A Serviceable Part)	24	W11446816	Valve, Water Inlet
2	W11046934	Assembly, Fill Tube (Includes Tubing, Fill Tube Elbow, Tube Insert and Clamp)	14	12992403	Screw	25	W10141645	Screw
			15		Hinge, Center (Left)	26	12726003	Cover, Water Line
3	12698403	Plate, Pivot		W10740149	Black	27	W10208593	Guard, Dual Water Valve
4	W11534848	Gasket	16		Hinge, Center (Right)	28	688983	Screw
5		Cover, Right Hinge		W10740145	Black	29	W10528513	Sweep, Dual Tube
	12962302B	Black	17		Cover, Corner	30	W10211855	Cover, Unit
6		Cover, Left Hinge		12587703B	Black	31	W10317076	Board, HV Control
		(Includes Foil)	18	12961602	Cover, Control Box	32	12990702	Screw
	W10337647	Black	19		Assembly, Roller	33	W11651067	Block, Fill Tube
7	M0108107	Clamp, Tube		W10515763	Left Hand	34	W10141622	Brake, Roller
8	12990504	Screw		W10515762	Right Hand			
9	12992602	Screw	20	W10709365	Screw			
10		Hinge, Top	21		Shim, Hinge			
	W11456626	Left Hand		12999501	Left Hand			
	W11456625	Right Hand		12999502	Right Hand			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W11657832	Insulation, Damper	27	12251001	Clip, Water Tube
2	W10464764	Module, Light	15	W10594329	Control, Damper	28	W11437003	Facade, Dispenser (Top)
3	W10746278	Overlay	16	W11657834	Insulation, Water Tank	29	W11097710	Tank, Water
4	W10464767	Module, Control	17	W11510657	Plate, Filter	30	61006182	Union, Water
5	W11593757	Board, Control	18	W11519957	Manifold, Water System	31	W11437004	Foam, Plate Switch
6	W10847853	Switch, Rocker	19	W11536439	Filter, Water	32	12990302	Screw
7	W11132917	Cover, Light	20	W11510654	Cover, Filter	33	W10190541	Mount, Crisper Support
8	W10443023	Housing, Light	21	12990512	Screw	34	12791416	Thermistor
9	W11468934	Light Module, LED	22	B8390302	Clip, Facade			FOLLOWING PARTS NOT ILLUSTRATED
10	10685510	Gasket, Seal	23	W11551461	Facade, Dispenser			
11	12806801	Insert, Damper Cover	24	W11437528	Plate, Switch			
12	12990604	Screw	25	W11495787	Switch, Limit	W11609495		Harness, Fresh Food Control (Includes Thermistor)
13	12806701	Cover, Damper	26	W11031909	Guide, Waterline			


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	15	13058002	Clip, Evaporator Motor	27		Cradle, Basket
2	A3189392	Gasket, Foam	16	W10847849	Switch, Light		W10280608	Left Hand
3	W11341630	Guide, Fill Tube	17	12002497	Gear		W10280613	Right Hand
4	12791419SP	Thermistor	18	W10662407	Assembly, Drain Funnel	28	W11644400	Slide, Door
5	13062901	Motor, Evaporator	19	M0500703	Seal	29		Adapter, Slide
6	W10171529N	Pan, Ice	20	A3189396	Gasket		W10284684	Left Hand
7	W10157765	Diverter, Air	21	B8381501	Gasket, Drain		W10284685	Right Hand
8	12815301	Cover, Thermistor	22	13024803	Grille, Freezer Air	30	12990501	Screw
9	W11468934	Light Module, LED	23	13057901	Shroud, Evaporator Fan	31	W10802332	Shaft, Rack
10	W11456887	Assembly, Icemaker (Complete)	24	2169142	Blade, Fan	32		Rack, Side
11	W10308416	Cover, Evaporator	25		Bracket, Door		W11309374	Left Hand
12	12990511	Screw		W10330991	Left Hand		W11309377	Right Hand
13	W10150583	Grommet, Fan Motor		W10330993	Right Hand			
14	W10277025	Module, Light	26	12990521	Screw			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left	9	W10449760	Gripper, Gallon	16		Closure, Door
	W11622644	Black Stainless	10	12990518	Screw		12028505B	Black
2		Door, Right	11		Handle, Door	17		Stop, Door
	W10879190	Black Stainless		W11339136	Stainless		12968202B	Black
3	12804701SP	Door, Dairy	12	W10289497	Bucket, Gallon	18		Latch, Door Closer
4	12369502SP	Tray, Dairy	13	12996601	Clip, Bushing			Right Hand
5	W10371194	Bucket, Medium	14		Mullion, Door		W10725267	Black
6	12990204	Screw		12722803BN	Black			
7	W11328753	Screw	15		Latch, Door Closer			
8		Gasket, Door			Left Hand			
	W10830162	Grey		W10725268	Black			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	3		Gasket, Door	5		Nameplate
	W10879185	Black Stainless		W10443320	Grey		W10765861	Grey
2		Handle, Door	4	W11328753	Screw			
	W11222206	Stainless						


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	20	W11337767	Tray, Drip	28	W11332031	Compressor
2	12825803	Blade, Fan	21	12990701	Screw			(Also Order the Following Lokring Parts)
3	W10480111	Basepan	22	W11515437	Assembly, Evaporator and Heater		W11504416	8.5/6 NR MS 00
4	12990511	Screw			(Also Order the Following Lokring Parts)			(Suction Tube to Compressor)
5	W10350564	Capacitor		W11504423	8/2 NR AL 00		W11504431	7/5 NR MS 00
6	W11566589	Tube, Discharge			(Capillary Tube to Evaporator)			(Discharge Tube to Compressor)
7	W11305540	Harness, Evaporator Heater		W11504415	8.5/8 NR MS 00		W11506621	6 NK MS 00
8	W10655368	Pan, Drain			(Suction Line to Evaporator)			(Charging Tube to Compressor)
9	W10622701	Screw	23	W11244122	Gasket, Foam		W11506635	Tube, Charging (1/4 in w/ Schrader Valve)
10	W11287565	Heater, Defrost	24	W11505534	Motor, Condenser Fan	29	10623002	Clip, Evaporator
11	W11379613	Strap, Bale	25	W11380964	Clip, Heater	30	12477202	Axle, Roller
12	W11359985	Device, Start	26	W11654036	Harness, Unit (Includes Power Cord)	31	W11463236	Shroud, Condenser Fan
13	W10137529	Grommet, Condenser	27	W11353156	Drier	32	W10622099	Extension, Drain Tube
14	2319835	Grommet, Condenser			(Also Order the Following Lokring Parts)	33	W10236396	Strap, Compressor
15	12477102	Roller		W11504445	5/4 NR MS 00	34	W10815863	Clip, Condenser
16	12992101	Screw			(Heat Loop to Drier)	35	2169104	Insulation, Sound Deadening
17	10835903	Grommet		W11504447	5/1.8 NR MS 00		W11566588	Tube, Suction
18	W11353137	Condenser (Also Order the Following Lokring Parts)			(Capillary Tube to Drier)	37	W10303521	Sleeve
	W11506623	5 NK MS 00 (Discharge Tube to Condenser)						REFRIGERANT CHARGE
	W11504432	6/5 NR MS 00 (Heat Loop to Condenser)						54 grams (R600a)
19	W10281329	Clip, Drier						

SHELF PARTS



SHELF PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10893772	Glass, Shelf
2	W10742811	Rack, Wine
3	W10149389N	Lift, Bail Arm
4	W10528935	Support, Glass
5	12227305WH	Brace, Pantry
6	12531901	Track, Deli Drawer
7	W10171558	Divider, Basket (Upper)
8	W10241046	Divider, Basket (Upper)
9	12656901	Gasket, Pantry
10	12656202	Housing, Control
11	W10739590	Assembly, Fixed Shelf
12	12655402	Slide, Temperature Control
13	12990512	Screw
14	W10235370	Glide, Pantry
15	12990513	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
16		Endcap, Pantry
	W10845509	Left Hand
	W10845508	Right Hand
17	12804601SP	Pan, Crisper
18	12642303WD	Brace, Crisper Cover
19	W10231345N	Trim, Crisper
20	W10329866	Frame, Crisper
21	12204824N	Glass, Shelf
22	W10273463	Ladder, Center
23	W10569182	Ladder, Side
24	12802602SP	Front, Crisper Pan
25	W10215666	Screw
26	12990504	Screw
27	12530805SP	Slide, Humidity Control
28	12655304	Bar, Control
29	12731302	Drawer, Pantry
30	12655204	Knob, Temperature Control
31	12656813	Lid, Pantry

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
32	W11115781	Basket, Freezer (Lower)
33	W10146440	Divider, Basket (Lower)
34	W11115256	Basket, Freezer (Upper)
35		Gear, Spur
	W10474716	Left Hand
	W10474715	Right Hand
36	W10781754	Assembly, Fixed Shelf
37	W10802333	Shaft, Rack
38		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
39	W10326469N	Rail, Center Crisper
40	13062602	Support, Crisper Frame
41	W10738157	Assembly, Tuck Shelf
42	13025201	Tray, Lower Basket

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TOUCH-UP PAINT
	72032	Black PAINT, PRESSURIZED SPRAY (12 oz.)
	350939	Enamel, Black
	285006	Black Important: The spray paint is not to be used where the paint may make contact with the door gaskets.
		MISCELLANEOUS
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet TORX SCREW WRENCH
	1117510	Torx Key