




ELECTRIC RANGE

MODELS:

WFE505W0HB6 (Black)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10275048	Element (3000 and 1400W)	11	3196169	Screw
	W11509595	Owners Manual			(Left Front)	12	W10691223	Pan, Radiant Element
	W11435582	Quick Start Guide	6	8273994	Element (1200W)			FOLLOWING PARTS NOT ILLUSTRATED
	W11326982	Diagram, Wiring			(Left Rear and Right Rear)	W11452624		Harness, Main
	W11326986	Tech Sheet	7	8273992	Element (2500W)	W11598759		Harness, Warm Zone
2	W11600012	Spring, Element			(Right Front)	W11134551		Harness, Cooktop (Right)
3	W10607641	Bracket, Cooktop (Left)	8	W11668631	Element, Warm Zone	W11134603		Harness, Cooktop (Left)
	W10607642	Bracket, Cooktop (Right)	9	W11379945	Bracket, Anti-Tip			
4		Cooktop	10	7101P485-60	Screw, Anti-Tip Kit			
	W11034825	Black						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10434452	Switch, Infinite (Dual)	7		Knob
	W11130372	Black (Left)			(Left Front)		W11022718	Black
	W11130379	Black (Right)		3148951	Switch, Infinite	8	W10134247	Shield, Heat
2	W10695491	Bracket, Control			(Left Rear and Right	9	3400882	Screw
3		Panel, Console			Rear)	10	8272473	Cover, Upper Rear
	W11027374	Black		3148954	Switch, Infinite	11	W10525121	Bracket, Console
					(Orange)			Mounting
					(Right Front)			
			5	3196169	Screw			
			6		Control, Electronic			
					(LCX)			
				W11428348	Black			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	15	W10390007	Base Rail Assembly (Right)	27	W10181986	Sensor, Oven
2	W10362924	Screw				28	3196169	Screw
3		Panel, Side		W10390008	Base Rail Assembly (Left)	29	W10326122	Cover, Terminal Block
	W10162245	Black				30	W10031780	Screw
4	3400029	Nut	16	W10058460	Foot, Leveling	31	W11173792	Rack, Oven
5	W10129032	Seal, Door	17	3196548	Fuse, Thermal	32	W10910404	Counterweight
6	9757340	Element, Broil	18	3196172	Screw	33	W11034869	Screw
7	W11111743	Element, Bake	19	W10404688	Clip, Oven Support	34	W11464547	Bracket, Front Frame
8	3196154	Screw	20	3186034	Bracket, Service	35	3196560	Screw
9	W10134285	Tube, Vent	21	W10245259	Block, Terminal	36	W11510560	Barrier Rail, Rubber (Left and Right)
10	W10674705	Glide, Drawer Front	22	W10281322	Kit, Bare Wire Adapter Block			FOLLOWING PARTS NOT ILLUSTRATED
11	W10341186	Front Foot Assembly	23	3196178	Screw			
12	W10067840	Screw	24	W11634772	Light Assembly		8273263	Insulation, Wrap
13	8054068	Retainer, Insulation	25	W10571723	Bulb, Halogen 40 Watts		8272611	Insulation, Back
14	W10137382	Clip, Panel	26	3400016	Screw		W10333344	Insulation, Flue


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly	7	9761505	Retainer, Insulation	12	W10299227	Hinge, Door (Passive)
	W11242949	Black	8	W10299225	Hinge, Active	13	W10031780	Screw
2	W10031790	Screw	9		Glass Assembly, Outer Door	14	W11379944	Strap, Door
3		Trim, Lower Door		W10884159	Black	15	W10200660	Screw
	W11444043	Black	10		Trim, Side	16	W10480830	Screw
4	9761344	Liner, Door		W10746436	Black (Left)			
5	W10884775	Badge		W10746435	Black (Right)			
6	W11367326	Glass, Inner	11	W10327235	Screw			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196169	Screw
2	W10688022	Drawer, Storage
3		Rivet, Push
	3196813	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10674708	Glide, Drawer Rear
5	3196165	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6		Panel, Drawer Front
	W11123900	Black
7	W10462912	Bracket, Mounting Drawer

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting