




## **30" ELECTRIC SLIDE-IN SELF-CLEAN RANGE**

### **MODELS:**

WEE515S0LB2 (Black)

WEE515S0LW2 (White)


# COOKTOP PARTS



# COOKTOP PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                             | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                         |
|-----------------------------|-----------------|------------------------------------------------|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|--------------------------------------------|
| 1                           |                 | Literature Parts                               | 12                          | W10162253       | Brace, Corner (Left)      | 26                          | W10689102       | Gasket, Console Short                      |
|                             | W11509605       | Owners Manual                                  |                             | W10162252       | Brace, Corner (Right)     | 27                          |                 | Knob                                       |
|                             | W11508915       | Quick Start Guide                              | 13                          | W10814304       | Support, Cooktop (Right)  |                             | W10905965       | Black                                      |
|                             | W11508781       | Tech Sheet                                     |                             | W10814303       | Support, Cooktop (Left)   |                             | W11027257       | White                                      |
| 2                           | W10814305       | Bracket, Console (Center)                      | 14                          | 3196169         | Screw                     | 28                          | W10437092       | Switch, Infinite (Left Front, Right Front) |
| 3                           | 9780274         | Screw                                          | 15                          | W10547960       | Bracket, Console (Left)   |                             | W10578768       | Switch, Infinite (Left Rear, Right Rear)   |
| 4                           |                 | Cooktop                                        |                             | W10547961       | Bracket, Console (Right)  | 29                          | W10674068       | Screw                                      |
|                             | W11523804       | Black                                          | 16                          |                 | Assembly, Console         | 30                          | 7201P077-60     | Gasket, Infinite Switch                    |
|                             | W11523818       | White                                          |                             | W11512199       | Black                     | 31                          | W10702912       | Gasket, Switch Stem                        |
| 5                           | 8273994         | Element (1200W) (Left Rear, Right Rear)        |                             | W11512198       | White                     |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED            |
| 6                           | W11282542       | Element (3000W Dual) (Left Front, Right Front) | 17                          | W10516115       | Screw                     |                             | W11453734       | Harness, Main                              |
| 7                           |                 | Console, Lower Panel                           | 18                          | W11546962       | Electronic, Control (LCX) |                             | W10664316       | Clip, Harness (Cooktop)                    |
|                             | W10816943       | Black                                          | 19                          | 3196178         | Screw                     |                             | W11171886       | Harness, Cooktop                           |
|                             | W10816942       | White                                          | 20                          | W10854253       | Bumper                    |                             | 313438          | Clip, Harness                              |
| 8                           |                 | Vent, Trim Top                                 | 21                          | W10536275       | Pan, Radiant              |                             | 7111P017-60     | Clamp, Wire                                |
|                             | W10636528       | Black                                          | 22                          | W11175271       | Bracket, Radiant          |                             | W11226230       | Harness, Console                           |
|                             | W10636527       | White                                          | 23                          | 3196173         | Screw                     |                             |                 |                                            |
| 9                           | W11379947       | Bracket, Anti-Tip                              | 24                          | W10612719       | Gasket, Console/ Cooktop  |                             |                 |                                            |
| 10                          | 7101P485-60     | Screw, Anti-Tip Kit                            | 25                          | W10689101       | Gasket, Console           |                             |                 |                                            |
| 11                          | W10225448       | Spring, Element                                |                             |                 |                           |                             |                 |                                            |


# CHASSIS PARTS



# CHASSIS PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|------------------------------------|
| 1                           | W11092984       | Screen, Vent                 | 22                          | W10853401       | Baffle, Upper Chassis        | 42                          | W11122085       | Assembly, Flue                     |
| 2                           | W10162248       | Cover, Wire                  | 23                          | W10586204       | Sensor                       | 43                          | 9758701         | Spacer, Door                       |
| 3                           |                 | Panel, Side                  | 24                          | W10362924       | Screw                        | 44                          | W10814301       | Chassis, Support Upper             |
|                             | W10162245       | Black                        | 25                          | 3400080         | Screw                        | 45                          | W10866583       | Clip-Panel, Ratcheting             |
|                             | W10575396       | White                        | 26                          | 3196169         | Screw                        | 46                          | W11379354       | Cover, Back                        |
| 4                           | W11491751       | Seal, Door                   | 27                          | W10289077       | Receiver, Hinge              | 47                          | W10162241       | Channel, Rear                      |
| 5                           | W10583047       | Element, Broil               | 28                          | W10627802       | Switch, Door                 | 48                          | W10674705       | Glide, Drawer Front                |
| 6                           | W10535148       | Bake, Element                | 29                          | 9757239         | Rod, Door Switch             | 49                          | W10914589       | Counterweight                      |
| 7                           | W10031780       | Screw                        | 30                          | W11379353       | Retainer, Insulation (Left)  | 50                          | W11034869       | Screw                              |
| 8                           | 3196178         | Screw                        |                             | W11379943       | Retainer, Insulation (Right) | 51                          | W11510561       | Barrier Rail, Rubber (Front Left)  |
| 9                           | 3400029         | Nut                          | 31                          | W11544377       | Light Assembly               |                             | W11510562       | Barrier Rail, Rubber (Front Right) |
| 10                          | W10341186       | Front Foot Assembly          | 32                          | 9761013         | Front Door Latch Assembly    | 52                          | W11464547       | Bracket, Front Frame               |
| 11                          | W10067840       | Screw                        | 33                          | W10078370       | Rod, Push Latch              |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED    |
| 12                          | W10312471       | Tray, Insulation             | 34                          | W10107820       | Rear Door Latch Assembly     |                             | W10830993       | Insulation, Wrap                   |
| 13                          | W10137382       | Clip, Panel                  | 35                          | 3196548         | Fuse, Thermal                |                             | W10815385       | Insulation, Back                   |
| 14                          | W10390008       | Base Rail Assembly (Left)    | 36                          | 3196172         | Screw                        |                             |                 |                                    |
|                             | W10390007       | Base Rail Assembly (Right)   | 37                          | 3196560         | Screw                        |                             |                 |                                    |
| 15                          | W10058460       | Foot, Leveling               | 38                          | W10571723       | Bulb, Halogen 40 Watts       |                             |                 |                                    |
| 16                          | W10327235       | Screw                        | 39                          | W11173792       | Rack, Oven                   |                             |                 |                                    |
| 17                          | W10355173       | Bracket, Oven Support        | 40                          | W10655441       | Shield, Power Cord           |                             |                 |                                    |
| 18                          | 3186034         | Bracket, Service             | 41                          | W10848443       | Chassis, Upper Insulation    |                             |                 |                                    |
| 19                          | W10245259       | Block, Terminal              |                             |                 |                              |                             |                 |                                    |
| 20                          | 3196154         | Screw                        |                             |                 |                              |                             |                 |                                    |
| 21                          | W10281322       | Kit, Bare Wire Adapter Block |                             |                 |                              |                             |                 |                                    |


# DOOR PARTS



# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|-----------------------------|-----------------------------|-----------------|----------------------|-----------------------------|-----------------|--------------------|
| 1                           | W10031790       | Screw                       | 8                           | 9758162         | Glass, Inner         | 15                          |                 | Trim, Door         |
| 2                           | 9761344         | Liner, Door                 | 9                           | W10031780       | Screw                |                             | W10746436       | Black (Left)       |
| 3                           | W10278991       | Insulation, Door Strip      | 10                          | 9761357         | Retainer, Insulation |                             | W10746435       | Black (Right)      |
| 4                           |                 | Handle and Vent<br>Assembly | 11                          |                 | Trim, Lower Door     |                             | 8523172         | White (Left)       |
|                             | W11242949       | Black                       |                             | W11444043       | Black                |                             | 8523166         | White (Right)      |
|                             | W11242947       | White                       |                             | W11444042       | White                | 16                          | W10316950       | Frame, Glass       |
| 5                           | W10388635       | Hinge, Door (Active)        | 12                          | W10440013       | Hinge, Door (Active) | 17                          |                 | Glass, Outer Door  |
| 6                           | W10200660       | Screw                       | 13                          | W10327235       | Screw                |                             | W10884159       | Black              |
| 7                           | W10884775       | Badge                       | 14                          | W11379944       | Strap, Door          |                             | W10409945       | White              |

# DRAWER PARTS





# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|--------------------|
| 1                           |                 | Panel, Front       | 3                           | W10462911       | Bracket, Mounting  | 6                           |                 | Rivet, Push        |
|                             | W11123976       | Black              | 4                           | W10674708       | Glide, Drawer Rear |                             | 3196813         | Black              |
|                             | W11123977       | White              | 5                           | 3196169         | Screw              |                             | 3196814         | White              |
| 2                           | W10688022       | Drawer, Storage    |                             |                 |                    |                             |                 |                    |

# OPTIONAL PARTS

## REFINISHING MATERIAL

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-----------------------------|-----------------|---------------------------|
|                             | 242756          | Oven Liner Touch Up Paint |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 72017           | White                   |
|                             | 72032           | Black                   |
|                             | 511873          | White Porcelain (2 oz.) |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |

## INSULATION

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-----------------------------|-----------------|----------------------------------|
|                             | 261514          | Insulation (1-1/2" x 24" x 120") |
|                             | 240132          | Insulation (2-1/2" x 22" x 120") |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 285006          | Black              |

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-----------------------------|-----------------|------------------------------|
|                             | 4396923         | Broiler Pan and Grid         |
|                             | W10123240       | Rack, Broiler Pan & Roasting |