




ELECTRIC DRYER

MODELS:

YMED5430MW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W10414381	Switch, Rotary Encoder (2 Position)	20	W10414397	Switch, Rotary Encoder (3 Position)
	W11555817	Owners Manual	10	688983	Screw	21	9740848	Screw
	W11495041	Tech Sheet	11	3348629	Screw	22	343641	Screw
	W11425775	Quick Start Guide	12		Top	23	W10726632	Seal, Console
2	W11438904	Connector, Service Standalone		W10613389	White	24	W11486550	Harness, Upper Encoder RS
3	W11606408	Appliance Control Unit (ACU)	13	W10298336	Nut, "U"	25	W11437795	Harness, Upper Encoder
4	W10775189	Panel, Rear	14	W11328381	Knob, Large	26	W10414398	Switch, Rotary Encoder (4 Position)
5	W11437790	Harness, Main	15	W11398762	Knob, Small			
6	8312709	Clip, Console	16		Assembly, Console			
7	3390663	Screw		W11576589	White			
8		Lint Screen	17	688805	Clip, Spring			
	W11538108	White	18	W10612925	Badge			
			19	W10662472	Collar, Lint Chute			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10529198	Cover, Door Catch	19		Panel, Front	35	8066184	Pulley, Motor
2	3390631	Screw		W10664697	White	36	691366	Idler Assembly
3	693995	Screw	20	W11224633	Strike, Door	37	W10131364	Belt, Drive
4	W10841728	Seal, Spill Guard	21	W10803476	Assembly, Seal and Bearing	38	348780	Base, Motor
5	W11219688	Cover, Terminal Block	22	W11224630	Assembly, Door Catch	39	3400500	Bolt
6	W10567345	Plug, Strike	23	342055	Screw	40	W10641296	Hinge, Top
7	W11593118	Panel, Rear	24		Assembly, Hinge and Pin	41	W10316529	Seal, Foam
8	8066092	Lock, Front Top				42	W10641295	Bracket, Rear
9	98234	Clip, Ground		W10362431	White	43	W10316619	Seal, Spill Guard
10	W10569603	Switch, Door	25	W10730752	Seal, Door	44	9740848	Screw
11	697773	Screw	26	W10463967	Door, Inner	45	W10685675	Seal, Rear Panel
12		Plug, Front Panel	27		Door, Front	46	W10529197	Bezel, Door Catch
	W11308618	White		W10714510	White	47	343641	Screw
13	685203	Clip, Felt Pad	28		Handle, Door	48	W10653662	Pad, Foam
14	694415	Clip, Strain Relief		W10714516	White			
15	W10775448	Clip, Front Panel	29	279393	Screw Kit, Terminal Block			
16	W10779369	Foot, Dryer	30	W10773242	Screw			
17	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)	31	W10712173	Cord, Power			
			32	3404162	Clamp, Motor (With Shield)			
18		Cabinet	33	W10121316	Clamp, Motor Mount			
	8530603	White	34	W10396029	Assembly, Motor			

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	17	W10724237	Element, Heater	32	692526	Bearing, Ring
2	339956	Seal	18	W10504381	Pad, Foam	33	W10219342	Screw
3	3388703	Washer	19	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	34	W10856781	Seal, Rear Drum
4	347139	Seal, Lint Chute				35	W10757750	Assembly, Drum (Complete)
5	90767	Screw	20	489463	Screw	36	692490	Baffle, Drum (Long)
6	W10389567	Shield, Exhaust	21	3390647	Screw	37	W11032820	Bracket, Support
7	3392519	Fuse, Thermal (91C)	22	3406124	Bulb, Light	38	90296	Nut, Push On
8	8577274	Thermistor	23	3402841	Lens, Drum Light	39	3403636	Baffle, Drum (Short)
9	W10900067	Kit, Thermal Cut-Off (Includes Thermostat)	24	W10512946	Washer, Tri Ring	40	W11424720	Pad, Sensor
10	694089	Wheel, Blower	25	W10359270	Shaft, Drum Roller - Left Hand Thread	41	W10709380	Seal, Drum Light
11	8577230	Housing, Blower	26	W10359269	Shaft, Drum Roller - Right Hand Thread	42	W11135293	Valve and Hose Assembly
12	3398161	Clip, Heater Box				43	W11100488	Nozzle, Cap
13	3390631	Screw	27	3397590	Roller, Support			
14	W11338355	Box, Heater	28	348197	Washer			
15	3977767	Thermostat, 221 F (105 C)	29	W10298789	Nut, Hex			
16	3977373	Bracket, Drum Light	30	W10714471	Bulkhead			
			31	W10214261	Socket, Light			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

350930	White
350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
-----------------------------	-----------------	--------------------

799344	White (Uncut)
--------	---------------

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	8522199	Kit, Dryer Vent Testing
	W10322470A	Dry Rack
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	3406839	Dry Rack
		Power Cords
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	W10242307	Washer, Hose
	W10336486	Connector, Hose -"Y"
	3976300	Washer, Inlet Hose