




## **GAS COOKTOP**

### **MODELS:**

WCGK5036PV00 (Black Stainless)


# COOKTOP, BURNER AND GRATE PARTS



# COOKTOP, BURNER AND GRATE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11352193	Flame Spreader (Left Front and Center)	13		Rear, Hinge-Grate (Stainless Model Only)
	W11613935	Owner's Manual		W11352197	Flame Spreader (Left Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W11635589	Quick Start Guide		W11352195	Flame Spreader (Right Front and Right Rear)	W11632719		Harness (Switch), Main
2		Cooktop				W10878749		Harness, Spark Module
	W11591938	Black Stainless	9	W10598131	Foot Pad, Grate (Outer)	3400015		Screw, Grounding
3		Burner Cap Kit	10	W10758282	Screw	W10392003		Cord, Power
	W11596821	Black (Set of 5)	11	W10723360	Orifice (Left Front)	W10132200		Relief, Strain
4		Grate Kit (Includes 3 Grates)		W11364991	Orifice (Left Rear)	313438		Clip, Harness
	W11591618	Black (Set of 3)		W11610057	Orifice (Center)	W11573776		LP Conversion Kit
5	W10827923	Electrode, Spring		W11631338	Orifice (Right Front and Right Rear)	3801F935-51		Bracket, Tie Down
6		Knobs, Cooktop	12	W11640975	Wiring, Electrode (440MM)	7101P062-60		Screw (For Tie Down Bracket)
	W11566381	Black Stainless		W11642338	Wiring, Electrode (636MM)			
7	W11567145	Holder, Orifice (12K) (Left Front)						
	W11567151	Holder, Orifice (5K) (Left Rear)						
	W11567144	Holder, Orifice (18K) (Center)						
	W11567146	Holder, Orifice (9.1K) (Right Front and Right Rear)						

# BURNER BOX, GAS VALVES AND SWITCH PARTS



# BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	8	W11566469	Bracket, Orifice Holder	17	3196537	Screw
2	W11576641	Manifold Assembly	9	W11350452	Spark Module	18	8286921	Screw, Burner Rail (M4)
3	W11629615	Valve, Single (Left Front and Center)	10		Box, Burner (Not Serviced)	19	W11573983	Tube, Gas (Center)
	W11629616	Valve, Single (Left Rear)	11	W11573975	Tube, Gas (Left Front)	20	W11704153	Bracket, Orifice Holder Center Burner
	W11629617	Valve, Single (Right Front and Right Rear)	12	W11573977	Tube, Gas (Left Rear)			INSULATION PARTS NOT ILLUSTRATED
4	8287055	Bracket, Single Valve	13	W11573979	Tube, Gas (Right Front)	W11631590		Insulation, Burner Box High Temp
5	W11507167	Seal, Switch Shaft	14	W11573978	Tube, Gas (Right Rear)			OPTIONAL ACCESSORY PART (NOT INCLUDED)
6	W11620861	Panel, Front	15	7101P426-60	Screw			
7	W10449143	Regulator, Pressure	16	W10443110	Screw	W10685483		Griddle