




GAS RANGE

MODELS:

WFG515S0MB1 (Black)

WFG515S0MW1 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	10	W11379945	Bracket, Anti-Tip
	W11426600	Owner's Manual		W11331143	Black	11	7101P485-60	Screw, Anti-Tip Kit
	W11508882	Wiring Diagram		W11331141	White	12	W10465081	Grate, Bumper
	W11427476	Quick Start Guide	5		Panel, Manifold			FOLLOWING PARTS NOT ILLUSTRATED
2		Burner Cap Kit		W11089575	Black		W11457167	Harness, Main
	W11395131	Black (Set of 4)		W11089574	White		W11450461	Harness, Bake and Broil
3	W11352018	Spreader, Flame (Left Front and Right Front)	6		Knob, Control		313438	Clip, Harness
	W11352020	Spreader, Flame (Left Rear)		W11510457	Black		3196173	Screw
	W11352021	Spreader, Flame (Right Rear)		W11510458	White		W10334923	Clip, Gas Wiring
			7		Kit, Grate (Set of 2)		3196520	Clip, Wire
				W11603169	Grates, Cooktop		3196896	Clip, Wire
			8	W10673618	Screw			
			9	3196557	Screw			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10920631	Module, Spark DSI	12		Control, Range (LCC190)
	W11130372	Black (Left)	6	W10516123	Bracket, Console Mounting		W11520699	Black
	W11130371	White (Left)					W11520697	White
	W11130379	Black (Right)	7	8523412	Bracket, Rear Cooktop	13	3196178	Screw
	W11130378	White (Right)	8	W10198745	Cover, Upper	14	W10695491	Bracket, Control
2	8053505	Shield, Heat	9	W10192841	Shield, Heat	15	W10797001	Bracket, Ignitor
3		Panel, Control	10	W10184370	Cover, Back	16	W10110488	Module, Spark
	W10885611	Black	11	3196169	Screw	17	3196165	Screw
	W10885610	Black						
4	W10762981	Bracket, Mounting						


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	15	8053968	Shield, Lower	27	W11511828	Switch, Door
2	8272747	Shield, Flue	16	W10390008	Base Rail Assembly (Left)	28	W11634772	Light Assembly
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	29	W10571723	Bulb, Halogen 40 Watts
4		Panel, Side	17	9757239	Rod, Door Switch	30	9761013	Front Door Latch Assembly
	W10162245	Black	18	W10031780	Screw	31	W10078370	Rod, Push Latch
	W10575396	White	19	3400080	Screw	32	W10107820	Rear Door Latch Assembly
5	W10137382	Clip, Panel	20	W11173792	Rack, Oven	33	W10674705	Glide, Drawer Front
6	8523249	Bracket, Manifold	21	W11491751	Seal, Door	34	3196178	Screw
7	W10362924	Screw	22	W10435470	Brace, Main Back	35	W10379120	Screw
8	3196560	Screw	23	W11379353	Retainer, Insulation (Left)			FOLLOWING PARTS NOT ILLUSTRATED
9	W10341186	Front Foot Assembly		W11379943	Retainer, Insulation (Right)		8524099	Insulation, Wrap
10	W10058460	Foot, Leveling	24	3196560	Screw		W10180437	Insulation, Back
11	3195097	Bottom, Oven	25	W10910642	Cord, Power			
12	W10586204	Sensor	26	W10289077	Receiver, Hinge			
13	8053967	Baffle, Burner Oven						
14	8053969	Shield, Heat						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	10	3196385	Screw	25	W11428831	Electrode
2	W10949105	Bracket, Saddle Valve	11	3400016	Screw			(Left Front and Left Rear)
3	W11459257	Orifice Holder Assembly (15K)	12	8054078	Burner, Broiler		W11428858	Electrode
		(Left Front)	13	W10184491	Spreader, Flame (Oven)			(Right Front and Right Rear)
	W11459258	Orifice Holder Assembly (9.5K)	14	9758078	Burner, Bake			FOLLOWING PARTS NOT ILLUSTRATED
		(Left Rear)	15	W11370883	Regulator		W11489400	LP Conversion Kit
	W11459260	Orifice Holder Assembly (15K)	16	W10333842	Electrode, Broil		W10566537	LP Bake and Broil Kit
		(Right Front)	17	W10420040	Tube, Broiler Supply		W10400495	Orifice, LP Bake
	W11459259	Orifice Holder Assembly (5K)	18	W11435700	Fitting, Broiler		W10465080	Orifice, LP Broil
		(Right Rear)	19	W11485872	Orifice (15K) (Left Front)			
4	W10215439	Tubing (Manifold to Regulator)		W11485873	Orifice (9.5K) (Left Rear)			
5	W11537750	Harness, Switch		W11428753	Orifice (15K) (Right Front)			
6	W11450459	Electrode, Bake		W11485871	Orifice (5K) (Right Rear)			
7	W11510001	Manifold Assembly	20	W10137062	Spreader, Flame (Broiler)			
8	W11509685	Valve, Gas (Left Front and Right Front)	21	3196265	Screw			
	W11509686	Valve, Gas (Left Rear)	22	W10362924	Screw			
	W11509687	Valve, Gas (Right Rear)	23	W10827923	Electrode, Spring			
9	W10224921	Bracket, Aegis	24	W10182767	Tie, Manifold Wire			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11242949	Black
	W11242947	White
2		Trim, Lower
	W11444043	Black
	W11444042	White
3	W10031780	Screw
4	9761344	Liner, Door
5	W10031790	Screw
6	W11044424	Glass, Inner
7	W10316950	Frame, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10299226	Hinge, Active
11		Glass, Outer Door
	W10884159	Black
	W10409945	White
12		Trim, Door
	W10746436	Black (Left)
	8523172	White (Left)
	W10746435	Black (Right)
	8523166	White (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10299227	Hinge, Door (Passive)
16	W10884775	Badge
17	W10200660	Screw
18	W10480830	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10462911	Bracket, Mounting	6		Rivet, Push
	W11123976	Black	4	W10674708	Glide, Drawer Rear		3196813	Black
	W11123977	White	5	3196169	Screw		3196814	White
2	W10688022	Drawer, Storage						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		FOLLOWING PARTS NOT ILLUSTRATED
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	285006	Black
	350930	White
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10539770	Wipes, Cleaning
	W10275756	Cleaner, Granite