




## **CHEST FREEZER**

### **MODELS:**

WZC5216LW (White)

# CABINET PARTS



# CABINET PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|---------------------|-----------------------------|-----------------|----------------------------|-----------------------------|-----------------|----------------------|
| 1                           | W11591689       | Foot                | 14                          | W11593742       | Separator                  | 26                          | W11592058       | Thermostat           |
| 2                           | W11591957       | Wheel Assembly      | 15                          | W11595453       | Basket                     | 27                          | W11593911       | Inverter             |
| 3                           | W11591958       | Cover Hinge (Lower) | 16                          | W11592036       | Thermostat Casing          | 28                          | W11593885       | Bulb, LED            |
| 4                           | W11591959       | Cover Hinge (Upper) | 17                          | W11592037       | Control Panel              | 29                          | W11593888       | Holder, Lamp         |
| 5                           | W11591960       | Compressor Grid     | 18                          | W11592038       | Lens (Red)                 | 30                          | W11593886       | Support, Lamp Holder |
| 6                           | W11593693       | Door, Freezer       | 19                          | W11592039       | Lens (Green)               | 31                          | W11592063       | Drier                |
| 7                           | W11591981       | Door Handle         | 20                          | W11592041       | Thermostat Knob            | 32                          | W11593738       | Assembly, Lock       |
| 8                           | W11591983       | Plug                | 21                          | W11593918       | Lamp, Pilot (with Harness) | 33                          | W11593756       | Cover, Lamp          |
| 9                           | W11593694       | Cover, Door Lock    | 22                          | W11593917       | Compressor                 | 34                          | W11594664       | Nameplate            |
| 10                          | W11591985       | Compressor Support  | 23                          | W11592044       | Compressor Damper          | 35                          | W11596777       | Handle, Basket       |
| 11                          | W11593345       | Hinge               | 24                          | W11592064       | Panel Drain                | 36                          | W11596840       | Clip                 |
| 12                          | W11593741       | Gasket, Door        | 25                          | W11592048       | Power Cord                 | 37                          | W11596854       | Kit, Frame           |
| 13                          | W11593701       | Key                 |                             |                 |                            |                             |                 |                      |