




ELECTRIC COMBO WALL OVEN

MODELS:

KOEC527PSS01 (Stainless)

KOEC527PBS01 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	7101P426-60	Screw	17	W11533682	Cover, WIFI
	W11655510	Owner's Manual	9	4450118	Nut			FOLLOWING PARTS NOT ILLUSTRATED
	W11618058	Quick Start Guide	10	W10655463	Bracket, Blower (Left)		W11659368	Harness, Main
	W11340885	Wiring Diagram		W10655462	Bracket, Blower (Right)		W11256627	Harness, Signal
	W11382178	Tech Manual					W11264646	Harness, Door Latch
2		Control Panel Assembly (Includes Overlay)	11	4451758	Block, Foam		W11229448	Harness, Communication
	W11640538	Stainless		W10588741	Stainless		313438	Clip, Harness
	W11640551	Black Stainless		W10861075	Black Stainless		4450800	Screw, Grounding
3	W11249218	Appliance Manager, Copernicus	13	W10283025	Side, Bracket		W11226264	Strap, Ground
4	W11339492	Screw (Black)	14	W11166802	Divider, Chassis Back		4448664	Clamp, Conduit
5	W11397930	Blower	15	W10318159	Chassis, Cover Top Front 27 In		W11394923	Bag, Hardware
6	W10655467	Chassis, Combo Side	16	W10681157	Cover, Combo Blower			
7	W11037652	Chassis, Cover Top Back 27 In WIFI						


OVEN PARTS



OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11134657	Duct, Lower Chassis Back	16	W11346074	Probe, Sensor	29	W10254050	Screw
2	W11085298	Tube, Vent	17	W11167419	Cover, Suction (Left)	30		Trim, Bottom Vent
3	W11239070	Receiver, Hinge (Left)		W11186675	Cover, Suction (Right)		W11624688	Black
	W11239072	Receiver, Hinge (Right)	18	4449751	Thermostat (TOD)	31	W11245118	Foot, Base
4	W11558603	Spacer, Base	19	W11244454	Base, Chassis	32	8285593	Cover, Connector
5	W11655005	Latch, Motorized	20		Bottom Vent Assembly	33	W11256423	Base, Vent Exhaust
6	W11244456	Top, Chassis		W11467824	Stainless	34	W10472384	Bulb, Light
7	W11205574	Light Assembly		W11467807	Black	35		Sidetrिम, Bended
8	W10283020	Support, Base (Left)	21	W11244446	Duct, Bottom Chassis		W11235457	Black (Left)
9	W10904163	Deflector, Blower	22	W10283021	Support, Base (Right)		W11235458	Black (Right)
10	W11518348	Vent, 27 In Combo Center	23	W11135135	Support, Air Channel	36	W11404000	Screw
11	W11608109	Gasket, Cavity	24	W11135125	Spacer, Bottom Chassis Duct	37	W11249635	Screw
12	W11256424	Cover, Vent Exhaust	25	W11166315	Bumper and Screw	38	W11245114	Foot, Chassis (Left)
13	W11165274	Side, Chassis	26	W10472386	Lens, Light		W11245116	Foot, Chassis (Right)
14		Back, Chassis (Not Serviced)	27	7101P426-60	Screw			FOLLOWING PARTS NOT ILLUSTRATED
15		Liner, Oven (Not Serviceable)	28	W11186391	Deflector, Chassis (Left)		W11244474	Insulation, Wrap
				W11186398	Deflector, Chassis (Right)		W11244475	Insulation, Back


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	8	W11633416	Hinge, Door (Left)	13	W10518672	Badge
2	7101P375-60	Screw		W11633417	Hinge, Door (Right)	14		Handle Assembly
3	W11290045	Screw	9	3196183	Screw		W11241574	Stainless
4	W10618123	Glass, Inner	10	W11317731	Screw (Black)	15	W10551026	Medallion, Handle
5	W11647161	Spacer, Air Divider	11		Door Assembly	16	W10656499	Screw
6	W11204277	Retainer, Air Divider Glass		W11295967	Stainless			
7	7101P426-60	Screw		W11295968	Black Stainless			
			12	W10319024	Washer, Door			


INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	12	W10546519	Element, Convection	20	W11033111	Nut, Locking
2	W10554529	Rack, Oven	13	W10819989	Baffle, Bow Tie	21	W11251715	Plate, Convect Motor
3	W10318198	Tray, Hidden Bake			(Stainless Model Only)	22	W11251716	Insulation, Convect Motor
4	7101P434-60	Screw		W10918895	Baffle, Bow Tie	23	W11398057	Cover, Convect Plate
5	7101P426-60	Screw			(Black Stainless Model Only)	24	W11661815	Basket, Airfry
6	W10282957	Crossbar, Hidden Bake Tray	14	W10554532	Rack, Sliding			
7	W11292248	Element, Bake	15	W10588737	Shield, Broil Front			
8	W11235537	Reflector, Broil	16	W10720084	Screw			
9	W11398058	Convect Motor Assembly	17	W10906658	Screw			
10	W11425715	Blade, Fan	18	9755542	Probe, Temperature			
11	W11433702	Nut, Acorn (LH)	19	W11252826	Jack, Meat Probe			


TOP VENTING PARTS



TOP VENTING PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11627410	Siderail, Combo (Left)	5	W11171919	Side, Combo Chassis (Right)	7	W11171004	Cover, Combo Chassis Back Duct
2	W11627411	Siderail, Combo (Right)	6	7101P426-60	Screw	8	W10283023	Support, Crossbar
3	7101P633-60	Screw (Black)						
4	W11171909	Side, Combo Chassis (Left)						


CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11289998	Manager, Appliance	17	W10490593	Holder, Lamp	37	461967750494	Support
2	423107845441	Sensor, Convection	18	W10795595	Lamp, Halogen	38	W11213889	Arm, Sliding
3	461967848711	Heater, Convection Element	19	W10358241	Assembly, Interlock Switch	39	423107570871	Spring, Release Rod
4	W11453899	Blade, Fan	20	461967848881	Switch	40	W10769147	Sealing, Lamp
5	W10120233	Nut, Speed	21	W10876593	Holder, Switch	41	461967825781	Screw (Shoulder)
6	W11505129	Filter, Noise	22	423107022541	Reflector	42	W10128850	Sliding Arm Assembly
7	461967754821	Duct, Magnetron	23	423107720491	Lens, Lamp	43	W11591019	Housing, Upper Inverter
8	461967017511	Trim, Side (Left)	24	W11440819	Clip, Spring	44	W11591018	Housing, Lower Inverter
	W11044584	Trim, Side (Right)	25	W11334717	Vent, Top	45	461967825601	Screw
9	461967825321	Screw	26	W10460457	Sensor, Humidity			MISCELLANEOUS PARTS
10	461967848621	Transformer, Light (20V)	27	461967008461	Support, Bottom			
11	461967842541	Thermoactuator	28	W11681075	Hinge, Door	W11539494		Harness, Inverter
12	241908600053	Fuse	29	W11233698	Motor, Convection Fan	W11555168		Harness, Interlock
13	4375231	Block, Fuse	30	W11131760	Cooling Fan Assembly	W11454022		Harness, Fan and Turntable
14	461967846741	Thermostat, Magnetron	31	W11504539	Inverter	W11539527		Jumper Harness, Communication
15	W11504545	Magnetron	32	461967825971	Screw			
16	W10465869	Spring, Lamp	33	461967750464	Rod, Push			
			34	241960100002	Sensor, Temperature			
			35	461967510191	Bushing			
			36	461967570351	Spring, Torsion			


MICROWAVE DOOR PARTS



MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8304588BL	Cap, Screw	6		Door Assembly	9	W10551026	Medallion, Handle
2	7101P338-60	Screw		W11300493	Stainless	10	W10656499	Screw
3	W11639552	Inner Door Assembly		W11300497	Black Stainless			
4	W10359769	Foam, Door Handle	7	W10319024	Washer, Door			
5	W11317731	Screw (Black)	8		Handle Assembly			
				W11241574	Stainless			

INTERNAL MICROWAVE PARTS



INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461967753742	Adapter, Turntable Motor	6	W11340343	Turntable	11	461967451001	Plate, Cover
2	W10796139	Steamer	7	W10367316	Ring, Turntable	12	461967753871	Support, Element
3	W10748279	Rack, Low Convection	8	W10545578	Drive, Turntable			
4	W10750839	Plate, Baking	9	252262898008	Support, Spring Lock Grill			
5	461967848971	Motor, Turntable	10	W10387651	Element, Grill			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		FOLLOWING PARTS NOT ILLUSTRATED
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORY PARTS
		Bottom Vent Assembly
	W11369893	Black
		Trim, Tall Vent
	W11570324	Stainless
	W11570326	Black
		Vent, Deflector
	W11551865	Stainless
	W11594554	Black