




ELECTRIC RANGE

MODELS:

YKFID500ESS5 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Cooktop	12	4450800	Screw, Grounding
	W11241802	Guide, Use & Care		W10687992	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
	W11241789	Instructions, Installation	6	W10808236	Control, UI			
	W11325873	Tech Sheet	7	W10873518	Assembly, Induction Module		W11190429	Harness, Main
2	W10410580	Hotplate (Left Front & Right Rear)	8	W10328492	Fuse		W11172529	Harness, Signal
			9	W10454938	Plate, Induction		W11172531	Harness, Sensor & Locks
3	W10460400	Hotplate (Left Rear)	10	W10564364	Assembly, Induction Pan		7101P027-60	Screw, Ground
4	W10536262	Hotplate (Right Front)	11	W10328381	Fan, Cooling (Left)		8019P013-60	Clip, Wire Lock
				W10328378	Fan, Cooling (Right)		W10590933	Board, Transient Suppressor
							8019P026-60	Clip, Wire-Wrap Nylon
							7103P027-60	Nut


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Support, Backguard	4	7101P634-60	Screw	9	W10299338	Shield, Wire Cover
	W10319109	Black (Left)	5	W10648866	Control, Electronic	10		Skin, Control Panel
	W10319111	Black (Right)	6	W10278697	Shield, Vent			(Not Serviced)
2	W10776098	Cover, Backguard	7	9780274	Screw			
3		Console	8		Assembly, Overlay			
	W10645848	Stainless		W10692425	Black			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10332459	Shield, Heat	23	W10357697	Bracket, Side Panel	41	W10614824	Duct, Side Induction (Front)
2	W11479123	Spacer, Side Panel	24	W11544370	Light Assembly	42	8285593	Cover, Connector
3	7101P642-60	Screw	25	W10311987	Shield, Cord (Right)	43	W10624592	Cord, Power
4		Panel, Side	26	W10683517	Lock, Rear Mount	44	W10720084	Screw
	W11477310	Black	27	W10268560	Cover, Wire Lower	45	W11515373	Front, Main (Lower)
5	3801F656-51	Bracket, Anti-Tip	28	7003P104-60	Insulator, Heat Shield	46	W11515376	Front, Main (Upper)
6	W10312612	Cover, Access (Terminal Block)	29	W10538516	Shield, Side Insulation	47	4449743	Screw
7	7403P899-60	Switch, High Limit	30	W10410463	Cover, Hinge (Left)	48	489290	Screw
8	7101P507-60	Foot, Leveler		W10410461	Cover, Hinge (Right)	49	7101P633-60	Screw (Black)
9	W10105790	Bumper & Screw	31	W11491754	Gasket, Oven Door (Upper)	50	7101P338-60	Screw
10	7430P044-60	Sensor, Oven		W11491753	Gasket, Oven Door (Lower)	51	7101P635-60	Screw (Black)
11	W10268559	Cover, Lower Wire	32	7101P426-60	Screw	52	W11030753	Block, Terminal
12	7101P376-60	Screw	33	W10190166	Bracket, Power Supply	53	3400029	Nut
13	W10332449	Shield, Cord	34	W10261388	Bracket, Terminal	54	7101P500-60	Screw
14	W10261386	Cover, Main Wire	35	W10548601	Pan, Element			INSULATION PARTS (NOT ILLUSTRATED)
15	W10337391	Tube, Vent (Upper)	36	W10253470	Bracket, Retaining	W10271637		Insulation, Floor
16	W10668730	Back, Main	37	W10260545	Clip, Retaining	W10322111		Insulation, Back
17	W10323793	Tube, Vent (Lower)	38	7407P103-60	Bulb, Light	W10204079		Insulation, Middle
18	7101P434-60	Screw	39	W10863342	Support, Lower Oven	W11462751		Insulation, Wrapper
19	W10322408	Adapter, Vent Tube	40	W10466974	Duct, Side Induction (Back)	W10204085		Insulation, Main Front Strip
20	W10319087	Bracket, U Channel				W11463064		Insulation, Hidden Bake Pouch
21	7101P485-60	Screw, Anti-Tip Kit						
22	8036P012-60	Shield, Power Cord						


INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10570887	Rack, Oven	7	W10631504	Nut, Acorn (LH)	14	W10570870	Rack, Oven (Telescoping)
2	W10249979	Element, Broil (Lower)	8	W10274268	Insulation, Convection Motor	15	W10685968	Rack, Steam
3	W11095935	Bake Element (Upper & Lower)	9	W10339476	Plate, Insulation	16	W10686408	Kit, Reservoir (Steam Rack)
4	W10317476	Element, Broil (Upper)	10	W10720084	Screw	17	7101P426-60	Screw
5	W11190725	Motor, Convection	11	8303962BU	Cover, Fan			
6	W10631503	Blade, Fan	12	W10319762	Shield, Broil			
			13	W10271639	Element, Convection (240VAC)			


UPPER DOOR PARTS



UPPER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11051041	Lining, Door	10	W10645182	Bracket, Door Handle	16	W10551026	Medallion, Handle
2	W11099272	Glass, Inner	11		Assembly, Door Handle	17	W10898280	Screw
3	W10272708	Frame, Glass		W11305108	Stainless			
4	W10292297	Screw	12	W10485733	Hinge, Door (Left)			
5	W10485723	Retainer, Insulation		W10485732	Hinge, Door (Right)			
6	W10321271	Insulation, Door	13	W10031780	Screw			
7	W10289077	Receiver, Hinge	14	W10656499	Screw			
8		Assembly, Door	15	W10284411	Screw with Washer			
	W11527830	Stainless						
9	W10480830	Screw						

LOWER DOOR PARTS



LOWER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door Handle	7	9757706	Glass, Inner	13	W10272329	Receiver (Left)
	W11305108	Stainless	8	W10335434	Hinge, Door (Left)		W10272328	Receiver (Right)
2		Assembly, Door		W10335433	Hinge, Door (Right)	14	W10656499	Screw
	W11489780	Stainless	9	W10292008	Lining, Door	15	W10284411	Screw with Washer
3	W10645182	Bracket, Door Handle	10	4449040	Screw	16	W10551026	Medallion, Handle
4	W10480830	Screw	11	W10340464	Retainer, Insulation	17	7109P084-60	Washer, Fiber
5	W10272594	Frame, Glass	12	W10321285	Insulation, Door	18	W10898280	Screw
6	W10518672	Badge						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	W10355016	Cleaner, Stainless Steel
	31605	Kit, Cooktop Care
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	WA906B	Scraper, Cooktop
	4396923	Broiler Pan and Grid
	W10432539	Griddle
	4396927	Rack, Oven (Split)