




GAS RANGE

MODELS:

WFG515S0MS1 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	11	7101P485-60	Screw, Anti-Tip Kit
	W11427476	Quick Start Guide		W11331143	Black			FOLLOWING PARTS NOT ILLUSTRATED
	W11426600	Owner's Manual	5		Panel, Manifold			
	W11508882	Wiring Diagram		W11089575	Black	W11457167		Harness, Main
2		Burner Cap Kit	6		Knob, Control	W11450461		Harness, Bake and Broil
	W11395131	Black (Set of 4)		W11510457	Black			
3	W11352018	Spreader, Flame	7		Kit, Grate (Set of 2)	W10334923		Clip, Gas Wiring
		(Left Front and Right Front)		W11603169	Grates, Cooktop	3196520		Clip, Wire
	W11352020	Spreader, Flame	8	W10673618	Screw	3196896		Clip, Wire
		(Left Rear)	9	3196557	Screw	313438		Clip, Harness
	W11352021	Spreader, Flame	10	W11379945	Bracket, Anti-Tip			
		(Right Rear)						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	5	W10920631	Module, Spark DSI	11	3196169	Screw
	W11130372	Black (Left)	6	W10516123	Bracket, Console Mounting	12		Control, Range (LCC190)
	W11130379	Black (Right)					W11520699	Black
2	8053505	Shield, Heat	7	8523412	Bracket, Rear Cooktop	13	3196178	Screw
3		Panel, Control	8	W10198745	Cover, Upper	14	W10695491	Bracket, Control
	W10835288	Stainless	9	W10192841	Shield, Heat	15	W10797001	Bracket, Ignitor
4	W10762981	Bracket, Mounting	10	W10184370	Cover, Back	16	W10110488	Module, Spark


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	15	8053968	Shield, Lower	26	W10289077	Receiver, Hinge
2	8272747	Shield, Flue	16	W10390008	Base Rail Assembly (Left)	27	W11511828	Switch, Door
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	28	W11634772	Light Assembly
4		Panel, Side				29	W10571723	Bulb, Halogen 40 Watts
	W10162245	Black	17	9757239	Rod, Door Switch	30	9761013	Front Door Latch Assembly
5	W10137382	Clip, Panel	18	W10031780	Screw			
6	8523249	Bracket, Manifold	19	3400080	Screw	31	W10078370	Rod, Push Latch
7	W10362924	Screw	20	W11173792	Rack, Oven	32	W10107820	Rear Door Latch Assembly
8	3196560	Screw	21	W11491751	Seal, Door			
9	W10341186	Front Foot Assembly	22	W10435470	Brace, Main Back	33	W10674705	Glide, Drawer Front
10	W10058460	Foot, Leveling	23	W11379353	Retainer, Insulation (Left)	34	3196178	Screw
11	3195097	Bottom, Oven		W11379943	Retainer, Insulation (Right)			FOLLOWING PARTS NOT ILLUSTRATED
12	W10586204	Sensor					8524099	Insulation, Wrap
13	8053967	Baffle, Burner Oven	24	3196560	Screw		W10180437	Insulation, Back
14	8053969	Shield, Heat	25	W10910642	Cord, Power			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	9	W10224921	Bracket, Aegis	24	W11428831	Electrode (Left Front, Left Rear)
2	W10949105	Bracket, Saddle Valve	10	3196385	Screw			
3	W11459257	Orifice Holder Assembly (15K) (Left Front)	11	3400016	Screw		W11428858	Electrode (Right Front, Right Rear)
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)	12	8054078	Burner, Broiler			FOLLOWING PARTS NOT ILLUSTRATED
	W11459260	Orifice Holder Assembly (15K) (Right Front)	13	W10184491	Spreader, Flame (Oven)		W10566537	LP Bake and Broil Kit
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	14	9758078	Burner, Bake		W10400495	Orifice, LP Bake
4	W10215439	Tubing (Manifold to Regulator)	15	W11370883	Regulator		W10465080	Orifice, LP Broil
5	W11537750	Harness, Switch	16	W10333842	Electrode, Broil		W11489400	LP Conversion Kit
6	W11450459	Electrode, Bake	17	W10420040	Tube, Broiler Supply		W10182767	Tie, Manifold Wire
7	W11510001	Manifold Assembly	18	W11435700	Fitting, Broiler			
8	W11509685	Valve, Gas (Left Front and Right Front)	19	W11485872	Orifice (15K) (Left Front and Right Front)			
	W11509686	Valve, Gas (Left Rear)		W11485873	Orifice (9.5K) (Left Rear)			
	W11509687	Valve, Gas (Right Rear)		W11485871	Orifice (5K) (Right Rear)			
			20	W10137062	Spreader, Flame (Broiler)			
			21	3196265	Screw			
			22	W10362924	Screw			
			23	W10827923	Electrode, Spring			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11242950	Stainless
2		Trim, Lower
	W11444043	Black
3	W10480830	Screw
4	9761344	Liner, Door
5	W10031790	Screw
6	W11044424	Glass, Inner
7	W10316950	Frame, Glass

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10299224	Hinge, Active (With Spring)
11		Glass, Outer Door
	W10884159	Black
12		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10299227	Hinge, Door (Passive)
16	W10884775	Badge
17	W10200660	Screw

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	2	W10688022	Drawer, Storage	4	W10674708	Glide, Drawer Rear
	W11190207	Stainless	3	W10462909	Bracket, Mounting	5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	285006	Black
	350930	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting